
RM-E1000T

SERVICE MANUAL

US Model Canadian Model AEP Model UK Model



(Control Unit)

For MICRO FLOPPYDISK DRIVE, refer to the "MPF420-1/11C of SERVICE MANUAL MPF420" (9-976-305-10).

SPECIFICATIONS

Input jacks

Video 5 lines (PLAYER INPUT 1/2/3/RECORDER

IN/PROCESSOR IN)

S-VIDEO IN: 4-pin mini DIN (5)

Luminance 1 Vp-p, 75 ohms, unbalanced,

sync negative

Chrominance 286 mVp-p, 75 ohms,

unbalanced

VIDEO IN: Phono jack (5)

1 Vp-p, 75 ohms, unbalanced, sync negative 6 lines (PLAYER INPUT 1/2/3/AUX AUDIO

Audio

INPUT/RECORDER IN/PROCESSOR IN)

Phono jack

—7.5 dBs, impedance 47 kohms or more

Microphone Minijack (front 1)

–60 dBs, 3 kohms or more

Output jacks

4 lines (RECORDER OUT/MONITOR OUT/ Video

PROCESSOR OUT 1/2)

S-VIDEO OUT: 4-pin mini DIN (4) Luminance 1 Vp-p, 75 ohms, unbalanced,

sync negative

VIDEO OUT: Phono jack (4)

1 Vp-p, 75 ohms, unbalanced, sync negative 4 lines (RECORDER OUT/MONITOR OUT/

Audio PROCESSOR OUT 1/2) Phono jack, -7.5 dBs, impedance 470 ohms or

Stereo mini-minijack (rear 3, front 1) **C** LANC CTRL S

Minijack (1)

GPI

Minijack (1)

EDIT I/F

8-pin mini DIN (1)

IR REPEATER

Stereo mini-minijack (1)

Headphones

Stereo mini-minijack (1)

12 mW (47 ohms), appropriate impedance

8 ohms or more

General

Power requirements

European models except the United

Kingdom: 220 - 230 V AC, 50/60 Hz

The United Kingdom models: 230 - 240 V AC,

50 Hz

USA/Canadian models: 120 V AC, 60 Hz

Power consumption

18 W

Operating temperature

5°C to 35°C (41°F to 95°F)

Storage temperature

-20°C to +60 °C (-4°F to +140°F)

-continued on next page-

VIDEO EDITING CONTROLLER/TITLER SONY



Main unit: Approx. $430 \times 71 \times 360$ mm (w/h/ Dimensions

d) $(17 \times 2^{7}/8 \times 14^{1}/4 \text{ inches})$

Control unit: Approx. $340 \times 55 \times 228$ mm (w/

h/d) $(13^{1}/2 \times 2^{1}/4 \times 9 \text{ inches})$

Keyboard: Approx. $340 \times 50 \times 180$ mm (w/h/

d) $(13^{1}/2 \times 2 \times 7^{1}/8 \text{ inches})$

Mass

Main unit: Approx. 4 kg (8 lb. 13 oz.)

Control unit: Approx. 1 kg (2 lb. 3 oz.)

Keyboard: Approx. 0.7 kg (1 lb. 9 oz.)

Supplied accessories

See page 1-5.

Design and specifications are subject to change without notice.

Note (AEP, UK models: PAL)

This appliance conforms with EEC Directive 87/308/EEC


regarding interference suppression.

US, Canadian models: NTSC

SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

- 1. Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
- 2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
- 3. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
- 4. Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
- 5. Check the line cord for cracks and abrasion. Recommend the replacement of any such line cord to the customer.
- 6. Check the B+ voltage to see it is at the values specified.
- 7. Check the antenna terminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.



LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microampers). Leakage current can be measured by any one of three methods.

- A commercial leakage tester, such as the 1. Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
- 2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
- Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75 V, so analog meters must have an accurate lowvoltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2V AC range are suitable. (See Fig. A)

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY MARK A OR DOTTED LINE WITH MARK A ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUB-LISHED BY SONY.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFIÉS PAR UNE MARQUE A SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COM-POSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPLÉMENTS PUBLIÉS PAR SONY.

TABLE OF CONTENTS

Sect	<u>Title</u>	<u>Page</u>	Section	<u>Title</u>	Page
SER	RVICE NOTE		and Sch	ematic Diagrams	4-3
	RVICE MODE			/26U Board	
	Entry in Service Mode	5	● FD-51 B	oard	4-31
	Use of Service Mode		● FL-59P/	59U, FR-85/85P and PS-317/317	P Boards 4-35
				175P and EI-2/2P Board	
1.	GENERAL			3oard	
• P:	arts Identification	1-1	● CM-42 H	Board	4-57
	Ienu Map			97U and PW-106P/106U Boards	
	That You Can Do with the Editing				
	Controller/Titler	1-5	5. REPA	IR PARTS LIST	
	upplied Accessories			PLODED VIEWS	5-1
	stalling the Lithium Battery		5-1-1.	Control Complete Assembly	5-1
	sable Video Equipment			Main Overall Assembly	
	onnecting the Players			Keyboard Complete Assembly	
	onnecting the TV and Power Sources			Keyboard Unit (1)	
	onnecting the Keyboard and Control Unit			Keyboard Unit (2)	
	onnecting the Recorder			ECTRICAL PARTS LIST	
	etting the Recorder Control System		• AC-	97P/97U Board	5- 6
	onnecting Other Equipment			26P/26U Board	
	rogram Editing		● CM-	42 Board	5-24
	evising the Program		● EI-2	/2P Board	5-26
	enerating the Special Effects		● FD-	51 Board	5-27
	djusting the Timing—To Edit Scenes Precisely			59P/59U Board	
	ptional Settings			85/85P Board	
	uperimposing Titles		• KM	-13 Board	5-29
	aving/Loading the Program in the Disk		• PS-3	317/317P Board	5-30
	ontrolling the Digital SEG			-106P/106U Board	
				175/175P Board	
2.	DISASSEMBLY			re List	
2.1.	Removal of Upper Case, Bottom Plate and				
	Front Panel	2-1	6. INTEI	RFACE AND IC PIN FUNCTION	N
2-2.	Removal of P\$317/317P Board,			Screen Display Control Microcon	
	FL-59P/59U Board and FR-85/85P Board	2-1		90076B (AV-26P/26U Board IC79	_
2-3.	Removal of FD Drive and FD-51 Board			Function Description	•
2-4.	Removal of AV-26P/26U Board			nt Microcomputer HD643383F	
2-5.	Removal of AC-97P/97U Board and			-26P/26U Board IC801) Port Fur	nction
	PW-106P/106U Board	2-3		cription	
2-6.	Removal of RP-175/175P Board and			Microcomputer HD643383F	
	EI-2/2P Board	2-3		-26P/26U Board IC802) Port Fur	nction
2-7.	Removal of Control Unit Lower Case			cription	
2-8.	Removal of CM-42 Board			NC Microcomputer MB89131	
2-9.	Removal of Keyboard Lower Case			-26P/26U Board IC803, IC804), C	Controller
2-10		2-4	•	rocomputer MB89131 (CM-42 Bo	
2-11				board Microcomputer MB89131	,,
				I-13 Board IC805) Port Function	Description
3.	BLOCK DIAGRAMS				-
3-1.	Overall Block Diagram	3-1	3		
3-2.	Video Block Diagram		7. ADJU	STMENTS	
3-3.	Control Block Diagram			CCTRICAL ADJUSTMENTS	7-1
3-4.	Audio Block Diagram			reparation before Adjustment	
3-5.	Power Block Diagram			Equipment Required	
J 0.				Equipment Connection	
4.	PRINTED WIRING BOARDS AND			Input Signal Check	
	SCHEMATIC DIAGRAMS			Input/Output Levels and Impeda	
4-1.		4-1		ower Supply Check	
4-2.	_			Output Voltage Check	
	• This Note in Common for Printed Wiring Bo			ideo System Adjustments	

<u>Section</u>	<u>Title</u>	Page
1-3-1.	Y Level Adjustment	7-3
1-3-2.	Chroma Level Adjustment	7-3
1-3-3.	White Fade Level Adjustment	7-4
1-4.	Display System Adjustments	7-4
1-4-1.	OSD Hue Adjustment	7-4
1-4-2.	Internal Sub-Carrier Frequency Check.	7-5
1-4-3.	OSD AFC Voltage Check	7-5
1-5.	Adjusting Parts Location Diagram	7-6

SERVICE NOTE

SERVICE MODE

 As well as normal operations, RM-E1000T offers Service Mode. Various functions to help you service and check the set are incorporated in the system and available in this mode.

The function to read the contents of a destroyed floppy disk is available.

This is helpful for responding to a recovery request from a customer who destroyed its important data by any accidental trouble such as disk failure.

CAUTION: The contents of memory storing edit data may be destroyed. The data should be stored in a floppy disk in normal mode befere entering Service Mode.

1. ENTRY IN SERVICE MODE

- To put RM-E1000T in Service Mode, proceed as follows:
- Connect a monitor to MONITOR OUT terminal.
- 2) Connect Control Unit and Keyboard to Main Unit.
- 3) Put the system in STAND-BY mode.
- 4) Move all of four slide VR's (MIC LEVEL/AUDIO MIX/AUDIO FADER/VIDEO FADER) on Control Unit to the top position.
- 5) Push POWER button and hold down it and perform the following operations:
- 5-1) Wait the Demo screen to appear.
- 5-2) Lower AUDIO FADER slowly (to bottom).
- 5-3) Lower VIDEO FADER slowly (to bottom).
- 5-4) Raise AUDIO FADER slowly (to top).
- When Steps 1) to 5) are normally performed, the Service Menu will be displayed with a beep.

① -	E1000T (
<pre>② -</pre>	Menu (□])
3 -	MENU TOUR	
4 -	Color Bar	
⑤ —	Key	
6 -	LED	
⑦ -	Volume/JS	
8 –	ROM/RAM/AB	
9 -	FD Check	
10 –	FD Load Compulsion	
	Ready ● Load	OK

Service Menu

2. USE OF SERVICE MODE

(Refer to Service Mene)

- 1 This indicates the version of Front micom.
- ② This indicates the version of Menu ROM.
- ③ Select this with the cursor and press YES to display all Menu and Dialogue information. (Select the desired menu and language with the cursor.)
- ④ Select this with the cursor and press YES to display color bar. (Press NO to return to Service Menu.)
- ⑤ Select this with the cursor and press YES to display the name of a specific button key on control unit. Push that button. When all the buttons have been pushed, you will return to Service Menu. (The buttons on control unit can be checked.)
- ⑥ Select this with the cursor and press YES to allow the LED indicator on control unit specified on the screen to be lit. Go to the next LED with the down cursor key. When all the LED indicators have been lit, you will return to Service Menu. (The LED's on control unit can be checked.)
- ⑦ Select this with the cursor and press YES to display the current set values of slide VR's and Jog/Shuttle on control unit. Move these controls. The values of slide VR's will change from 0 to 255.

Depending on the number of rotations, the value of Jog Pulse will change from 0 to 1 to 2... When Jog-dial control is rotated clockwise and it will change from 0 to 255 to 254... When rotated counter clockwise. Depending on the angle of turn, the value of Shuttle position will increase when Shuttle control is turned clockwise and it will decrease when turned clockwise.

Press NO to return to Service Menu.

Select this with the cursor and press YES to open the
 Menu ROM and RAM Check Menu. Select each memory and
 press YES to check it. (This function is used for software
 debugging as well as Menu ROM and RAM check.)

Press NO to return to Service Menu.

CAUTION: Other than check, the contents of memory storing edit data will be destroyed. The data be stored in a floppy disk in normal mode.

FD Tests

TEST LINE
TEST NO DISK
TEST WRITE PROTECT
TEST 2DD
TEST 2HD

FD Tests Menu

- TEST LINE: Press YES to check communication between Front micom and FD micom. This should be checked first of all. (After this check, move to the next item.)
- 2) TEST NO DISK: Press YES without inserting floppy disk. This checks the disk-remove detect function.
- 3) TEST WRITE PROTECT: Insert a write-protected floppy disk into drive and press YES. This checks the write-protect detect function.
- 4) TEST 2DD: Insert a 2DD floppy disk whose data may be cleared and press YES. This performs the formetsave-verify operation.
- 5) TEST 2HD: Insert a 2HD floppy disk whose data may be cleared and press YES. This performs the format-save-verify operation.
- Select NO from FD Tests Menu to return to Service Menu.
- ① This mode reads by compulsion a floppy disk that cannot be read in normal mode. In normal mode, the system check the format of all data and will load data on memory only when there is no fault. This function is used if you want to read the data on a partially destroyed disk anyhow.

Insert destroyed floppy disk into drive and press YES. If destroyed data is found, the Test Disk Error dialogue will be displayed. Take a note of the sector number. Press YES to return to Service Menu.

If only that sector is destroyed, OK will be marked "•". If any other sectors are destroyed, Load will be marked "•". If so, press YES. The system continues this operation and find another destroyed data.

When OK is marked "●", press MENU button and return to normal mode. Save the data to a new floppy disk.

For how the destroyed sector numbers are associated with the data, see the following teble. Load Compulsion

Test Disk Error

SECT

(□□□□: Sector No.)
Test <u>Disk Error Dialogue</u>

• SECTOR DATA TABLE

SECTOR	DATA
000	SYSTEM DATA, CUT DATA 1
001	CUT DATA 2, 3
002	CUT DATA 4, 5
003	CUT DATA 6, 7
004	CUT DATA 8, 9
005	CUT DATA 10, 11
	SECT No. ×2+1
044	CUT DATA 88, 89
045	CUT DATA 90, 91
046	CUT DATA 92, 93
047	CUT DATA 94, 95
048	CUT DATA 96, 97
049	CUT DATA 98, 99
050-051	TIMING ADJUST DATA
052-067	REMOTE COM LEARNNING DATA
068-071	TITLE DATA 1
072-075	TITLE DATA 2
076-079	TITLE DATA 3
080-083	TITLE DATA 4
084-087	TITLE DATA 5
088-091	TITLE DATA 6
092-095	TITLE DATA 7
096-099	TITLE DATA 8
100-103	TITLE DATA 9
104-107	TITLE DATA 10
108-111	TITLE DATA 11
112-115	TITLE DATA 12
116-119	TITLE DATA 13
120-123	TITLE DATA 14
124-127	TITLE DATA 15

SECTION 1 GENERAL

MOVE SEL (select) button (p. 38)

MOVE END button (p. 38)

[27] CUT DATA button (p. 35, 36, 42)

25 MENU button (P. 17, 46, 51, 57)

25 EDIT LIST button (p. 37)

23 1 CUT PREVIEW button (p. 31)

24 GO TO button (p. 37, 41)

21 EDIT START button (p. 32)

22 PREVIEW button (p. 31)

30 YES button (p. 17, 37, 46, 51, 57)

31 NO button (p. 37) 32 Arrow buttons

29 DEL (delete) button (p. 39)

28 COPY button (p. 38)


This section is extracted from instruction manual.

67

Parts Identification

For the use of each control, see the pages indicated in the parentheses.

Control Unit




國富


Parts Identification

Main Unit

Front panel



Rear panel



- [f] POWER ON/STANDBY switch (p.33)
 - 2 Standby lamp
- 3 PLAYER/RECORDER select buttons (p.33)
 - [4] HEADPHONES LEVEL control
- Connect the headphones (not supplied). 5 HEADPHONES jack
- (6) CONTROL UNIT connector (p.11)
 - Thoppy disk drive (p. 56)
- B Remote sensor (p.20)
- [9] IR REPEATER connector (p.15)

PROCESSOR OUT (output) 1, 2 jacks (p. 23)


23 GP! OUT (output) jack (p. 23)

22 CTRL (control) SOUT (output) jack (p. 14) [2] MONITOR OUT (output) jacks (p. 10)

20 AC INLET connector (p. 10)

- [I] MIC (microphone) jack (p. 24)
- [1] Lithium battery compartment (bottom) (p. 6)
- 12 PLAYER INPUT 3 jacks (p. 10)
- (p. 6) 1/2 jacks (p. 9)

Keyboard



- Title number buttons (1 to 15, OUT) (p. 55)
 - [2] MENU button (p. 17, 46, 51, 57)

MANUAL OUT (SPACE) button (p. 54,55) [3] MANUAL IN (SPACE) button (p. 54, 55)

14 SUPER-TITLE button (p. 54)

[S] COPY button (p. 54)

- 4 CTRL (control) button (p. 54) 3 TITLE LIST button (p. 54)
- SHIFT button (p. 54)
- Wipe effect buttons (p. 55) G CAPS button (p. 54)

[14] AUX (auxiliary) AUDIO INPUT jack (p. 24)

15 PROCESSOR IN (input) jacks (p. 23)

[6] EDIT 1/F OUTPUT jack (p. 23)

- 8 "font" button (p. 54)
- [9] "size" button (p. 54)
- [1] MARK TITLE (SPACE) button (p. 54) 10 "colour" button (p. 54)

[I] RECORDER IN/OUT (input/output) connectors (p. 13, [7] RECORDER & LANC connector (p. 13, 14, 15)

22 DEL (delete) button (p. 54)

[2] INS (insert) button (p. 54)

[9] Arrow buttons (p. 54) Return button (p. 54)

SHIFT button (p. 54)


T YES button (p. 55) 16 NO button (p. 55)

- 23 BS (back space) button (p. 54)

Parts Identification

Entry Mode Display

Turn on the power and press YES to display this.



- Player number (The number indicates the 1, 2 or 3 of PLAYER INPUT jacks.) [1] Cut number
 - 3 Tape transport mode of the player
- [4] TITLE, EDIT 1/F or GPI counter (Appears when you press TITLE, EDIT 1/F or GPI, see p. 55, 60, 61).
 - [5] IN point counter (or time code)
- (6) OUT point counter (or time code)
 - T Current counter of the player

Edit List

Press EDIT LIST on the entry mode display to display this.

IN point list

2 Player number 1 Cut number 3 IN point

Cut name list

3 Player number


6 Cut name

4 Cut number

9 45

3 Player number 7 Cut number


3 Lap time (Playback time of each cut) 10 Total time of the program




Lap time list

Cut Data Display

After selecting the cut number on the entry mode display, press CUT DATA to disply this.



- [1] Player number (The number indicates the 1, 2, or 3 of PLAYER INPUT jacks.) [2] Cut number Cut name
 - | IN point counter
- (B) Video/audio effent icon (p. 41) 5 OUT point counter
- You can look at the following items by scrolling with ♠, ◆. [7] Synchronized playback point (p. 60)
 - EDIT 1/F or GPI points (p. 60, 61)
 - 1 TITLE IN/OUT points (p. 55)



What You Can Do with the Editing Controller/Titler

Supplied Accessories

When you played back a tape, did you feel that it was too long and had some unnecessary scenes. Or, the tape would look more interesting if that scene come before this scene.

Û Unneccesary scene Unneccessary scene

00

A/V connecting cable (1)

Check that the following accessories are included.

Control unit (1)

LANC @/CONTROL L connecting cables (2)

6

CONTROL L cable adaptors (2)

CONTROL S/GPI connecting cables (2)

You can edit the tape like this (page 25). (PA)

of the second B

This unit enables you to edit using up to 3 pla

Û

When you want to make one story using scenes from more than one tape

Keyboard (1)

IR repeater (1)

Power Cord (1) Operation Manual (1)

Lithium Battery (1)

œ

Ê

927

E

S video connecting cable (1)

No.


The unit can generate special effects such as monotone and cinema (page 41) so that you can enjoy processing images. Furthermore, by connecting the Digital SEG (not supplied) to this unit, you can enjoy making various other effects. The keyboard allows you to create and superimpose the titles for video images (p. 53).

4

Installing the Lithium Battery

Install the supplied lithium battery to keep the data of programs aretings, intaining adjustment settings, and the furthciton of a non-Sony recorder stored. Note that the lithium battery has a positive (+) and negative (-) terminal as

 $\widehat{\pm}$ Be sure to install the lithium battery so that terminals on the battery match the terminals on the unit.



Main unit (bottom) Install the supplied lithium battery with + side facing Open the lithium battery compartment lid at the bottom of the main unit. Close the lid. M

Press the side of the battery as shown in the illustration. To avoid a short-circuit, do not use a metallic object. To remove the battery





Wipe the battery with a dry cloth to assure a good contact. Do not hold the battery with metalik tweezers as they may cause a short-circuit.

WARNING

Isitery may explode if mistreated. Do not recharge, disassemble or lispose of in fire.

Keep the lithium battery out of the reach of children. Should the battery be swallowed, consult a doctor immediately.

Usable Video Equipment

To use the video editing controller/titler, you need a player and recorder as specified below. For the descriptions on connecting the equipment, see from page 9.


Player

Video cassette player or video camera recorder that has:

• LANC Connector
• CONTROL L or REMOTE connector (Sony's)

Video cassette recorder or video camera recorder that has:

LANC & connector
 CANTROL Le ne REMOTE connector (Sony's)
 CONTROL Lipput connector (Sony's)
 CONTROL Lipput connector (Sony's)
 Inirared remote control system (depending on models)



Note on LANC & mark

Le stands for Local Application Control Bus System. The C control jack is used for controlling the tape transport of the video equipment and peripherals connected to it. This jack has the same function as the connectors indicated as CONTROL L or REMOTE.


Usable Video Equipment

Notes on Connection

- Be sure to turn off the power of the equipment before
- Be sure to use the equipment with its AC power adaptor connected to a wall outlet. If a battery pack is used and exhausted during editing, the editing will stop on the
- When both the player and the recorder have S video jacks, we recommend using the S video jacks to obtain a high
- Connect the red plug to the right audio jack (red.) and the white plug to the left audio jack (white).
 If you connect to both the S' video and video input jacks, the S' video signal is selected automatically. To view the video signal, disconnect the S' video input jack.
 You may connect the player to the VIDEO INPUT jack and the recorder to the S' VIDEO OUTPUT jack. Or, you may connect the player to the S' VIDEO INPUT jack and the recorder to the VIDEO OUTPUT jack. Or, you may connect the player to the S' VIDEO NPUT jack and the recorder to the VIDEO OUTPUT jack. The video signal input to the video edit controller fuller can be output through both the S' VIDEO and VIDEO OUTPUT jacks.
- When you connect a monaural player to the AUDIO INFUT jecks connect only the AUDIO-L plug (white). The sound is output from the left and right AUDIO OUTPUT jecks in monaural.
 - When connecting a monaural player to the AUDIO OUTPUT jack, use a monaural audio cable.

Note on the supplied CONTROL L cable adaptors

Use this adaptor when the CONTROL L, REMOTE or LANC C connector is the 5-pin () type.



Optional Connecting Cables

Use the supplied connecting cable to connect the player and recorder. When you need more cables, we recommend the following A/V connecting cables (not supplied).


	- stereo	Ì	Ŷ	•	~	monaural	•	Y	Ì	-2				4-pin plua				Ŷ	Phono plug	
₽	Audio: stereo	Í	1	þ	Phone plug 3	Audio: stereo ←	•		Ó	o plug 3 •				4-oin plug		n/ft)		•	Phono plug	
vg cable (m/ft)	1/3	15/5	2/2	3/10		1/3	1.5/5	2/7	3/10		cable (m/ft)	1/3	1.5/5	2/7	3/10	ting cable (n	1/3	1.5/5	2/7	3/10
AV connecting cable	VMC-8105	VMC-8135	VMC-8205	VMC-8305		VMC-910MS	VMC-915MS	VMC-920MS	VMC-930MS		S connecting cable (m/ft)	YC-10V	YC-15V	YC-20V	YC-30V	Video connecting cable (m/ft)	VMC-10	VMC-15	VMC-20	VMC-30

LANC E/CO	NTROL L C	LANC CACONTROL L connecting cable (m/ft)
VK-620	2/2	L-shaped stereo mini-miniplug
VK-810	2/7	E < ■
EDIT W connecting cable (m/ft)	necting ca	bie (m/ft)
SMF-540	2/7	Er Men Graff og
Audio connecting cable (m/ft)	ecting cab	le (m/ft)
RK-C310	1/3	stereo → stereo
RK-C315	1.5/5	
2K-C38	3/10	Phono plan 2 11 2
RK-C210	1/2	January Consts
8	2/2	
RK-C230	3/10	Phono plug 2 → 1
GPI connecting cable (m/ft)	ting cable	(m/ft)
RK-C60	1/3	
RK-C67	2/2	
Other accessories	sories	Cable (m/t)
Microphone F-PC30	F-PC30	2/7
Headpones MUK-34	4DK-34	7/7


Connecting the Players

You can connect up to 3 players. Connect them to the PLAYER INPUT 1 and PLAYER INPUT 2 jacks on the rear and the PLAYER INPUT 3 on the front of the main unit.

Connecting a Player with an S Video Jack




Connecting a Player without an S Video Jack




Connecting the Players

Connecting the Player to PLAYER INPUT 3 on the Front



When the player has no S video jack, connect to the VIDEO jack.

Connecting the TV and Power Sources




When the TV has no S video jack, connect to the VIDEO jack.

Connecting the Keyboard and Control Unit

Connect the keyboard directly to the main unit, and the control unit to the keyboard.

You can connect the control unit directly to the main unit when you do not use the keyboard.



2

Connecting the Recorder

Which Connection to Make?


The way to connect the recorder depends on what kind of control jack or system the recorder has. Follow the flowchart below to find out the connection for your recorder. After connecting the recorder as described in the appropriate page, set the recorder control system (p.16).

You cannot use your recorder with this video editing controller/titler. Does the recorder have an infrared remote control system? ş Does the recorder have a CONTROL 5 connector? Does the recorder have a CONTROL L or REMOTE connector? Connection 3 (page 15) Yes Does the recorder have a LANC & connector? ş Connection 2 (page 14) ş Is the recorder a Sony? Connection 1 (page 13) Yes Yes , Start here. Υes

Connection 1

- Connect as illustrated below;
 when your recorder has a LANC & connector, or
 when your recorder is a Sony and has a CONTROL L or REMOTE connector.


Note: When you connect to the VIDEO jack, do not use the S VIDEO jack. If you do, the video signal cannot be input. When the recorder has no S video jack, connect to the VIDEO jack.




RM-E1000T

Published by Personal A & V Products Div. Quality Engineering Dept.

2-3. REMOVAL OF FD DRIVE AND FD-51 BOARD




2-4. REMOVAL OF AV-26P/26U BOARD




2-5. REMOVAL OF AC-97P/97U BOARD AND PW-106P/106U BOARD


Note: The set positioned upside-down




2-6. REMOVAL OF RP-175/175P BOARD AND EI-2/2P BOARD




2-7. REMOVAL OF CONTROL UNIT LOWER CASE




2-8. REMOVAL OF CM-42 BOARD (CONTROL UNIT)



2-9. REMOVAL OF KEYBOARD LOWER CASE




2-10. REMOVAL OF KM-13 BOARD (KEYBOARD)




2-11. CIRCUIT BOARDS LOCATION


• MAIN UNIT



5-1-2. MAIN OVERALL ASSEMBLY




5-1-3. KEYBOARD COMPLETE ASSEMBLY




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
101	X-3943-910-1	CASE ASSY, KEY BOARD UPPER		106	4-864-324-11	SPACER	
102	3-703-710-41	STICKER, SONY SYMBOL (12)		107	3-953-461-01	FOOT	
103	1-467-712-11	KEY BOARD UNIT		* 108	3-954-645-01	SHEET (A)	
* 104	A-7072-024-A	KM-13 BOARD, COMPLETE		109	1-751-796-11	CORD, CONNECTION	
105	3-956-837-01	CASE KEY ROARD LOWER				·	

5-1-4. KEYBOARD UNIT (1)



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
151	9-907-778-01	KEY TOP QG175A	(SHIFT) (BLACK)	159	9-907-749-01	SHAFT, CRANK	
152	9-907-761-01	KEY TOP QY200A	(MARK TITLE) (BLACK)	160	9-907-750-01	RUBBER, CLICK ST-2	
153	9-907-760-01	KEY TOP QY200A	(MANUAL IN) (BLACK)	161	9-907-751-01	CHIP, GUIDE	
154	9-907-759-01	KEY TOP QY200A	(MANUAL OUT) (BLACK)	162	9-907-752-01	RUBBER, CONTACT	
155	9-907-755-01	KEY TOP QG200A	(YES) (BLACK)	163	9-907-748-01	SHAFT, CRANK	
156	9-907-781-01	KEY TOP QGG150A	A (←) (BLACK)	* 164	9-907-754-01	FRAME HJX-9	
157	9-907-717-01	KEY TOP QG200A	(↑) (BLACK)	165	9-907-753-01	MEMBRANE PRO	
158	9-907-766-01	KEY TOP QG200A	(↓) (BLACK)	166	9-907-747-01	SCREW (M2X4)	

5-1-5. KEYBOARD UNIT (2)



Ref. No.	Part No. Description	Remark	Ref. No.	Part No.	Description		Remark
201	9-907-746-01 KEY TOP Q150A	(MENU) (BLACK)	232	9-907-714	-01 KEY TOP Q10	OOA (S) (GRAY)	
202	9-907-745-01 KEY TOP Q100A	(1) (GRAY)	233	9-907-713	-01 KEY TOP Q10	00A (D) (GRAY)	
203	9-907-744-01 KEY TOP Q100A	(2) (GRAY)	234	9-907-712	-01 KEY TOP QH	.00A (F) (GRAY)	
204	9-907-743-01 KEY TOP Q100A	(3) (GRAY)	235	9-907-789	-01 KEY TOP Q10	OA (G) (GRAY)	
205	9-907-742-01 KEY TOP Q100A	(4) (GRAY)	236	9-907-788	-01 KEY TOP Q10	OA (H) (GRAY)	
206	9-907-741-01 KEY TOP Q100A	(5) (GRAY)	237	9-907-787	-01 KEY TOP QH:	.00A (J) (GRAY)	
207	9-907-740-01 KEY TOP Q100A	(6) (GRAY)	238	9-907-786	-01 KEY TOP Q10	OA (K) (GRAY)	
208	9-907-739-01 KEY TOP Q100A	(7) (GRAY)	239	9-907-785	-01 KEY TOP Q10	OA (L) (GRAY)	
209	9-907-738-01 KEY TOP Q100A	(8) (GRAY)	240	9-907-784	-01 KEY TOP Q10	OA () (GRAY)	
210	9-907-737-01 KEY TOP Q100A	(9) (GRAY)	241	9-907-783	-01 KEY TOP Q16	0A (?) (GRAY)	
211	9-907-736-01 KEY TOP Q100A	(0) (GRAY)	242	9-907-782-	-01 KEY TOP Q10	OA (,) (GRAY)	
212	9-907-735-01 KEY TOP Q100A	(-) (GRAY)	243	9-907-780-	-01 KEY TOP Q10	0A (←) (BLACK)	
213	9-907-734-01 KEY TOP Q100A	(&) (GRAY)	244	9-907-779	-01 KEY TOP Q10	$OA (\rightarrow) (BLACK)$	
214	9-907-733-01 KEY TOP Q100A	(BS) (BLACK)	245		-01 KEY TOP Q10		
215	9-907-732-01 KEY TOP Q100A	(DEL) (BLACK)	246	9-907-776-	-01 KEY TOP Q10	OA (X) (GRAY)	
216	9-907-731-01 KEY TOP Q100A		247	9-907-775-	-01 KEY TOP Q10	OA (C) (GRAY)	
217	9-907-730-01 KEY TOP Q100A		248		-01 KEY TOP Q10		
218	9-907-729-01 KEY TOP Q100A		249		-01 KEY TOP Q10		
219	9-907-728-01 KEY TOP Q100A		250		-01 KEY TOP Q10		
220	9-907-727-01 KEY TOP Q100A	(E) (GRAY)	251	9-907-771-	-01 KEY TOP Q10	OA (M) (GRAY)	
221	9-907-726-01 KEY TOP Q100A		252	9-907-770-	-01 KEY TOP Q10	0A (φ) (GRAY)	
222	9-907-725-01 KEY TOP Q100A		253			0A (β) (GRAY)	
223	9-907-724-01 KEY TOP Q100A	(Y) (GRAY)	254	9-907-768-	-01 KEY TOP Q10	OA (!) (GRAY)	
224	9-907-723-01 KEY TOP Q100A		255	9-907-767-	-01 KEY TOP Q10	OA () (GRAY)	
22 5	9-907-722-01 KEY TOP Q100A	(I) (GRAY)	256	9-907-765-	-01 KEY TOP Q19	OA (CAPS) (BLACK)
226	9-907-721-01 KEY TOP Q100A		257	9-907-764-	-01 KEY TOP Q10	OA (font) (BLACK)
227	9-907-720-01 KEY TOP Q100A	(P) (GRAY)	258	9-907-763-	-01 KEY TOP Q10	OA (size) (BLACK)
228	9-907-719-01 KEY TOP Q100A		259		-	OA (colour) (BLA	
229	9-907-718-01 KEY TOP (Œ)	• •	260		•	OA (SUPER-TITLE)	
230	9-907-716-01 KEY TOP Q125A	(CTRL) (BLACK)	261	9-907-757-	-01 KEY TOP Q10	OA (COPY) (BLACK)
231	9-907-715-01 KEY TOP Q100A	(A) (GRAY)	262	9-907-756-	-01 KEY TOP Q15	OA (NO) (BLACK)	

AC-97P AC-97U AV-26P AV-26U

5-2. ELECTRICAL PARTS LIST

NOTE:

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX and -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS
 All resistors are in ohms.
 METAL:Metal-film resistor.
 METAL OXIDE: Metal oxide-film resistor.

F:nonflammable

- Items marked "*" are not stocked since they are seldom required for routine service.
 Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS

 In each case, u:

In each case, $u:\mu$, for example: $uA\dots:\mu A\dots$ $uPA\dots:\mu PA\dots$

uPB..: μPB.. uPC..: μPC.. uPD..: μPD..

CAPACITORS uF: μFCOILS

uH: μH

When indicating parts by reference number, please include the board.

The components identified by mark \triangle or dotted line with mark. \triangle are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque <u>A</u> sont critiques pour la sécurité.

Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description		Re	mark	Ref. No.	Part No.	Description		Ren	nark
*	A-7072-018-A	AC-97P BOARD, (COMPLETE (A	EP, UK)		C021	1-164-232-11	CERAMIC CHIP	0. 01uF		50V
*	A-7072-046-A	AC-97U BOARD, (lied with P COMPLETE (U		-	C022	1-163-239-11	CERAMIC CHIP (AEP, UK)	33PF	5%	50V
			lied with P			C022	1-163-243-11	CERAMIC CHIP (US, Canadian)	47PF	5%	50V
				5,000 se	ries)	C023	1-163-038-00	CERAMIC CHIP	0. 1uF		25V
			(.,		C024		CERAMIC CHIP	0. 1uF		25V
		< CONNECTOR >									
						C025	1-126-204-11	ELECT CHIP	47uF	20%	167
∆ CN900	1-251-134-11	INLET, AC (NONE	POLAR) (AEP	, UK)		C026	1-163-038-00	CERAMIC CHIP	0. 1uF		25
_		INLET, AC. (US,	-	*****	****	C060	1-163-237-11	CERAMIC CHIP (AEP, UK)	27PF	5%	50V
	A-7066-028-A	AV-26P BOARD, (OMDIETE /A	ED IIK/		C061	1-163-141-00	CERAMIC CHIP (AEP, UK)	0. 001uF	5%	50V
*		AV-26U BOARD, (COMPLETE (U		an)	C062	1-163-141-00	CERAMIC CHIP (AEP, UK)	0. 001uF	5%	50V
			(Ref. No	1,000 se	ries)			(121, 011)			
		< BATTERY HOLDI	•	,		C063	1-164-232-11	CERAMIC CHIP (AEP, UK)	0. 01uF		50V
DATOON	1_550_104_21	HOLDER, BATTERY				C064	1-163-087-00	CERAMIC CHIP (AEP, UK)	4PF		50
DATOUU	1-330-104-21	HOLDER, DATTER				C069	1-163-125-00	CERAMIC CHIP	220PF	5%	50
		< CAPACITOR >						(AEP, UK)			
						C070	1-163-227-11	CERAMIC CHIP	10PF	0. 5PF	50
C013	1-163-239-11	CERAMIC CHIP (AEP, UK)	33PF	5%	50V	C071	1-163-227-11	CERAMIC CHIP	10PF	0. 5PF	50
C013	1-163-243-11	CERAMIC CHIP	47PF	5%	50V	C072	1-163-227-11	CERAMIC CHIP	10PF	0. 5PF	507
		(US, Canadian)				C073	1-163-227-11	CERAMIC CHIP	10PF	0. 5PF	501
C014	1-164-232-11	CERAMIC CHIP	0. 01uF		50V	C074	1-163-227-11	CERAMIC CHIP	10PF	0. 5PF	50
C015	1-163-239-11	CERAMIC CHIP	33PF	5%	50V	C075	1-163-227-11	CERAMIC CHIP	10PF	0. 5PF	501
		(AEP, UK)				C076	1-163-227-11	CERAMIC CHIP	10PF	0. 5PF	50
C015	1-163-243-11	CERAMIC CHIP	47PF	5%	50V						
		(US, Canadian)				C077	1-163-227-11	CERAMIC CHIP	10PF	0. 5PF	50
						C078	1-163-227-11	CERAMIC CHIP	10PF	0. 5PF	50
CO16	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	C079	1-163-227-11	CERAMIC CHIP	10PF	0. 5PF	50
C017	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	C092	1-163-239-11	CERAMIC CHIP	33PF	5%	50
C018	1-126-204-11	ELECT CHIP	47uF	20%	16V	C101	1-124-779-00	ELECT CHIP	10uF	20%	16
CO19	1-163-038-00	CERAMIC CHIP	0. 1uF		25V						
C020	1-163-239-11	CERAMIC CHIP	33PF	5%	50V	C102	1-124-779-00	ELECT CHIP	10uF	20%	16
		(AEP, UK)				C103	1-163-227-11	CERAMIC CHIP	10PF	0. 5PF	50
						C104	1-124-779-00	ELECT CHIP	10uF	20%	16
C020	1-163-243-11	CERAMIC CHIP	47PF	5%	50V	C105	1-124-779-00	ELECT CHIP	10uF	20%	16
		(US, Canadian)				C106	1-124-779-00	ELECT CHIP	10uF	20%	161

Ref. No.	Part No.	Description		Reл	ıark	Ref. No.	Part No.	Description		Ren	nark
C107	1-163-227-11	CERAMIC CHIP	10PF	0. 5PF	50V	C202	1-126-193-11	ELECT	1uF	20%	50V
C108	1-124-779-00	ELECT CHIP	10uF	20%	16V	C203	1-124-779-00	ELECT CHIP	10uF	20%	16V
C109	1-124-779-00		10uF	20%	16V	C204		CERAMIC CHIP	10PF	0. 5PF	50V
C110	1-163-227-11		10PF	0. 5PF	50V	C205	1-124-779-00		10uF	20%	16V
C111	1-124-779-00		10uF	20%	16V	C211	1-124-779-00		10uF	20%	16V
VIII	1 124 775 00	LECT OIL	1001	204)	101	0211	1 124 775 00	LLLO1 OIII	1041	204	101
C112	1-124-779-00		10uF	20%	16V	C212	1-124-779-00		10uF	20%	16V
C113	1-124-779-00		10uF	20%	16V	C213	1-124-779-00		10uF	20%	16V
C114	1-163-227-11		10PF	0. 5PF	50V	C214	1-124-779-00		10uF	20%	16V
C115	1-124-779-00	ELECT CHIP	10uF	20%	16V	C215	1-124-779-00	ELECT CHIP	10uF	20%	16V
C116	1-124-779-00	ELECT CHIP	10uF	20%	16V	C216	1-124-779-00	ELECT CHIP	10uF	20%	16V
C117	1-163-227-11	CERAMIC CHIP	10PF	0. 5PF	50V	C217	1-124-779-00	ELECT CHIP	10uF	20%	16V
C118	1-124-779-00		10uF	20%	16V	C218	1-124-779-00		10uF	20%	16V
C119	1-124-779-00		10uF	20%	16V	C219	1-124-779-00		10uF	20%	16V
C120	1-124-779-00		10uF	20%	16V	C220	1-124-779-00		10uF	20%	16V
C121	1-163-227-11		10PF	0. 5PF	50V	C221	1-124-779-00		10uF	20%	16V
V121	1 100 227 11	OLIUMIO OIII	1011	0, 011	001	0221	1 124 113 00	EBEOT OHT	Tour	20%	101
C122	1-124-779-00	ELECT CHIP	10uF	20%	16V	C231	1-124-779-00	ELECT CHIP	10uF	20%	16V
C123	1-124-779-00	ELECT CHIP	10uF	20%	16V	C232	1-163-235-11	CERAMIC CHIP	22PF	5%	50V
C124	1-163-227-11	CERAMIC CHIP	10PF	0. 5PF	50V	C241	1-163-235-11	CERAMIC CHIP	22PF	5%	50V
C125	1-124-779-00	ELECT CHIP	10uF	20%	16V	C242	1-163-235-11	CERAMIC CHIP	22PF	5%	50V
C126	1-124-779-00	ELECT CHIP	10uF	20%	16V	C243	1-124-779-00	ELECT CHIP	10uF	20%	16V
C197	1-124-779-00	ELECT CUID	10E	2012	100	0044	1 194 770 00	CLECT CHID	10P	anw.	101
C127			10uF	20%	16V	C244	1-124-779-00		10uF	20%	16V
C128	1-163-227-11		10PF	0. 5PF	50V	C251	1-124-779-00		10uF	20%	16V
C141	1-124-779-00		10uF	20%	101	C252	1-124-779-00		10uF	20%	16V
C151	1-124-779-00		10uF	20%	16V	C261	1-124-779-00		10uF	20%	16V
C152	1-124-779-00	ELECT CHIP	10uF	20%	16V	C262	1-124-779-00	ELECT CHIP	10uF	20%	16V
C153	1-163-227-11	CERAMIC CHIP	10PF	0. 5PF	50V	C263	1-126-193-11	ELECT	1uF	20%	50V
C154	1-124-779-00	ELECT CHIP	10uF	20%	16V	C264	1-126-193-11	ELECT	1uF	20%	50V
C155	1-124-779-00	ELECT CHIP	10uF	20%	16V	C265	1-126-193-11	ELECT	1uF	20%	50V
C156	1-124-779-00	ELECT CHIP	10uF	20%	16V	C266	1-126-193-11	ELECT	1uF	20%	50V
C157	1-163-227-11	CERAMIC CHIP	10PF	0. 5PF	50V	C267	1-124-779-00	ELECT CHIP	10uF	20%	16V
0101	1-124-779-00	ELECT CUID	10E	0.00	100	0071	1 104 770 00	CLECT OULD	10P	0.00	1 017
C161			10uF	20%	16V	C271	1-124-779-00		10uF	20%	16V
C162	1-163-235-11		22PF	5%	50V	C272	1-124-779-00		10uF	20%	16V
C163	1-124-779-00		10uF	20%	16V	C282	1-163-038-00		0. 1uF		25V
C164	1-124-779-00		10uF	20%	16V	C291	1-164-505-11		2. 2uF		16V
C165	1-163-235-11	CERAMIC CHIP	22PF	5%	50V	C292	1-164-505-11	CERAMIC CHIP	2. 2uF		16V
C171	1-124-779-00	ELECT CHIP	10uF	20%	16V	C293	1-164-505-11	CERAMIC CHIP	2. 2uF		16V
C172	1-163-235-11	CERAMIC CHIP	22PF	5%	50V	C294	1-124-779-00	ELECT CHIP	10uF	20%	16V
C173	1-124-779-00		10uF	20%	16V	C295	1-124-779-00		10uF	20%	16V
C174	1-124-779-00	ELECT CHIP	10uF	20%	16V	C296	1-124-779-00		10uF	20%	16V
C175	1-124-779-00		10uF	20%	16V	C297	1-124-779-00		10uF	20%	16V
04.50	4 400 007 44	OPDANIA OUTP	0000	Fo ₂	FOU	0000	4 400 000 00	OPPANIA SUIT	0.4.5		050
C176	1-163-235-11		22PF	5%	50V	C300	1-163-038-00		0. 1uF		25V
C177	1-124-779-00		10uF	20%	16V		1-124-779-00		10uF	20%	16V
C178	1-124-779-00		10uF	20%	16V	C302	1-124-779-00		10uF	20%	16V
C179	1-163-235-11		22PF	5%	50V	C303	1-124-779-00		10uF	20%	16V
C180	1-124-779-00	ELECT CHIP	10uF	20%	16V	C304	1-124-779-00	ELECT CHIP	10uF	20%	16V
C181	1-124-779-00	ELECT CHIP	10uF	20%	16V	C305	1-124-779-00	ELECT CHIP	10uF	20%	16V
C182	1-124-779-00		10uF	20%	16V	C306	1-124-779-00		10uF	20%	16V
C183	1-163-235-11		22PF	5%	50V	C307	1-164-232-11		0. 01uF	,	50V
C184	1-124-779-00		10uF	20%	16V	C308	1-164-232-11		0. 01uF		50V
0101	00	41111	2041	207	~~.	0000	104 II	-21440110 VIIII	5. 51di		

Ref. No.	Part No.	Description		Ren	nark	Ref. No.	Part No.	Description		Ren	nark
C309 C310	1-164-232-11 1-124-779-00	CERAMIC CHIP	0. 01uF 10uF	20%	50V 16V	C403	1-163-239-11	CERAMIC CHIP (AEP, UK)	33PF	5%	50V
C311	1-124-779-00		10uF	20%	16V	C403	1-163-243-11	CERAMIC CHIP	47PF	5%	50V
C312	1-124-779-00		10uF	20%	16V	0100	1 100 210 11	(US, Canadian)		0.0	001
C313	1-124-779-00		10uF	20%	16V	C404	1-163-038-00	CERAMIC CHIP	0. 1uF		25V
****	/					C405		CERAMIC CHIP	33PF	5%	50V
C314	1-124-779-00	ELECT CHIP	10uF	20%	16V			(AEP, UK)			
C315	1-124-779-00		10uF	20%	16V	C405	1-163-243-11	CERAMIC CHIP	47PF	5%	50V
C316		CERAMIC CHIP	0. 01uF		50V			(US, Canadian)			
C317	1-164-232-11	CERAMIC CHIP	0.01uF		50V						
C318	1-164-232-11	CERAMIC CHIP	0. 01uF		50V	C406	1-164-232-11	CERAMIC CHIP	0. 01uF		50V
						C407	1-164-005-11	CERAMIC CHIP	0. 47uF		25V
C319	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	C408	1-164-005-11	CERAMIC CHIP	0. 47uF		25V
C320	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	C409	1-164-005-11	CERAMIC CHIP	0. 47uF		25V
C321	1-163-038-00	CERAMIC CHIP	0. 1uF		.25V	C410	1-126-193-11	ELECT	1uF	20%	50V
C322	1-163-038-00	CERAMIC CHIP	0. 1uF		25V						
C323	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	C411	1-163-038-00	CERAMIC CHIP	0. 1uF		25V
						C412		CERAMIC CHIP	0. 1uF		25V
C324	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	C413		CERAMIC CHIP	27PF	5%	50V
C325	1-164-232-11		0. 01uF		50V	C414		CERAMIC CHIP	0. 1uF		25V
C326	1-164-232-11		0. 01uF		50V	C415	1-164-232-11		0. 01uF		50V
C327	1-164-005-11		0. 47uF		25V						
C328	1-164-005-11		0. 47uF		25V	C416	1-163-249-11	CERAMIC CHIP	82PF	5%	50V
*****	1 101 000 22	V2-12-0-1-0	0. 1			0110	1 100 210 11	(AEP. UK)	0211	0.0	001
C329	1-164-005-11	CERAMIC CHIP	0. 47uF		25V	C416	1-163-251-11	CERAMIC CHIP	100PF	5%	50V
C330		CERAMIC CHIP	0. 47uF		25V	0110	1 100 201 11	(US, Canadian)	10011	0.0	007
C331	1-124-779-00		10uF	20%	16V	C417	1-163-099-00	CERAMIC CHIP	18PF	5%	50V
C333		CERAMIC CHIP	0. 1uF	20,0	25V	0117	1 100 000 00	(AEP, UK)	1011	O.W	001
C334	1-164-232-11		0. 01uF		50V	C417	1-163-235-11	CERAMIC CHIP	22PF	5%	50V
			0, 010		.	V 12.	1 100 200 11	(US, Canadian)		0.0	•••
C335	1-124-360-00	ELECT	1000uF	20%	16V	C418	1-163-235-11	CERAMIC CHIP	22PF	5%	50V
C341	1-124-779-00		10uF	20%	16V	¥ 125	1 100 200 11	011111111111111111111111111111111111111		0.0	007
C343		CERAMIC CHIP	0. 1uF	20.0	25V	C419	1-163-125-00	CERAMIC CHIP	220PF	5%	50V
C344	1-164-232-11		0. 01uF		50V	C441		CERAMIC CHIP	0. 47uF	0.6	25V
C345	1-124-360-00		1000uF	20%	16V	C442		CERAMIC CHIP	0. 47uF		25V
			100001	20.0	1	C443		CERAMIC CHIP	0. 01uF		50V
C351	1-164-232-11	CERAMIC CHIP	0. 01uF		50V	C444		CERAMIC CHIP	0. 01uF		50V
C353		CERAMIC CHIP	0. 1uF		25V	V.,.	1 101 202 11	ODIUMITO VIII	0. 014.		•••
C354	1-164-232-11		0. 01uF		50V	C445	1-163-038-00	CERAMIC CHIP	0. 1uF		25V
C361	1-124-779-00		10uF	20%	16V	C446	1-124-779-00		10uF	20%	16V
C363		CERAMIC CHIP	0. 1uF	20.0	25V	C447	1-163-133-00		470PF	5%	50V
		021121120 01121	0, 20,			C448	1-163-989-11		0. 033uF	10%	25V
C364	1-164-232-11	CERAMIC CHIP	0. 01uF		50V	C449	1-163-038-00		0. 1uF	10%	25V
C365	1-124-360-00		1000uF	20%	16V	0110	1 100 000 00	ODIZZETO OTTI	o. Iui		201
C371	1-124-779-00		10uF	20%	16V	C450	1-163-263-11	CERAMIC CHIP	330PF	5%	50V
C373	1-163-038-00		0. 1uF	2070	25V	C451	1-163-251-11		100PF	5%	50V
C374	1-164-232-11		0. 01uF		50V	C453	1-126-206-11		100uF	20%	6. 3V
	1 101 202 11	onianico oniri	0.0141		001	C454	1-163-038-00		0. 1uF	20/0	25V
C375	1-124-360-00	ELECT	1000uF	20%	16V	C455	1-126-206-11		100uF	20%	6. 3V
C381	1-164-232-11		0. 01uF	20.0	50V	0.100	1 120 200 11	DDD01 01111	10001	20%	0. 0.
C383	1-163-038-00		0. 1uF		25V	C456	1-124-779-00	FLECT CHIP	10uF	20%	16V
C384		CERAMIC CHIP	0. 01uF		50V	C457	1-126-206-11		100uF	20%	6. 3V
C401	1-163-239-11		33PF	5%	50V	C458	1-163-038-00		0. 1uF	2010	25V
		(AEP, UK)	· · · ·	4.4		C459	1-163-141-00		0. 001uF	5%	50V
						C460	1-163-141-00		0. 001uF	5%	50V
C401	1-163-243-11	CERAMIC CHIP	47PF	5%	50V	V-100	2 100 111 00	-Digmit VIIII	21 201di	0.0	001
7	_ 100 210 11	(US, Canadian)	****	V.4	•••	C461	1-163-038-00	CERAMIC CHIP	0. 1uF		25V
C402	1-164-232-11		0. 01uF		50V	C462	1-163-141-00		0. 001uF	5%	50V
0.102	_ 101 202 11	- DIMENIO VIIII	o. 04ui		001	0402	7 100 141 00	ADIUMITA AIIII	5. 551ul	0.0	JU1

Ref. No.	Part No.	Description		Ren	nark	Ref. No.	Part No.	Description		Re	mark
C463	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	C523	 1-163-038-00	CERAMIC CHIP	0. 1uF		25V
C464		CERAMIC CHIP	0. 001uF	5%	50V	C531		CERAMIC CHIP	0. 1uF		25V
C465	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	C532		CERAMIC CHIP	2. 2uF		16V
C466	1-126-206-11		100uF	20%	6. 3V	C533		CERAMIC CHIP	0. 1uF		25V
C467	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	C534		CERAMIC CHIP	2. 2uF		16V
C468	1-126-204-11	FLECT CHIP	47uF	20%	16V	C535	1_163_038_00	CERAMIC CHIP	0. 1uF		25V
C469		CERAMIC CHIP	0. 1uF	20%	25V	C536		CERAMIC CHIP	0. 1ur 2. 2uF		25V 16V
C470		CERAMIC CHIP	0. 1uF		25V	C537		CERAMIC CHIP	2. zur 0. 1uF		25V
C471		CERAMIC CHIP	0. 1di 0. 01uF		50V	C538	1-163-038-00		0. 1uF		25V 25V
C472		CERAMIC CHIP	0. 47uF		25V	C539		CERAMIC CHIP	0. 1uF		25V
0470	1 100 100 11	CI COM	4 F	000	F017	05.40	1 104 505 44	APPANIA GUID	0.0.0		
C473	1-126-193-11		1uF	20%	50V	C540		CERAMIC CHIP	2. 2uF		16V
C474	1-126-194-21		1. 5uF	20%	50V	C541	1-163-038-00		0. 1uF		25V
C475		CERAMIC CHIP	0. 033uF	10%	25V	C551	1-164-232-11		0. 01uF		50V
C476	1-164-699-11	CERAMIC CHIP	0. 0033uF	5%	50V	C552		CERAMIC CHIP	0. 01uF		50V
C476	1-163-989-11	(AEP, UK) CERAMIC CHIP	0. 033uF	10%	25V	C553	1-164-232-11	CERAMIC CHIP	0. 01uF		50V
		(US, Canadian)		20.0		C554	1-163-038-00	CERAMIC CHIP	0. 1uF		25V
		(-2, -2, -2, -2, -2, -2, -2, -2, -2, -2,				C555	1-164-232-11		0. 01uF		50V
C477	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	C556	1-164-232-11		0. 01uF		50V
C478	1-126-206-11		100uF	20%	6. 3V	C557	1-163-038-00		0. 1uF		25V
C479	1-163-141-00		0. 001uF	5%	50V	C561	1-163-038-00		0. 1uF		
C480		CERAMIC CHIP	0. 1uF	J/0	25V	0301	1-103-030-00	CENAMIC CHIP	u. 1ur		25V
C481	1-126-194-21		1. 5uF	20%	50V	C562	1-163-038-00	CEDAMIC CUID	0. 1uF		25V
0401	1 120 134 21	ELECT	1. Jur	20/0	301	C563	1-163-038-00		0. 1ur 0. 1uF		
C482	1-124-779-00	FIECT CHID	10uF	20%	16V	C564					25V
C483		CERAMIC CHIP	0. 1uF	20.6	25V	C581	1-163-038-00		0. 1uF	200	25V
C484	1-163-037-11		0. 022uF	10%	25V 25V	C582	1-126-206-11		100uF	20%	6. 3V
C485	1-124-779-00		0. 022ar 10uF	20%	16V	0302	1-126-206-11	CLCCI CHIP	100uF	20%	6. 3V
0400	1 124 773 00	(AEP, UK)	1001	2070	101	C583	1-163-038-00	CEDAMIC CUID	0 1E		250
C485	1-126-193-11		1uF	20%	50V				0. 1uF		25V
0400	1 120-133-11	(US, Canadian)	Tur	20%	304	C584	1-163-038-00		0. 1uF		25V
		(US, CallauTall)				C601	1-164-232-11		0. 01uF		50V
C406	1-163-038-00	CEDAMIC CUID	0.1		957	C602	1-164-232-11		0. 01uF		50V
C486	1-163-038-00		0. 1uf	O OFFE	25V	C603	1-164-005-11	CERAMIC CHIP	0. 47uF		25V
			9PF	0. 25PF	ľ	0004	1 104 005 11	GEDINIO GUID	0 47 5		0011
	1-163-227-11		10PF	0. 5PF	50V	C604	1-164-005-11		0. 47uF		25V
C489	1-163-038-00		0. 1uF		25V	C605	1-163-038-00		0. 1uF		25V
C490	1-164-232-11		0. 01uF		50V	C606	1-163-038-00		0. 1uF		25V
		(US, Canadian)				C607	1-126-204-11		47uF	20%	16V
C491	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	C608	1-126-206-11	ELECT CHIP	100uF	20%	6. 3V
	1-126-204-11		47uF	20%	16V	C609	1-163-125-00	CERAMIC CHIP	220PF	5%	50V
	1-163-038-00		0. 1uF	_0.0	25V	C610	1-163-038-00		0. 1uF	0.0	25V
	1-163-038-00		0. 1uF		25V	C611	1-164-232-11		0. 01uF		50V
	1-164-232-11		0. 01uF		50V	C612	1-164-232-11		0. 01uF		50V
	1 101 202 11	(AEP, UK)	01 0141			C613	1-164-005-11		0. 47uF		25V
C499	1~163-237-11	CERAMIC CHID	27PF	5%	50V	C614	1-164-005-11	CEDAMIC CUID	0.47		950
	1-164-505-11		2. 2uF	3/6					0. 47uF		25V
C501	1-163-038-00		2. zur 0. 1uF		16V 25V	C615 C616	1-163-038-00		0. 1uF		25V
C502	1-163-038-00				1		1-163-038-00		0. 1uF	ን በው	25V
			0. 1uF		25V	C617	1-126-204-11		47uF	20%	16V
UJU4	1-163-038-00	OLDANIO UTIP	0. 1uF		25V	C618	1-126-206-11	EPECI CUIL	100uF	20%	6. 3V
	1-164-232-11		0. 01uF		50V	C619	1-163-125-00		220PF	5%	50V
	1-163-038-00		0. 1uF		25V	C620	1-163-038-00		0. 1uF		25V
	1-163-038-00		0. 1uF		25V	C621	1-124-779-00	ELECT CHIP	10uF	20%	16V
C522	1-163-038-00	CERAMIC CHIP	0. 1uF		25V						

6-2. FRONT MICROCOMPUTER HD643383F (AV-26P/26U BOARD IC801) PORT FUNCTION DESCRIPTION

Pin No.	Signal	9	Function	Pin No	Signal
1~3	PC0/AN8~ PC2/AN10		N. C.	45	P56/WKP6/ SEG7
4	PC3/AN11		LOW Batt. Detect IC input.	46	P57/WKP7/
വ	AVss	-	Connected to GND.	2	SEG8
9	TEST	-	Connected to GND.	47~52	P60/SEG9~P6
7	X2	0	NC. (Not used on sub clock)		Dec /CEC15 De
∞	X1	-	Connected to Vcc.	53, 54	F66/SEG15, FG SEG16
6	Vss	Ι	GND.		DZ0/CEC17~
10	OSC1	I	SYSTEM CLOCK (8MHz)	22~60	P75/SEG22
11	oscz	0	SYSTEM CLOCK (8MHz)		P76/SEG23 P7
12	RES	I	Reset IC input.	61, 62	SEG24
13	MDO	П	Connected to Vcc.	63	P80/SEG25
14	P20/IRQ4/	0	EDIT I/F CLOCK input.	64	P81/SEG26
15	P21/UD	0	POWER ON.	65, 66	P82/SEG27, P8 SEG28
-16	P22	0	N. C.	67	P84/SEG29
17	P23	0	EDIT RESET.	89	P85/SEG30
18	P24	0	N. C.	69	P86/SEG31
19	P25	0	GPI.	20	P87/SEG32
8	P26	0	CONTROLLER MICROCOMPUTER CS.	11~17	P90/SEG33~
21	P27	-	Power SW∼	1	P93/SEG36
22	P30/SCK1	0	CONTROLLER SCK.	75	P94/SEG37/M
23	P31/SI1	-	CONTROLLER SI.	92	P95/SEG38/DC
24	P32/S01	0	CONTROLLER SO.	7.7	P96/SEG39/CI
22	P33/SCK2	8	EDIT/OSD/EVR SCK.	78	P97/SEG40/CI
56	P34/SI2	-	EDIT/OSD/EVR SI.	79	Vcc
22	P35/S02	0	EDIT/OSD/EVR SO.	80	P10/TMOW
28	P36/STRB	0	IR CS∼.	81	P11/TMOFL
53	P37/CS	0	FD CS∼.	82	P12/TMOFH
30	Vss	I	GND.	83	P13/TMIG
$31 \sim 33$	V3~V1	Ι	N.C.	84	P14/PWM
34	Vcc	П	+5V POWER.	82	P15/IRQI/TM
33	PA3/COM4	0	DA CS∼.	98	P16/IRQ2/TM
98	PA2/COM3	0	SCI CS∼.	87	P17/IRQ3/TM
37	PA1/COM2	0	OSD CS∼.	88	P40/SCK3
88	PA0/COM1	0	EDIT CS∼.	88	P41/RXD
39	P50/WKP0/	0	MENU.	6.	P42/TXD
	PSI/WKPI/			5 8	P43/IRQ0
40	SEG2	0	INT/EXT.	26	AVCC PRO/ANO
41	P52/WKP2/ SEC3	0	EE/RECOUT.	94	PB1/AN1
42	P53/WKP3/	0	CINEMA ON	95~100	PB2/AN2~ PB7/AN7
	SEG4				
43	P54/WKP4/ SEG5	0	MONOTONE ON.		
44	P55/WKP5/ SEG6	0	FADER W/B.		

Pin No.	Signal	0/1	Function
45	P56/WKP6/ SEG7	0	MASK H SCROLL.
46	P57/WKP7/ SEG8	0	MASK V SCROLL.
47~52	P60/SEG9~P65/ SEG14	0	FADER LEVEL bit0~bit5.
53, 54	P66/SEG15, P67/ SEG16	0	N. C.
25~60	P70/SEG17~ P75/SEG22	0	ROM/RAM ADDRESS0~ADDRESS5.
61, 62	P76/SEG23, P77/ SEG24	0	N. C.
63	P80/SEG25	0	RAM CS∼.
64	P81/SEG26	0	ROM CS∼.
65, 66	P82/SEG27, P83/ SEG28	0	N. C.
29	P84/SEG29	0	Middle Strobe.
89	P85/SEG30	0	High Strobe.
69	P86/SEG31	0	OE.
20	P87/SEG32	0	WE.
71~74	P90/SEG33~ P93/SEG36	0/I	ROM/RAM DATA 0~DATA 3.
75	P94/SEG37/M	1/0	ROM/RAM DATA 4.
92	P95/SEG38/DO	1/0	ROM/RAM DATA 5.
77	P96/SEG39/CL2	2	ROM/RAM DATA 6.
78	P97/SEG40/CL1	8	ROM/RAM DATA 7.
79	Vcc	-	+5V POWER.
80	P10/TMOW	0	TITLE FADER LEVEL bit 0.
81	P11/TMOFL	0	TITLE FADER LEVEL bit 1.
83	P12/TMOFH	0	TITLE FADER LEVEL bit 2.
83	P13/TMIG	0	TITLE FADER LEVEL bit 3.
84	P14/PWM	0	TITLE FADER LEVEL bit 4.
82	P15/IRQ1/TMIB	-	TITLE FADER LEVEL bit 5.
88	P16/IRQ2/TMIC	-	OSD Vd IRQ2.
87	P17/IRQ3/TMIF	I	Vd IRQ3.
88	P40/SCK3	0/1	DTR EDIT I/F.
68	P41/RXD	I	RXD EDIT I/F.
96	P42/TXD	1/0	TXD EDIT I/F.
91	P43/IRQ0	I	DSR EDIT I/F.
92	AVcc	I	Connected to Vcc.
93	PB0/AN0	I	FD BUSY∼.
94	PB1/AN1	-	IR BUSY∼.
95~100	PB2/AN2~ PB7/AN7	-	N. C.

6-3. EDIT MICROCOMPUTER HD643383F (AV-26P/26U BOARD IC802) PORT FUNCTION DESCRIPTION

Pin No.	ğ	Signal	0/	Function	ā	Pin No.
1~3	3	PC0/AN8~ PC2/AN10	-	N. C.		21
4		PC3/AN11	I	N. C.	22	25~24
2		AVss	I	Connected to GND.	, i	55~57
9		TEST	I	Connected to GND.	5	5
7	7	X2	0	N. C. (Not used on sub clock)		88
80	~	X1	I	Connected to Vcc.	35	29~65
6	6	Vss	I	GND.		:
10	0	0SC1	I	SYSTEM CLOCK (8MHz)		2
=	1	osc ₂	0	SYSTEM CLOCK (8MHz)	9	64, 65
12	2	RES	ı	Reset IC input.		99
13	3	MDO	I	Connected to Vcc.		8
14	4	<u>P20/IRQ4/</u> ADTRG	0	N. C.	9	02~29
15	5	P21/UD	0	RESET OUT.	7	71~73
_	16	P22	0	EDIT I/F CLK.		74
17~21	22	P23~P27	0	N. C.	1.	75
2	22	P30/SCK1	0	N. C.	<u> </u>	2,4
Ž	23	P31/SI1	I	LANC R input.	<u> </u>	2 2
2	24	P32/S01	0	LANC R output.	<u> </u>	182
2	25	P33/SCK2	0/I	At IR communication: Hi-Z/LANC C CLK.		62
	92	P34/SI2	ı	IR/LANC P output.	<u>L</u> .	8
2	22	P35/S02	0	IR/LANC P input.		8
2	88	P36/STRB	0	N. C.		82
2	29	P37/CS	0	N. C.		83
3	30	Vss	I	GND.	<u>l</u>	25
31~	$31 \sim 33$	V3~V1	Ι	N. C.	<u> </u>	
3	34	Vcc	H	+5V POWER.		82
35	35~38	PA3/COM4∼ PA0/COM1	0	N. C.	lL.	98 6
	39	P50/WKP0/	0	LANC A CS.		5 æ
		P51/WKP1/		1:		æ
4	40	SEG2	0	LANC B CS.		8 8
4	41	P52/WKP2/ SEG3	0	N. C.	<u> </u>	1 26
4	42	P53/WKP3/ SEG4	0	IR CS.	66	93~95
4	43	P54/WKP4/ SEG5	0	LANC SEL A0.		96
4	44	P55/WKP5/ SEG6	0	LANC SEL A1.		86
4	45	P56/WKP6/ SEG7	0	LANC SEL B0.	55	99, 100
4	46	P57/WKP7/ SEG8	0	LANC SEL B1.		
47,	47, 48	P60/SEG9, P61/ SEG10	0	SELECT OUT ISO, ISI.		
49,	49, 50	P62/SEG11, P63/ SEG12	0	SELECT OUT PS0.		

52~54 Pe 55~57 P7 55~57 SF	P64/SEG13	0	VS. W
			SELECT OUT PS.
	P65/SEG14~ P67/SEG16	0	N. C.
	P70/SEG17, P72/ SEG19	0	LED OUT IN1~IN3.
	P73/SEG20	0	LED OUT REC.
59~62 P7	P74/SEG21~ P77/SEG24	0	N. C.
63 PE	P80/SEG25	0	S/V SEL OUT MAIN.
64, 65 SE	P81/SEG26, P82/ SEG27	0	S/V SEL OUT PRO1, PRO2.
99 PE	P83/SEG28	0	S/V SEL OUT REC MON.
$\frac{P8}{67\sim70}$	P84/SEG29~ P87/SEG32	0	N. C.
71~73 Pg	P90/SEG33~ P92/SEG35	I	S/V DET IN INI~IN3.
74 Pe	P93/SEG36	ı	S/V DET IN PRO IN.
75 P	P94/SEG37/M	I	S/V DET IN REC IN.
34 92	P95/SEG38/DO	I	N. C.
77 PS	P96/SEG39/CL2	I	N. C.
	P97/SEG40/CL1	ı	N.C.
79 V.	Vcc	I	+5V POWER.
80 P.	P10/TMOW	0	N. C.
81 P1	P11/TMOFL	0	N. C.
	P12/TMOFH	0	N. C.
┪	P13/TMIG	0	N.C.
84 P.	P14/PWM	0	N. C.
85 T	P15/ <u>IRQ1/</u> TMIB	I	LANC PB REQ.
86 P.	P16/IRQ2/TMIC	I	LANC PA REQ.
	P17/IRQ3/TMIF	0	N. C.
	P40/SCK3	1/0	F/E communication CLK/Hi-Z (at Non communication).
	P41/RXD	-	F/E communication input.
	P42/TXD	0/1	F/E communication output/Hi-Z (at Non communication).
	P43/IRQ0	I	F/E communication CS.
92 A	AVcc	I	Connected to Vcc.
93~95 PI	PB0/AN0~ PB2/AN2	I	MONITOR KEY INI~IN3.
96 PJ	PB3/AN3	I	MONITOR KEY REC.
97 P	PB4/AN4	ı	1/S.
98 PJ	PB5/AN5	I	PLG.
99, 100 P	PB6/AN6, PB7/ AN7	1	.c.

(CM-42 BOARD IC014), KEYBOARD MICROCOMPUTER MB89131 (KM-13 BOARD IC805) PORT FUNCTION DESCRIPTION LANC MICROCOMPUTER MB89131 (AV-26P/26U BOARD IC803, IC804), CONTROLLER MICROCOMPUTER MB89131 64.

Note) This microcomputer operates in three modes for voltage setting of pin 18 and 20.

- ① LANC microcomputer in operation: pin 18 to be driven "L", pin 20 to be driven "L".
- © Controller microcomputer in operation: pin 18 to be driven "L", pin 20 to shuttle input. ③ Keyboard microcomputer in operation: pin 18 to be driven "L", pin 20 to be driven "H".

	Coor or mines							_
2	i di		LANC Microcomputer in Operates		Controller Microcomputer in Operates		Keyboard Microcomputer in Operates	
<u> </u>	2000 2000	0/1	Function	0/1	Function	9	Function	
-	A Vcc	1	ADC Power.	-	ADC Power.	_	ADC Power.	
2	RESET	-	Reset input.	ı	Reset input.	I	Reset input.	
3, 4	MODE0, MODE1	-	Mode input, Fixed to "L".	I	Mode input, Fixed to "L".	1	Mode input, Fixed to "L".	
5	0X	-	4MHz clock input.	Г	4.19MHz ceramic vibrator.	I	4.19MHz ceramic vibrator.	
9	X1	0	Not used.	0	4.19MHz ceramic vibrator.	0	4.19MHz ceramic vibrator.	
7	Vcc	1	+5V Power.	ı	+5V Power.	1	+5V Power.	
iœ	X0A	-	Connected to GND.	I	32768Hz crystal oscillator.	I	Connected to GND.	
6	X1A	0	Not used.	0	32768Hz crystal oscillator.	0	Not used.	
10—17	P27—P20	0	Not used.	0	Key matrix select.	0	Key matrix select.	
188	P17	П	Function select, Fixed to "L".	I	Function select, Fixed to "H".	I	Function select, Fixed to "L".	
19	Vss		GND.	Ī	GND.	-	GND.	
20	P16	I	P16 Function select, Fixed to "L".	1	Shuttle input.	1	P16 function select, Fixed to "H".	_
21-24	P15-P12	0	Not used.	1	Shuttle input.	0	P15-P12 key matrix select.	
22	P11	0	Not used.	0	LED latch.	0	Key matrix select.	_
56	P10	0	Not used.	0	LED serial SCK.	0	Key matrix select.	
27	P07	0	Not used.	0	LED serial SO.	I	Key matrix read.	
28	P06	0	Not used.	0	Not used.	I	Key matrix read.	
29, 30	P05, P04	0	Not used.	Ι	Key matrix read.	I	Key matrix read.	
31, 32	P03, P02	0	Not used.	1	Key matrix read.	I	Key matrix read.	
33	P01	0	-	Ι	Key matrix read.	I	Key matrix read.	
34	P00	0	LANC communication output.	1	Key matrix read.	I	Key matrix read.	
35	P37/BZ	0	Not used.	0	Buzzer.	0	"L" for data through.	
36	P36/INT2	П	LANC communication input.	I	Not used.	0	Not used.	
37	P35/INT1	-	CS.	I	CS.	I	CS.	
88	P34/INT0	I	Not used.	Ι	JOG_B.	0	Not used.	
39	P33/EC/SC0	-	Not used.	Ι	IOG_A.	0	Not used.	_
40	P32/SI	ı	IS	I	SI.	1	SI.	_
41	P31/S0	0	SO.	0	.08	0	so.	_
42	P30/SCK	-	SCK.	1	SCK.	I	SCK.	
43	A Vss	1	GND.	1	GND.	1	GND.	_
44	AVR	1	GND.	1	ADC Power.	Ι	ADC Power.	
45	AN3/P43	0	Not used.	ı	Video fader	0	Not used.	_
46	AN2/P42	0		I	Audio fader	0	Not used.	
47	AN1/P41	0	Not used.	I	Audio mixing	0	Not used.	
48	AN0/P40	0	Not used.	1	Mic volume	0	Not used.	

1-1-4. Input/Output Levels and Impedance Input jacks

Video

5 lines (PLAYER INPUT 1/2/3/RECORDER

IN/PROCESSOR IN)

S-VIDEO IN: 4-pin mini DIN (5)

Luminance 1 Vp-p, 75 ohms, unbalanced,

sync negative

Chrominance 286mVp-p, 75 ohms,

unbalanced

VIDEO IN: phono jack (5)

1 Vp-p, 75 ohms, unbalanced, sync negative

Audio

6 lines (PLAYER INPUT 1/2/3/AUX AUDIO

INPUT RECORDER IN/PROCESSOR IN)

Phono jack

-7.5 dBs, impedance 47k ohms or more

Microphone Minijack (front 1)

-60 dBs, 3k ohms or more

Output jacks

Video

4 lines (RECORDER OUT/MONITOR OUT/

PROCESSOR OUT1/2)

S-VIDEO OUT: 4-pin mini DIN (4)

Luninance 1 Vp-p, 75 ohms, unbalanced, sync

negative

VIDEO OUT: Phono jack (4)

 $1\ \mathrm{Vp\text{-}p},\,75\ \mathrm{ohms},\,\mathrm{unbalanced},\,\mathrm{sync}$ negative

Audio

4 lines (RECORDER OUT/MONITOR OUT/

PROCESSOR OUT1/2)

Phono jack, -7.5 dBs, impedance 470 ohms or

less

LANC Stereo mini-minijack (rear 3, front 1)

CTRL S Minijack (1)

GPI

Minijack (1)

EDIT I/F 8-pin mini DIN (1)

IR REPEATER

Stereo mini-minijack (1)

Headphones

Stereo mini-minijack (1)

12 mW (47 ohms), appropriate impedance

8 ohms or more

1-2. POWER SUPPLY CHECK

1-2-1. Output Voltage Check (PW-106P/106U Board)

Mode	E-E
Measurement instrument	Digital voltmeter
+13V check	
Measurement point	CN105 pin ① or ②
Specified value	13.0±0.5V
+6V check	
Measurement point	CN105 pin ® or ⑦
Specified value	$6.0\pm0.5\mathrm{V}$

[Check Method]

 Each of these supply voltages must meet its specified value.

1-3. VIDEO SYSTEM ADJUSTMENTS

Color video signal supplied from a pattern generator is used as a video input signal for Video System Alignment. This signal should be checked to ensure that it meets the specifications provided is Fig. 7-1-2 and "INPUT SIGNAL CHECK". The adjustments in Video System Alignment should be performed in the following sequence.

[Adjustment sequence]

- 1. Y Level Adjustment
- 2. Chroma Level Adjustment
- 3. White Fade Level Adjustment

1-3-1. Y Level Adjustment (AV-26P/26U Board) [Adjustment Object]

Set the Y level of video signal. If deviated, the picture image becomes brighter or darker. Extreme deviation causes distorted image.

Mode	E-E
Signal	Color bar
Measurement point	Recorder output video terminal
Measuring instrument	Oscilloscope
Adjustment element	RV451
Specified value	$1.00 \pm 0.05 \text{Vp-p}$

[Adjustment Method]

- 1) Input color bar signal to PLAYER INPUT 1.
- 2) Select PLAYER 1.
- 3) Adjust RV451 so that the level difference between sync chip and white peak is 1.00 ± 0.05 Vp-p.




Fig. 7-1-3. (A) (NTSC: US, Canadian Model)




Fig. 7-1-3. (B) (PAL: AEP, UK Model)

1-3-2. Chroma Level Adjustment (AV-26U board) (NTSC: US, Canadian Model only) [Adjustment Object]

Set the chroma level of video signal. If deviated, the picture color becomes darker or thinner.

Mode	E-E
Signal	Color bar
Measurement point	Recorder output video terminal
Measuring instrument	Oscilloscope
Adjustment element	RV471
Specified value	286±10mVp-p

[Adjustment Method]

- 1) Input color bar signal to PLAYER INPUT 1.
- Select PLAYER 1.
- 3) Adjust RV471 so that the burst level is $286 \pm 10 \text{mVp-p}$.




Fig. 7-1-4.

1-3-3. White Fade Level Adjustment (AV-26P/26U Board)

[Adjustment Object]

Set the brightness of the picture image in white fader mode. If deviated, the white fader is excessively bright or dark.

Mode	E-E
Signal	Color bar
Measurement point	Recorder output video terminal
Measuring instrument	Oscilloscope
Adjustment element	RV501
Specified value	0.63±0.02Vp-p

[Adjustment Method]

- 1) Input color bar signal to PLAYER INPUT 1.
- 2) Select PLAYER 1.
- 3) Select picture fader WHITE. Place the fader lever in the bottom.
- 4) Adjust RV501 so that the level difference between pedestal level and white level is 0.63 ± 0.02 Vp-p.




Fig. 7-1-5.

1-4. DISPLAY SYSTEM ADJUSTMENTS

Color vdieo signal supplied from a pattern generator is used as a video input signal for Video System Alignment. This signal should be checked to ensure that it meets the specifications provided in Fig. 7-1-2 and "INPUT SIGNAL CHECK". The adjustments in Video System Alignment should be performed in the following sequence.

[Adjustment sequence]

- 1) OSD Hue Adjustment
- 2) Internal Sub-Carrier Frequency Check
- 3) OSD AFC Voltage Check

1-4-1. OSD Hue Adjustment (AV-26P/26U Board) [Adjustment Object]

Set the hue when the menu is displayed on the screen. If deviated, the hue is not appropriate.

Mode	E-E
Signal	Color bar
Measurement point	Monitor output video terminal
Measuring instrument	Vector scope
Adjustment element	RV701
Specified value	Adjust so that the two bright points of cyan on the scope are aligned with each other.

[Adjustment Method]


- 1) Input color bar signal to PLAYER INPUT 1.
- 2) Select PLAYER 1.
- 3) Press MENU key to display the menu on the screen.
- Connect a vector scope to MONITOR OUT.
 Use RV701 to adjust the angle between blue and cyan of the menu screen.

Connecting the Recorder

Connection 2

Connect as illustrated below when the recorder is a Sony and has the CONTROL S connector only. After connecting, set the recorder control system (p.16)

When the recorder has no S video jack, connect to the VIDEO jack.




Connection 3

Connect as illustrated below when the recorder can be controlled with an infrared remote commander only.

The IR repeater connected to the main unit transmits the infrared signal to the recorder and players. Attach the IR repeater close to the remote sensor of the recorder.


After connecting, set the recorder control system (p.16).

When the recorder has no S video jack, connect to the VIDEO jack.




Setting the Recorder Control System

According to the connection of the recorder, set the recorder control system so that you can control the recorder using the control unit.



Switching the Menu Language You can choose the English menu, the German menu or the French menu. The factory setting is English.




Selecting the Recorder Control System

Select the recorder control system according to the convection. The factory setting is LANC @. This setting is not necessary for Connection [].

Preparations

Turn on the TV or monitor, and set the input selector to external input.



17


Setting the Recorder Control System

Setting the VTR Mode

When you have connected the recorder using Connection $[\underline{\bf 2}]$ you must set the VTR mode. The factory setting is the VTR 2 (8 mm).

On the VTR mode

Type of remote control signal. To avoid mis-operation by remote control signal among Sony video equipment, there are three different command modes, VTR, 1, VTR, 2, and VTR, 3. Other manufacturers also have their own command modes.



Setting the Manufacturer and Command Mode of the Recorder

the recorder. This unit has the command modes of other manufacturers preset. Select the appropriate command mode in the menu system. If you cannot find the command mode for your recorder, store the control signal as described When you have connected the recorder using Connection 3, you must set the manufacturer and command mode of on page 20.

The factory setting is Sony VTR 2.

Notes

- You cannot use the jog-shuttle dial with a remote controller other than Sony's.
 Some buttons may not operate with some manufacturers
 - recorders.

SONY (VTR. 1) MITSUBESHI (1) SONY (VTR. 2) MITSUBESHI (1) PANASONIC (1) PANASONIC (1) PANASONIC (10.5 VSTEM) SHARP (2) SHARP (2) SHARP (2) SHARP (2) SHARP (2) SHARP (2) PANYO (2) NEC (1) NEC (1) Preset manufacturers (command mode)

CONT. CONTROL OF THE CONTRO INTRACED SET UP: SELECT SO SOCK RECORDER RENOTS CONTROL
RESIGNATION STREETS OF
CONTROL STREETS OF
MANAGEMENT STREETS OF
SURFICE RENOTS CONTROL
SURFICE RECORDER
SURFICE ROOM
SURFICE INFRANCE SET UP: MANUFACTURER(1) STATES SO MC (E) F D SELECTE SELECT The menu of the selected item appears. Press +, + to select the item for selecting the command mode of the recorder, and press YES. for registering the recorder control system, and press Press ↑, ↓ to select the item The command mode list appears. The main menu appears. Press MENU. 2

command mode of the recorder by pressing 4, 4. If you are not sure which is the correct Move the • mark to the one, select one of them and try operating the recorder. 4

NAME OF THE PARTY OF THE PARTY

The menu disappears. Press MENU. n

After the setting, confirm that the recorder operates correctly.

Setting the Recorder Control System

Storing the Function of the Remote Commander

If you cannot find the command mode of the recorder on the preset command mode list (p.19), store the control signal in this unit so that you can control the recorder using the

control unit. However, in this case you cannot use the jog-shuttle dial.

Setting the Shuttle Mode

slow playback in reverse).
When you have connected the recorder using Connection (I his unit learns the shuttle mode of the recorder automatically.

When you have connected the recorder using Connection [2] or Connection [3] and you use a Sony remote commander, you must set the shuttle mode according to the

The factory setting is A mode (for a recorder that cannot do

Press MENU.

NECONDER NESOTE CONTROL.

CHARLES OF ST UP
LEADETH MODE
SENT UP
SENT U

(E)

SELECT SO SACK

-i-

SELECT EXECUTE

recorder, and press YES.

The menu of the selected item appears.

Press +, + to select the item

The main menu appears.

Press MENU.

for registering the remote control system of the

The main menu appears.

The menu of the selected item appears. Press ↑, ↓ to select the item for registering the remote control system of the recorder, and press YES.

NECONDER PEROTE CONTROL
SET UP
SENSE PROSE PROSE
SET UP
SENSE PROSE
SET UP
SENSE PROSE
SENTING SET UP
SENTING S

(E) T D

ES SELECT | CO SACK

PECCEDER NEWGYE CONTROL SET TO RESIDENCE CONTROL SYSTEM CONTROL S VTR MODE LEFENDE DESTRUCTURE DESTRUCTURE CONTROL for seting the shuttle mode, and press YES.
The menu to select the shuttle mode Press +, + to select the item

3

CPERATION 1 PUBBLISH RESOUR 2 PUBBLISH RESOUR 2 SCHOOLER STATE STATE SO SACK SO SACK

FINISHED LEADNING TO STORE, PRESS IES. IF YOU DO NOT STORE, DATA WILL ME LOST.

슡

LEANITHG RESOTE CONTROL STOP PLAY

As indicated on the screen,

4

press the button of the

recorder's remote

commander.

STORE E GUIT

remote sensor of the main unit. Place the remote commander horizontally, 3 to 5 cm (1 ²/₂ to 2 inches) away from

"FINISHED" message appears.
Aim the remote commander at the

Continue the operation until the

message appears, press YES. The control signal is stored.

When the "FINISHED"

the remote sensor.

LEADUTING MENOTE CONTROL

LEADNING RESOTE CONTROL STOP PLAY PAGE MENT PAGE

分

ALCOHOLA REMOTE CONTROL.
SET UP
CONTROL S YER MONE
INTERNAL SET UP
SET U

Press +, + to select the item for storing the control signal that is not preset, and press

M

SECURET SO SACK

The menu of the selected item appears.

A (BACKINA SACA B (BACKINA SACA PLAYBACK) C (RI - SPRED CUL/MEV) PLEASE USE MODE A.
IF SHUTTLE DATS NOT
MORE PROPERLY.
SET UP

B) 00 BACK

E) 00 PACK SELECT SO PACE

iii ooit

Move the ● mark to the appropriate shuttle mode by pressing ↑, ↓. A (FORWARD SLOW PLAYBACK ONLY):

When an infrared remote commander is not supplied with the recorder, nor sold separately,

When an infrared remote commander is supplied with the recorder, or sold separately B (BACKWARD SLOW PLAYBACK):

C (HI-SPEED CUE/REV):

Besides the conditions of the B mode, the recorder can do fast-forward/reverse playback at high speed

The menu disappears. Press MENU. S

The menu disappears.

Press MENU.

L

Notes on storing the control signal


- Do not move the main unit or remote commander:
 If you are instructed to press a burior that is not on the remote commander, press the 4 button and go to the next step. Or, press any other button. (The function of the button will be acreed.)
 You cannot operate the player and recorder using the control unit while storing the control unit.
- If you turn off the power of the main unit or control unit, the connents stored until then are reaced. Make sure that you do not turn off the power until the "FINISHED" message appears.

 This unit cannot store the control signal of an ultrasonic remote commander or special remote commander or special remote commander.

 This unit may not be able to store every key function of some manufacturers.

Setting the Recorder Control System

Setting the Pause Mode Release Button
When you have connected the recorder using Connection [2] and [3], you must set which button to release recording pause
mode on the recorder. The factory setting is the pause button.




Connecting Other Equipment

You can connect a digital SEG, audio equipment and microphone to the main unit.

Connecting the Digital SEG

Connect a Digital SEG to the PROCESSOR IN/OLT jacks of the main unit. If the Digital SEG has a GPI jack or EDIT 1/F jack, you can transmit the GPI signal or EDIT 1/F signal

from this unit to the Digital SEG and mix images or generate effects (p. 58).



- When the Digital SEG has no S video jack, connect to the

 - You can connect the player directly to the digital SEG.

Connecting Other Equipment

Connecting the Audio Equipment and Microphone

Connect the audio equipment to the AUX AUDIO INPUT jacks of the main unit. Connect the microphone to the MIC jack on the front of the main unit. You can mix the audio

signal of the picture and that of the audio equipment (p.44). Also, you can insert narration.

Program Editing

Editing means to make a new tape from a prerecorded tape by deleting unnecessary scenes and allocating the scenes you want in the desired order.

Words Used in Editing

Ü

The each scene to be allocated for editing
The start point of a cut
The end point of a cut
Agroup of cut of desired length and
allocation IN point OUT point Program

Program editing

The automatic editing function of this unit
performed by pressing the EDII START
putton after making the program.

Time code (RC time code)

This is the function to record the frame-by-

frame position of the tape as a serial number of hour, minute, second, frame. As the picture and counter reading are identical, you can locate a scene precisely by the counter.

Program Edit œ ş Program ž ŧ + Ê ≆ | |• |• Player 2 Player 1

wolf lengis : ---900 000 9 A CD player, etc. to AUX AUDIO INPUT to audio output Audio cable Main unit (front) 0 Main unit (rear) 0 0 •


You cannot use a microphone that is exclusive "plug-in-power" type. Note

Procedure of the Program Editing

Turn the power on (p. 27).
Set the IN points and OUT points of the cuts (p. 28).
3 Preview the program (p. 31).
Execute the program editing (p. 32).

On-screen display while designating the cuts

The entry mode display appears



On the entry mode display:

Pressing 4, 4 changes the cut numbers. Pressing 4, 4 changes the display position.

How may cuts can be designated for a

If you edit using the RC time toder, you can designate up to 99 cuts in a program. If you do not use the RC time code, when you designate more than 20 cuts per player, the editing accuracy will deteriorate. When you edit more than

- 20 cuts, do the following.

 20 cuts, do the following.

 Before you designate the cuts, rewind the tape to the
 beginning and reset the counter to zero.

 Execute the program editing so that the number of cuts
 does not exceed 20 per player.

 Before executing each program editing mentioned above,
 rewind the tape to the beginning and reset the counter to
- Rewritable Consumer time code

Notes on time code

- The RC time code is not compatible with the time code of
- recorded in series, the program editing may stop on the way. In such a case, record the RC time code from the beginning to the erd of the tape again. (The previous time code or data code will be erased.) products for institutional use.

 • When editing using the RC time code must be recorded from the beginning to the end of the tape in series to edit correctly. If the RC time code is not

To adjust the lag between the program and edited tape caused by the start time of the recorder or recording pause mode, see "Adjusting the Jiming - To Edit Scenes Precisely" on page 45.

Preparations for the Program Editing

Before you start the editing operation, get the player and recorder ready. Refer to the operating instructions of the player and recorder.

Preparations Player


- Insert the tape you want to edit.
 If the player has an input/output selector for the video/audio jack, set it to "output".
- If the player has an edit switch, set it to "on". Picture deterioration will be minimized.
- If the player has an infrared remote commander, set it so that the player is not operated by the remote commander. If you use the RC time code, set the counter mode to time
- If the player has a LANC M/S switch or that in menu, set

Preparations Recorder

- Insert a tape that can be recorded. (Check the position of the safety tab to prevent recording.)
- Set the input selector to external input.
 Set the recording time, volume and so on. (Refer to the operating insurations of the recorder.)
 In case of LANC control and if the recorder has a LANC M/S switch or that in menu, set to "5".


With some recorders, the beginning and end of the recorded picture may become hard to see. To avoid such cases, we recommend inserting video-muted cuts (p. 41) at the beginning and end of a program.


Turning the Power On Procedure 1



Procedure 2 Setting the IN and OUT Points

You can edit by connecting up to 3 players. To designate cuts, first select the player of the desired tape and then designate the cuts.





Make sure that you reset the tape counter to 0:00:00 (0000 for the 4-digit counter) at the beginning of tape.

Press COUNTER RESET.
If you use the RC time code, however, the COUNTER RESET button does not function.


(1 count). If the cut is displayed in white in the edit list, the unit will not edit the cut. If the cut is displayed in red, this unit will edit the cut. However, as the cut is not long errough, the cut may be recorded incorrectly. A cut longer than 2 seconds (2 count) is displayed in blue.

Make a cut longer than 2 seconds (2 counts). The unit carnot execute editing a cut shorter than 1 second

The counter reading you can designate for cuts ranges from +8:59:59 to +8:59:59.


i'ou cannot designate the counter readings out of this range.

Operating the Jog/Shuttle Dial
You can use the lape transport buttons or jog/shuttle dial to
transport the lape of the player that you have selected with
the PLAYER or RECORDER buttons.



Continued to the next page

Tape transport buttons




On the jog/shuttle dial

The jog/shuttle dial functions differently depending upon the recorder. If you control a recorder other than LANC, set the shuttle mode (p. 21).

- Shuttle ring leib got —





The jog/shuttle dial functions as follows when used in infrared remote control mode.

Shuttle mode	Shuttle ring	Jog dial
	Playback pause	
(FORWARD SLOW PLAYBACK ONLY)	Reverse playback (Review)	You cannot use the jog dial.
	Playback pause	
B (BACKWARD SLOW PLAYBACK)	1/5-speed reverse playback Reverse playback X2-speed reverse playback X2-speed reverse playback Reverse playback (Review) Fast-forward playback (Cue)	To reverse Ten To forward
C (HI-SPEED CUEREV)	1/5-speed reverse playback Reverse playback Reverse playback X2-speed reverse playback X2-speed fleviewol High speed fleviewol High speed flevieword playback	To reverse

When you cannot set the recorder to playback pause mode with the jog/shuttle dial, use the II button.

Notes

- The jog/shuttle dial may operate incorrectly in the following cases.

 You harved the jog/shuttle dial too quickly.

 The recorder is connected using Connection 2 or 3 (p. 14, 15).


 The player or recorder is slow to react to signals from the remote control unit.

You do not need to keep pressing the button of the recorder's remote commander to do the picture search (Fixed picture search function).
 You turned the shuttle ring immediately after turning on the power. In this case, transport the age using tape transport buttons once. The jeg-shuttle dial will operate normally afterward.

Procedure 3 Previewing the Program


After you have designated the cuts, preview the program to check that the cuts are the correct ones.

Previewing the Program




To check the total time, see page 37.

Previewing One cut



Executing the Program Editing Procedre 4

This unit automatically edits and records the cuts you have designated for the program.



When Program Editing is Finished The player enters playback pause mode and the recorder

enters recording pause mode. You can select stop mode for the recorder (p. 52).

To Stop Program Editing

Press CANCEL. The player and recorder stop.

To Save the Programs

You can save the program data in a Sony 3.5-inch floppy disk (2HD and 2DD) (p. 56).

Press POWER again. The lamp of POWER button goes off. The STANDBY lamp of the main unit lights. When You Finished Editing

If You Will Not Use the Unit for

Unplug the power cord. The STANDBY lamp goes off. Long Time

To minimize the lag between the program and the edited tape

It is inevitable that a lag occurs between the program and the edited tape. There are three causes. One of them is that the IN and OUT points are designated by the counter


reading. There is lag between the counter reading and the actual frame. Against two other causes, we recommend the following method to minimize the lag.

Cause	Countermeasures
There is a lag at the start time or at the recording pause of the	Perform the timing adjustment (p. 45).
recorder.	
The IN and OUT points are set by the counter reading, and there is a Locate the IN and OUT points in fast-forward playback or reverse	Locate the IN and OUT points in fast-forward playback or reverse
lag between the playback picture and the counter reading of the	playback, without using the stop button. Use the fast-forward
plaver."	playback or reverse playback for executing program edit as well (p.

This lag does not occur when you edit using the RC time code on a player and recorder that are compatible with the RC time code.

When You are Not Editing

Even if you do not use the unit for editing, you can keep the player and recorder connected to the main unit and use this unit as the input signal selector.




When you select RECORDER

The signal (audio and video) of the player of lighting button (PLAYER 1/23) is output from the RECORDER OUT jack. The signal of the recorder (RECORDER) is output from the MONITOR OUT jack.

Revising the Program

You can change the IN and OUT points of the designated cuts or change the order of cuts. In addition, you can copy or delete cuts.

Changing the IN and OUT Points



You can change the IN and OUT points on the cut data display.

Select the cut you want to revise on the cut data display and locate the new IN and OUT points, or directly input the counter reading (p. 35).

Note

If the cut you selected is in a different player from the player currently selected, the IN and OLD points are shown as white in black. In this situation, you cannot change the IN and OLJ points. Select the player of the cut you want to revise.

Adjusting the IN and OUT points

You can change the counter reading of the IN and OLT points on the cut data display to adjust by a few frames. In this case, the playback picture does not appear.

676 04 PLATES 1 OF THE PROPERTY OF THE PROPERT Press 1, 4 on the entry mode display until the cut number you want to revise appears (example: cut no. 4).

The current scene of the player containing the cut appears on the screen. Ξ Change the counter reading by pressing f_{\star} \downarrow .

Pressing f_{\star} \downarrow changes the frame digits. The second and minute digits will increase or descrease accordingly. If the counter does not display frame digits, pressing f_{\star} , \downarrow changes the second digits. In case of a 4-digit counter, the last digit changes. 0 0 0 0 ${f 5}$ To reset other items, press ϵ and repeat steps 3 and 4. E) Ð € The entry mode display appears again. The playback picture disappears and the cut data display appears. change, and press → until its Press 1, ↓ to select the item [a] Items to be able to set on the cut [b] Counter readings (IN or OUT) you want to counter reading flashes. Press CUT DATA. Press CUT DATA. 9 2 3

On the cut data display


Pressing ♦, ♦ moves the cursor to an item.
Pressing ♦ makes the counter of the selected item flash so that you can write figures.
Pressing ♦ stops the counter flashing, and you can select an item.

When the cursor is at a cui number: Pressing ₱ displays the cut data of the previous cut. Pressing ₱ displays the cut data of the next cut.

Revising the Program

Naming the cut

You can name each cut using up to 12 letters, numbers, and symbols.



You can write characters using the control unit

In step 4, press ↑ + until the desired character appears.

Then press → to go to next character position. You can write characters by repeating this operation.


To insert a space, press 4.

Pressing YES switches to the upper case, lower case, and symbol / figure in turn.

Moving/Copying/Deleting the Cut

You can move, copy and delete the cuts on the edit list.

Using the Edit List



On the edit list

Pressing ♠, ♦ moves the cursor up and down so that you can select a cut.

Pressing ♠, ♦ switches the cut list.

After you have selected a cut:
To locate the IN point scene, press GO TO.
To enter the entry mode, press EDIT LIST.
To display the cut data, press CUT DATA.

To return to the entry mode display, press EDIT LIST.

Checking the Total Time of the


ProgramThe total time of selected cuts is displayed at the bottom of the lap time list (TOTAL LAP).

To Exclude a Cut While Program Editing is Executed


Select the cut and press NO to turn off the Thark.

To include the cut, press VES to turn on the Thark.

Moving the Cut




Deleting the Cut



Clearing the Program Data from the Unit

The unit keeps the newest one of the program data in memory. You can clear the program data from the unit to restart making program from the beginning.



MANE Cut 1 Air port1 Air port2 Air port2 Air port2 Mort2 Mort2 Mort2 Set 1 Set 1

\$**}**€

To insert the same cut at another position, first copy the cut and then move the copy of the cut to the desired position.

Ē,

•

Press ¢, ↓ on the edit list to select

Copying the Cut

press COPY.
The copy of the cut is placed just after the the cut you want to copy, and

original cut.


38

Advanced Operations Generating the Special Effects


You can make your edited tape more impressive by generating special effects in the video and audio.

Monotone Black and white picture (p. 41)


... Cuts off the top and bottom of the picture so that the picture looks wide just like a film (p.41). Cinema



.... Makes the video and/or audio appear or disappear gradually (p. 41, 43). Fade



.... Turns off the video and/or audio (p. 41). Aute ...



Mixing Mixes in external audio during editing (p. 44).


Monotone, Cinema, Fade, Mute, Synchronized Playback

Set the special effect on the cut data display. You can change the setting afterwards.

Cut Data

You can check or change the contents of the cut on the cut data display.

To locate the IN point, OUT point, SYNC PB point, EDIT 1/F point, or GPI point from the cut data display, press GO TO after selecting each point on the cut data.



Continued to the next page


To check the monotone and cinema effects

Before you generate the effects, make a test to see how the The picture takes on the effect.
You can generate both effects for one cut.
After you have checked, press the button to turn off the effect. picture will look with the effects.

Press the button of desired effect.


Monotone effect....... Press MONOTONE.

Cincma effect Press CINEMA.



Generating the Special Effects

Setting the Effects




Note on the Synchronized Playback

You can enjoy the A/B roll edit using the Digital SEG (not supplied). The Digital SEG equipment mixes the images by overlapping them. To make the A/B roll edit, connect the Digital SEG to the PROCESSOR IN/OUT jacks and press PROCESSOR ON/OFF to turn on. See page 56 for details.

Fading In/Out Manually

You cannot adjust the fading speed when you set fading on the cut data display. When you want to fade in or out matching the speed to the cut, edit (record) the cut manually and move the FADER lever.



Fading In

Recorder: Locate the point to start recording and set to recording pause mode.

Player: Start playback from a few seconds before the IN point.

Position the FADER lever to MIN.
VideoVIDEO FADER lever
AudioAUDIO FADER lever

Recorder: Start recording.

Move the FADER lever towa

Move the FADER lever towards MAX as fast as you want.
The video/audio appears by fading in.

Fading Out

While recording, move the FADER lever towards MIN as fast as you want.

4 Stop recording and playback.

Generating the Special Effects


Audio Mixing

While performing the program editing, you can insert narration or mix in sound from connected audio equipment.

Mixing from Microphone

Use a microphone connected to the MIC jack on the front of

the main unit to insert narration.




Mixing in the Sound of Audio Equipment

You can mix in the sound of audio equipment such as a CD player connected to the AUDIO INPUT jacks on the rear of the main unit.

Adjust the balance of the picture sound and the audio source with the AUDIO MIX lever. To turn up volume of picture sound


To turn up volume of audio source



Adjusting the Timing — To Edit Scenes Precisely

When you play back the tape that you edited using the program editing, the IN point and/or the OUT point may not be the scene you had designated. Some scenes may not appear, or some unnecessary scenes may be included. There are several possible causes for such discrepancies: some recorders are late to start recording, or some recorders

rewind the tape at the end of recording. Timing adjustment is the operation to compensate for the lag caused by the above characteristics of the recorder so that the cuts are more accurately recorded from the IN point to the OUT point as you designated.



Why the beginning of a cut is lost

the recording pause mode at the IN point. Some recorders, however, require several seconds before starting recording alter the recording pause mode is released. This is why the beginning of the cut is lost. For the program editing operations, this unit transmits a control signal to the player to play back from about 15 seconds before the IN point and to the recorder to release

Why the end of a cut is lost, or an unnecessary scene is included at the end of a cut

starting the next recording, some recorders rewind the tape all this and then enter recording pause or stop mode. This is why the end of the cut is lost, or an unnecessary scene is included at the end of the cut. Once the furning adjustment has been done, this unit will automatically compensate for the characteristics of the recorder to ensure that the IN and OUT points are recorded control signal to the player to play back until about 2 seconds after the OUT point and to the recorder to enter the recording pause or stop mode at the OUT point. Some recorders, however, require several seconds before entering recording pause or stop mode after recording. Or, when For the program editing operations, this unit transmits a

accurately. This unit can compensate for the lag:

NTSC system - up to 5 seconds by 1/30 second (1 frame*) PAL system - up to 5 seconds by 1/25 second (1 frame*)

PAL system - from -1 second to +4 seconds by 1/25 second NTSC system - from -1 second to +4 seconds by 1/30 OUT point

One frame equate one image. The number of frames displayed in one second differs depending upon the TV system.
NTEC system – about 30 frames per second
FAL system – about 25 frames per second

45

Adjusting the Timing — To Edit Scenes Precisely


Adjusting the Recorder's Timing

Compensate for the Lag.

Procedure 2

Preparations Have a pen or something to write with.

Measure the Lag. Procedure 1



(Example)
OUT 1 -0:02 (-002F)
OUT 2 -0:06 (-006F)
OUT 3 -0:02 (-002F)
OUT 4 -0:04 (-004F)

this figure.

-0:21 (-021f) -0:22 (-022f) -0:23 (-023f) -0:20 (-020f) -0:24 (-024f)

Continued to the next page

007 PORT 0:00 0007 | 2 PART | 1 0:00 | 0007 | 2 PART | 2

THEOREM ADJUST DATA INPUT

SELECT B GO BACK

RODALANDE SET UP PLAYER/NECONDER SET UP TIMENC ADJUST DATA INFUT

8ET UP

Adjusting the Timing — To Edit Scenes Precisely

To compensate for the lag at the IN point, select "IN POINT" and press \rightarrow . Io compensate for the lag at the OUT point, select "OUT POINT" and press \rightarrow . 0

TIMING ADJUST DATA INPUT RECOUDER. 9 9 <u>→</u> Ē • adjustment value obtained in step 2 appears.
Input the value for the IN and OUT points. Press ↑, ↓ until the

The timing adjustment is completed and the menu disappears. When you have finished, press MENU. 00

If there is lag even after you have performed the timing adjustment, adjust it again manually. Even if you have performed the timing adjustment using the automatic measurement, there may be some frames of lag. If the lags are uniform when you confirm the editing result, adjust the lag manually (p. 50). The manual adjustment, however, may not be effective

you use a 4-digit counter during A/B roll editing.

the lags are not uniform.
you are recording in LP mode.
you are editing with other than the RC time code.

- With some recorders, the lag at the IN point of the first cut of the program is different from that of other cuts.
 With some recorders, the lag at the OUT point of the last cut of the program is different from that of other cuts.
 Perform the thining adjustment again when:

 —you change the recording mode (5P/L).
 —you change the control connection of the recorder and this

 On the recorder

On the player

- Accurate compensation by frame is only possible with video equipment having the RC lime code recording function. Use the video equipment on the RC time code, not the HMS counter. Accurate compensation is not possible with video equipment.
 - lacking the RC time code recording function.

On the recorder and player
Accurate compensation is not possible with video equipment that
produces noise in the picture duing the playback pause mode, or
does not have the frame-by-frame playback function.

Adjusting the Player's Timing

When you execute the A/B roll edit or synchronized playback, the images may overlap at a different point from the SYNC PB point you set. The reason for this is that the player which starts playback later (B roll player) starts playback later than the SYNC PB point. To compensate for playback rater than the SYNC PB point. To compensate for the lag, perform the timing adjustment for the player. As the lag may differ depending upon individual player, perform the fining adjustment for each player.

Two ways of timing adjustment are available. **Automatic measurement**

inputs the adjustment value automatically.

This unit measures the tape in the player for the lag, then

Manual adjustment

automatic measurement, or input the adjustment value You can revise the adjustment value obtained in the directly.

Automatic Measurement

Insert a recorded tape in the player and rewind the tape.

PANER 2 AND CHARACTER PANER 2 AND CHARACTER PANER 3 AND CHARACTER PANER (E) P D AUTO TIMING ADJUST SELECT SELECT **(C)** 1100 0 for measuring the timing automatically, and press YES. The menu of the selected item appears. Press +, + to select the item The main menu appears. Press MENU. 3

調

The automatic measurement display of Press +, + to select the player you want to measure, and the selected player appears. press YES. 4

AUTO TIMING ADJUST

PARTER 1 AND DIRECTOR
BANK TOO DESCRIPTION
IN VOICE PARTER
PARTER OFFE TO THE COME FOR
PARTER PARKEN
TOO PARKE

After this unit measures the lag, it inputs the adjustment value automatically. Press YES.

S

After the operation finishes, press MENU. The menu disappears. 0

You can revise the adjustment value (next page)

Adjusting the Timing — To Edit Scenes Precisely

Manual Adjustment

You can revise the adjustment value obtained in the automatic measurement. When you find some lag in the GPI output and EDIT I/F output timing, make the adjustment described below. In this case, measure the lag by yourself.

- The manual adjustment, however, may not be effective
- - the lags are not uniform.
 you are recording in LP mode.
 you are editing with other than the RC time code.
 you use a 4-digit counter during A/B roll editing.

SANE/LOAD
SANE/LOAD
AUTO TIMING ADJUST
NEMOTE CONTROL, FUR

0 0

800

The main menu appears.

Press MENU.


S SKEETS

Q & (2)

You can reset the performance of the unit to your preference.

Optional Settings

Setting the Options



FLANTA 2 ::00 0007 FLANTA 3 ::00 0007 GFI COTTUTE 0::00 0007 EDIT 7/T 0:00 0007 HECOMORA ANNOST DATA INFORMATION DESCRIPTION OF POLINY -0:04 (-004F) B FOLL 100 ⊕_£ ⊕_⊕ lacksquarePress +, + and change the adjustment value. Press MENU.
The menu disappears. 6 S

Press $au_i + to$ select the player for which you want to revise the adjustment value, and

To compensate for the recorder, GPI and EDIT I/F timing, select each item in this step.

then press →.

4

M

TIMING ADJUST DATA IMPUT RECOMMEN

ENTRY MODE SET UP FUNCTIONS
ENTRY MODE SET UP
PLAYER/MECONDER, SET UP
PLAYER/MECONDER, SET UP

Press ↑, ↓ to select the item for adjusting the timing manually, and press YES. The menu of the selected item appears.

150

88 118 518

SELECT SECONE

The menu of the selected item appears.

HINT HOE SET UP PLAYER/NECONDER SET UP FINING ADJUST DATA INPO

KAVE LOAD
KAVE LOAD
ANTO TRAING ADJUST
NEMOTE CONTROL FOR (E) F D

Press ↑, ↓ until the item for setting or adjusting the options appears, and press

SET 08

Optional Settings

Description of Options

INITIAL SET UP FUNCTIONS

Menu display	Setting	Description
BUTTON SOUND	No	A beep sounds when you press a button.
	OFF	No beep sounds.
ERROR SOUND	NO	Beeps sound to warn against wrong operation.
	OFF	No warning beeps sound.
DEMONSTRATION	NO	Demonstration appears when the power is turned on.
	HO.	No demonstration appears.

ENTRY MODE SET UP


Menu display	Setting	Description
GPI OUTPUT DURING ENTRY	ООТРОТ	During designation of the IN and OUT points on the entry mode display, the unit sends the GPI signal to the connected equipment when you press GPI.
	NOOUTPUT	The unit does not send the GPI signal during designation of the IN and OUT points. It sends the GPI signal during program editing instead.
AFTER ENTERING IN/OUT:	NEXT CUT	After the OUT point is set, the entry mode display to set the next IN point appears automatically. (The cut number increases.)
	CUT DATA	After each cut is set, the cut data display appears.
	PRESENT CUT	The cut number does not change. To change the cut number, press ♠, ♣.

PLAYER/RECORDER SET UP

Menu display	Setting	Description
PLAYER 1/2/3 SEARCH	FF/REW	Locates a scene by fast-forwarding or rewinding. You can set this player by player.
	CUE/REV	Locates a scene by fast-forward playback or reverse playback. You can set this player by player. Note If the interval between the cuts is too long, the recorder may release recording pause mode. In this case, change to fast-forward/rewind.
RECORDER STATUS AFTER	STOP	Sets the recorder to stop mode after program editing.
PROGRAM EDIT	PAUSE	Sets the recorder to pause mode.


Superimposing Titles

You can make titles using the keyboard and superimpose them in the program.



Making Titles

Use the buttons with white letters or marks.



To make other titles, repeat from step 1. Select a different title number in ster 2.

55

Superinposing Titles

To Type In Characters

the arrow buttons and press the character buttons. To place Move the cursor to the desired position on the screen with a blank space, press (SPACE). You can type in characters up to 24 charaters per line and

up to 12 lines per page.

To move the cursor to the next line, press ←.

To erase the character you just typed in, press BS (back

To delete a character, move the cursor to the character you want to delete and press DEL. To delete a line, move the cursor to the line you want to delete, press SHIFT and DEL at the same time.

To insert the characters,

1 Move the cursor to where you want to insert, and press

Press INS repeatedly to insert enough spaces for the characters you want to insert. If you want to overwrite, you do not need to insert A blank space is inserted.

To insert a line, move the cursor to where you want to insert, press SHIFT and INS at the same time. Type in characters.

If there is a character at 24th character position, you

cannot insert characters.

If there is a line at 12th line position, you cannot insert a

To type in upper case (capital letters), press SHIFT and the character button at the same time. If you type in all capital letters, press CAPS. Press it again to release CAPS.

To type in European letters such as "a" for example, while pressing CTRL, press "," then press "a". The CTRL button lets you select the character/mark on the upper right indication of the button. To change the font, press "font". 3 kinds of font are available. Each time you press "font", the

To change the size, press "size". 4 kinds of size are available. Each time you press "size", the size changes.

Note on large characters

When you use large characters for a title, a parts of the title

To change the color, press "colour". 8 kinds of color are available. Each time you press "colour", the color changes.

Note on font, size and color

You can select only one kind of font, size or color per line.

To use a factory preset title, press SUPER-TITLE. Each time you press SUPER-TITLE, the factory preset title

To position the title, while pressing CTRL, press ←, →, ←, → of the desired direction.

To change the line position, move the cursor to the line, then while pressing SHIFT, press Φ , Φ until the line comes to the desired position.


You can make up to 5 titles per cut and store up to 15 titles How many titles can be stored? per program.

To check the titles

Press again to make the title list disappear. Press TITLE LIST.
The list of stored titles appears.


Superimposing the Titles

You can superimpose the titles in the entry mode display or in the cut data display. Use the buttons with yellow letters or marks to superimpose the titles. You can superimpose the titles with effect such as scroll.



In the entry mode display

To turn off the title



Press the title number key (1 to 15) on the keyboard.

4 Press YES. The title indication disappears. If you do not want to superimpose the title, press NO.

Press OUT. 2

Press the desired superimpose button.
 Press MARK ITILE at the desired scene.
 Press YES. The title indication disappears.
If you do not want to turn off the title press NO.

Press the desired superimpose button. Press MARK TITLE at the desired scene.

You can superimpose a title during designating cuts or executing the program editing. Superimposing titles directly

To superimpose the title

2 Select the desired superimpose button.
3 Press MANUAL IN when you want to superimpose the title.

L Title-out point - Title-in point

Superimpose ---

Set the TITLE option using ♠, ♣, ♠, ♣.

In the cut data

To turn off the title

Press the desired superimpose button.

Press MANUAL OUT when you want to turn off the title.

cannot fit in the screen. They, however, exists out of the screen and will appear when you superimpose the title.

Saving/Loading the Program in the Disk


You can save program data including the titles in a Sony 3.5-inch floppy disk (2HD or 2DD) to load the data back to the unit to execute program editing.

When the saving is completed, press YES.

The entry mode display appears

Saving the Program

You can save 1 program data in 1 disk



1100

EXECUTE

FILE NOW

Û

LOADING COMPLETED

Ξ

THE CONTINUE

Controlling the Digital SEG

By connecting a Digital SEG having an EDIT 1/P* or GPI* input jack, you can generate effects during editing.

- EDIT 1/F (Edit Interface) and GPI (General Purpose Interface) signals are control signals output from the video editing controller to control external equipment other than the video recorder/player.

A/B Roll Edit by EDIT I/F

A/B roll edit switches 2 pictures while generating special effects such as overlapping and wiping. For A/B roll editing, you need 2 players, 1 recorder, and a Digital SEG


Note This unable to edit by ± 0 frame accuracy.

1:34:56:12 OUT

having an EDIT I/F jack.

1:34:28:00 SYNC PB 0:12:40 W 1:23:45:12 IN Player Player 2

\$27A























During A/B roll editing, the A roll cut is output from the PROCESSOR OUT 1 and the B roll cut from the PROCESSOR OUT 2 (The first cut played back is the A Make the program memory to switch from INPUT 1 to INPUT 2 on the Digital SEC. roll cut.)

Notes

Cut to be played back after switching. Designate the cut of a different player from that of A roll

You need to decide the following items for the A/B roll edit.

Cut to be played back before switching. Set the OUT point of the cut with extra seconds for

witching scenes.

When the A roll comes to the SYNC PB point, the B roll

Point to start B roll playback.

SYNC PB point

• Special effect to switch the pictures Set the special effect on the Digital SEG. • EDIT 1/F point

Point to start switching

- If you use a player with a 4-digit counter, there will be a time lag.
 Make sure that you select separate players for the A roll and B
 - roll . You cannot perform an A/B roll edit of more than 2 cuts
- The video/audio signal of the player selected when you pressed PROCESSOR ON/OFF to turn it on is output from PROCESSOR
- OUT 2 during setting. If the unit cannot execute the A/B roll edit because of an error in the A roll cut, the unit displays the message to indicate the cause. " SYNC" appears on the edit list.

The unit transmits the EDIT I/F or GPI signal. In the above example, the EDIT I/F or GPI point is same as the SYNC PB point.

Setting the A/B Roll Edit in the Program Connect the unit and the Digital SEG as shown on page 23.

Io Y-<u>و</u> On the edit list, move the B roll cut next to the A roll cut (p. 38).

-B 70 A roll

Select the player of the B roll

The video/audio signal of B roll player is input to the INPUT 2 jack of the Digital SEG.

Then turn it on again.

Press PROCESSOR ON/OFF to If the button is lit, turn it off once.

M

turn it on.

8

Select the player of the A roll

4

Select a player other than the one

selected in step 2.

When you select a player on this unit afterward, the signal to the INPUT 1 jack of the Digital SEG switches. The signal to the INPUT 2 remains same as that of the player you selected in step

On the Digital SEG, switch the pictures using the mix lever, etc. so that the INPUT 1 picture of the Digital SEG appears and make the program memory. See the operating instructions of the Digital SEC for making the program memory.

On the Digital SEG, switch the pictures using the mix lever, etc. so that the INPUT 2 picture of the Digital SEG appears and make the program memory.

Also set the switching speed and effect here.

Select a number other than the one used in step 5. O

Continued to the next page

You can easily set these items on this unit, and execute the program edit with the A/B roll.

Controlling the Digital SEG

In the A roll picture, locate the point to switch to the B roll picture.

(1) Reall the program memory of the Digital SEC made in step 5.

(2) Start playback on the A roll player, locate the scene to switch the pictures and set to pause mode.

CONT. 1/L 02 1:24:21:12 CONT. 11:24:25:12 007 1:34:26:12 Make the entry mode display of the A roll player appear, recall the program memory of the Digital SEG made in step 6 and press EDIT IF. The recalled memory number and EDIT 1/F point are displayed. 00

Press CUT DATA to make the cut data display of the A roll cut appear, and set the SYNC PB point, which should be the same counter reading as that of the EDIT IF point set in [a] Program memory number set in step 6. [b] SYNC PB point step 8.

01

The INPUT 1 signal needs to be selected before switching. Make the program memory to output the INPUT 1 signal on the Digital SEC and set it to PRE-EVENT. PRE-EVENT is Set the memory number made in step 5 to the blank item of EDIT IF, and set the counter reading to "PRE-EVENT" by keeping + [c] Program memory number set in step 5.
[d] Set to PRE-EVENT. the status before the cut is played back. pressed.

1000 1111 1000 1

å

2

I

Executing the A/B Roll Edit

881111 46 If you preview the A/B roll edit, press 1 CUT PREVIEW at the \boldsymbol{A} roll cut. Press EDIT START to execute the edit.

Notes

- The number of EDIT I/F settings in a program is limited to the number of program memories available on the Digital SEC. (This unit can display up to 15)
 This unit can control only 1 Digital SEC via the EDIT I/F jack.

A/B Roll Edit by GPI

Setting the A/B Roll Edit in the Program Connect the unit and the Digital SEG as shown on page 23.

Perform in the same way as steps 1 to 4 on page 59. 4 I

On the Digital SEG:

S

to perform wipe or mixing only
Make the setting to switch from the INPUT 1 picture to the INPUT 2 picture.
to recall the program memories in sequence.
(1) Make the program memory so that the INPUT 1 picture appears.
(2) Switch the picture and make the next program memory so that the INPUT 2 picture appears.

In the A roll picture, locate the point to switch to the B roll picture.

(1) Make the INPUT 1 picture of the Digital SEC appear.

(2) Start playback on the A roll player, locate the scene to switch the pictures and set to pause mode. 0

₤

Press CUT DATA to make the cut data display of the A roll cut appear, and set the SYNC PB point, which should be the same counter reading as that of the GPI point. Make the entry mode display of the A roll player appear, and press GPI. 00

1:24:28:00 1:24:28:12 1:34:56:12

20 A 24

Make the cut data display of the cut next to the A/B roll appear, and set the counter reading to "PRE-EVENT" by keeping aupressed. ത

32

I [RAME] Cut. J. M. Porti. J. M. Porti. J. M. Porti. J. M. Porti. J. Porti.

1181

The INPUT I signal needs to be selected before switching. Make the program memory to output the INPUT I signal on the Digital SEG and set it to PRE-EVENT. PRE-EVENT is the status before the cut is played back. [a] Aroll cut [b] B roll cut

Controlling the Digital SEG

Executing the A/B Roll Edit

 To perform wipe or mixing only
Set the Digital SEG so that the INPUT 1 picture appears.
 To recall the program memories in sequence
 Recall the first program memory containing the setting to output the INPUT 1 picture. On the Digital SEG:

Press EDIT START to execute the edit. If you preview the A/B roll edit, press I CUT PREVIEW at the A roll cut.

You can set up to 5 points of EDIT I/F and GPI in total in a A/B and B/A Roll Edit

To execute the A/B and B/A roll, make the program memories on the Digital SEG.

• A/B roll Program memory to switch from INPUT 1 to INPUT 2

... Program memory to switch from INPUT 2 to INPUT 1

• B/A roll

yesting the long switching duration of the A roll and B roll, and recalling the program memory to output the A roll and the program memory to output the B roll alternately, you can switch the pictures in sequence. This method is recommended to edit a video of long shots and one of close ups.

EDIT I/F B + A EDIT I/F A → B SYNC PB

- 30 - 30 A STATE OF THE PARTY 1 S roll A roll

Other Special Effects
When you recall the program memory of special
effects, excluding switching pictures, you can
record the cuts with mosaic and freeze effects.

Ref. No.	Part No.	Description		Rem	ıark	Ref. No.	Part No.	Description		Rema	ark
C622	1-163-239-11	CERAMIC CHIP (AEP, UK)	33PF	5%	50V	C723	1-163-241-11	CERAMIC CHIP (AEP, UK)	39PF	5%	50V
C622	1-163-243-11	CERAMIC CHIP (US, Canadian)	47PF	5%	50V	C723	1-163-243-11	CERAMIC CHIP (US, Canadian)	47PF	5%	50V
C623	1-164-232 - 11 1-163-239-11	CERAMIC CHIP	0. 01uF 33PF	5%	50V 50V	C724	1-163-116-00	CERAMIC CHIP (AEP, UK)	91PF	5%	50V
C624		(AEP, UK)				C724	1-163-251-11	CERAMIC CHIP	100PF	5%	50V
C624	1-163-243-11	CERAMIC CHIP (US, Canadian)	47PF	5%	50V	C725	1-163-038-00	(US, Canadian) CERAMIC CHIP	0. 1uF		25V
C625	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	C740	1-126-206-11	ELECT CHIP	100uF	20%	6. 3V
C626	1-124-779-00	ELECT CHIP	10uF	20%	16V	C743	1-163-251-11	CERAMIC CHIP	100PF	5%	50V
C627		CERAMIC CHIP	0. 01uF		50V	C744	1-163-038-00	CERAMIC CHIP	0. 1uF		25V
C628		CERAMIC CHIP	0. 1uF		25V	C745	1-164-232-11	CERAMIC CHIP	0. 01uF		50V
C671	1-124-779-00		10uF	20%	16V	C746	1-164-232-11	CERAMIC CHIP	0. 01uF		50V
C672	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	C747	1-126-193-11		1uF	20%	50V
C673	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	C748	1-126-206-11	ELECT CHIP	100uF	20%	6. 3V
C674	1-126-395-11		22uF	20%	16V	C749		CERAMIC CHIP	0. 1uF		25V
C675	1-126-395-11	ELECT	22uF	20%	16V	C750		CERAMIC CHIP	0. 1uF		25V
C676	1-124-779-00	ELECT CHIP	10uF	20%	16V	C751	1-126-206-11	ELECT CHIP	100uF	20%	6. 3V
C677	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	C752	1-163-017-00	CERAMIC CHIP	0. 0047uF	5%	50V
C678		CERAMIC CHIP	0. 1uF		25V	C753		CERAMIC CHIP	0. 0033uF	5%	50V
C679	1-126-206-11		100uF	20%	6. 3V	C754	1-126-602-11		3. 3uF	20%	50V
C680		CERAMIC CHIP	0. 1uF	20.0	25V	C755		CERAMIC CHIP	220PF	5%	50V
C681		CERAMIC CHIP	0. 1uF		25V	C756		CERAMIC CHIP	16PF	5%	50V
C682	1-126-206-11	ELECT CHIP	100uF	20%	6. 3V	C757	1-163-092-00	CERAMIC CHIP	9PF	0. 25PF	50V
C683	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	C758	1-163-141-00	CERAMIC CHIP	0. 001uF	5%	50V
C684	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	C761	1-126-206-11	ELECT CHIP	100uF	20%	6. 3V
C685	1-126-206-11	ELECT CHIP	100uF	20%	6. 3V	C762	1-163-038-00	CERAMIC CHIP	0. 1uF		25V
C701	1-124-779-00	ELECT CHIP	10uF	20%	16V	C763	1-163-141-00	CERAMIC CHIP	0. 001uF	5%	50V
C702	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	C771	1-163-141-00	CERAMIC CHIP	0. 001uF	5%	50V
C706	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	C772	1-164-232-11	CERAMIC CHIP	0. 01uF		50V
C707	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	C773	1-163-038-00	CERAMIC CHIP	0. 1uF		25V
C708		CERAMIC CHIP	0. 1uF		25V	C776	1-164-699-11	CERAMIC CHIP	0. 0033uF	5%	50V
C709		CERAMIC CHIP	0. 001uF	5%	50V	C781	1-163-038-00	CERAMIC CHIP	0. 1uF		25V
C710	1-163-141-00	CERAMIC CHIP	0. 001uF	5%	50V	C782	1-163-038-00	CERAMIC CHIP	0. 1uF		25V
C711	1-163-243-11	CERAMIC CHIP	47PF	5%	50V	C789	1-126-206-11	ELECT CHIP	100uF	20%	6. 3V
C712	1-163-141-00	CERAMIC CHIP	0. 001uF	5%	50V	C790	1-126-206-11	ELECT CHIP	100uF	20%	6. 3V
C714		CERAMIC CHIP	0. 001uF	5%	50V	C791	1-163-038-00	CERAMIC CHIP	0. 1uF		25V
C715	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	C792	1-163-038-00	CERAMIC CHIP	0. 1uF		25V
C716	1-126-206-11	ELECT CHIP	100uF	20%	6. 3V	C794	1-163-038-00	CERAMIC CHIP	0. 1uF		25V
C717	1-126-206-11	ELECT CHIP	100uF	20%	6. 3V	C795	1-163-141-00	CERAMIC CHIP	0.001uF	5%	50V
C718		CERAMIC CHIP	0. 1uF		25V	C797	1-163-251-11	CERAMIC CHIP	100PF	5%	50V
C719		CERAMIC CHIP	100PF	5%	50V	C798		CERAMIC CHIP	220PF	5%	50V
C720		CERAMIC CHIP	330PF	5%	50V	C799		CERAMIC CHIP	220PF	5%	50V
0701	1_100 051 11	CEDAMIC CUID	10000	Ew	EUM			(AEP, UK)			
C721		CERAMIC CHIP	100PF	5% 5%	50V	CONT	116303000	CEDAMIC CHID	0 1F		2577
C722	T-T02-080-00	CERAMIC CHIP	13PF	5%	50V	C801		CERAMIC CHIP	0. 1uF		25V
gane	1 100 000 00	(AEP, UK)	1000	E ev	EON	C802		CERAMIC CHIP	0. 1uF		25V
C722	T-T02-AAQ-AA	CERAMIC CHIP	16PF	5%	50V	C803		CERAMIC CHIP	0. 1uF		25V
		(US, Canadian)				C804		CERAMIC CHIP	0. 1uF	0 505	25V
						C805	1-163-227-11	CERAMIC CHIP	10PF	0. 5PF	bUV

Ref. No.	Part No.	Description		Rem	ark	Ref. No.	Part No.	Descript	ion		Rem	ark
C806	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	C969	1-124-360-00	ELECT		1000uF	20%	16V
C807	1-163-038-00		0. 1uF		25V	C981	1-164-232-11	CERAMIC	CHIP	0. 01uF		50V
C808	1-126-206-11		100uF	20%	6. 3V	C983	1-163-038-00			0. 1uF		25V
C810	1-163-038-00		0. 1uF	20.0	25V	C984	1-164-232-11			0. 01uF		50V
C811	1-163-038-00		0. 1uF		25V	0001	1 101 202 11	ODIUMITO	01111	0.0141		
0011	1 100 000 00	OCIULIIO OIII	0. Iui					< CONNEC	TOR >			
C812	1-163-038-00	CERAMIC CHIP	0. 1uF		25V				•			
C813	1-163-038-00		0. 1uF		25V	* CN001	1-564-007-11	PIN, CON	NECTOR	8P		
C816	1-163-038-00		0. 1uF		25V		1-562-717-11					
C817	1-163-038-00		0. 1uF		25V	CN104	1-564-002-11	PIN, CON	NECTOR	3P		
C818	1-163-038-00		0. 1uF		25V		1-562-717-11					
							1-562-717-11					
C819	1-163-038-00	CERAMIC CHIP	0. 1uF		25V							
C820	1-126-395-11		22uF	20%	16V	CN401	1-691-199-21	CONNECTO	R, FPC	26P		
C821		CERAMIC CHIP	0. 1uF		25V	CN403	1-691-199-21	CONNECTO	R, FPC	26P		
C822		CERAMIC CHIP	0. 1uF		25V	CN501	1-506-470-11	PIN, CON	NECTOR	5P		
C823	1-163-038-00		0. 1uF		25V							
								< DIODE	>			
C831	1-163-235-11	CERAMIC CHIP	22PF	5%	50V							
C832	1-163-235-11	CERAMIC CHIP	22PF	5%	50V	D001	8-719-157-33	DIODE	RD6. 2M-	В		
C833	1-163-235-11	CERAMIC CHIP	22PF	5%	50V	D002	8-719-157-33	DIODE	RD6. 2M-	В		
C834	1-163-235-11	CERAMIC CHIP	22PF	5%	50V	D003	8-719-157-33	DIODE	RD6. 2M-	В		
C881	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	D004	8-719-157-33	DIODE	RD6. 2M-	В		
						D060	8-719-988-40	DIODE	HVR17TR	F (AEP, UK)		
C882	1-163-038-00	CERAMIC CHIP	0. 1uF		25V							
C883	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	D281	8-719-106-43	DIODE	RD9. 1M-	B1		
C884	1-124-779-00	ELECT CHIP	10uF	20%	16V	D291	8-719-104-34	DIODE	1S2836			
C891	1-126-206-11	ELECT CHIP	100uF	20%	6. 3V	D331	8-719-800-76	DIODE	1SS226			
C892	1-126-206-11	ELECT CHIP	100uF	20%	6. 3V	D341	8-719-800-76	DIODE	1SS226			
					l	D351	8-719-800-76	DIODE	1SS226			
C893	1-126-206-11	ELECT CHIP	100uF	20%	6. 3V							
C894	1-126-206-11	ELECT CHIP	100uF	20%	6. 3V	D361	8-719-800-76	DIODE	1SS226			
C896	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	D371	8-719-800-76	DIODE	1SS226			
C897	1-163-251-11	CERAMIC CHIP	100PF	5%	50V	D381	8-719-800-76	DIODE	1SS226			
C898	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	D421	8-719-800-76	DIODE	1SS226			
						D481	8-719-104-34	DIODE	1S2836	(US, Canadian))	
C899	1-163-038-00	CERAMIC CHIP	0. 1uF		25V							
C901	1-124-779-00	ELECT CHIP	10uF	20%	16V	D482	8-719-104-34		1S2836			
C903	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	D484	8-719-104-34			(AEP, UK)		
C904	1-164-232-11	CERAMIC CHIP	0. 01uF		50V	D485	8-719-104-34		1S2836			
C905	1-124-360-00	ELECT	1000uF	20%	16V	D486	8-719-104-34		1S2836			
						D487	8-719-104-34	DIODE	1S2836	(US, Canadian))	
C917	1-124-779-00		10uF	20%	16V							
C919		CERAMIC CHIP	0. 1uF		25V	D488	8-719-104-34			(AEP, UK)		
C920	1-164-232-11	CERAMIC CHIP	0. 01uF		50V	D489	8-719-104-34		1S2836			
C921	1-124-360-00	ELECT	1000uF	20%	16V	D490	8-719-104-34		1S2836			
C933	1-164-232-11	CERAMIC CHIP	0. 01uF		50V	D491	8-719-104-34			(US, Canadian)		
						D493	8-719-104-34	DIODE	1S2836	(US, Canadian))	
C935		CERAMIC CHIP	0. 1uF		25V							
C936		CERAMIC CHIP	0. 01uF		50V	D494	8-719-104-34			(US, Canadian))	
C949	1-124-779-00		10uF	20%	16V	D495	8-719-104-34			(AEP, UK)		
C951	1-163-038-00		0. 1uF		25V	D741	8-719-988-40		HVR17TR	F		
C952	1-164-232-11	CERAMIC CHIP	0. 01uF		50V	D800	8-719-104-34		1S2836			
***	4 404 5	Er com	4005 =	0.0	4011	D801	8-719-801-78	DIODE	1SS184			
C953	1-124-360-00		1000uF	20%	16V	B000	0.840.404.53	24014	400000			
C965	1-124-779-00		10uF	20%	16V	D802	8-719-104-34		1S2836	D4		
C967		CERAMIC CHIP	0. 1uF		25V	D803	8-719-106-43		RD9. 1M-	RT		
C968	1-164-232-11	CERAMIC CHIP	0. 01uF		50V	D806	8-719-800-76	NIONE	1SS226			

AV-26P

AV-26U

Ref. No.	Part No.	Descri	ption	Remark	Ref. No.	Part No.	Descr	iption		Remark
D807	8-719-157-33	DIODE	RD6. 2M-B		IC301	8-759-710-07	IC 1	 VJM2234M	(VIDEO SELECTOR)	
D808	8-719-157-33		RD6. 2M-B			8-759-710-07			(Y SELECTOR)	
D809	8-719-157-33		RD6. 2M-B			8-759-710-07			(C SELECTOR)	
D810	8-719-157-33		RD6. 2M-B			8-759-710-07			(VIDEO SELECTOR)	
D811	8-719-157-33		RD6. 2M-B			8-759-710-07			(Y SELECTOR)	
D812	8-719-106-43	DIODE	RD9. 1M-B1	•	10306	8-759-710-07	IC i	V.TM2234M	(C SELECTOR)	
D831	8-719-104-34		1S2836			8-759-056-33			(MAIN SELECTOR)	
D832	8-719-104-34		1S2836			8-759-300-71		•	FP (Y/C SELECTOR)	
D832	8-719-104-34		1S2836			8-759-300-71			FP (MONOTONE SW)	
D881	8-719-104-34		1SS226			8-752-352-67			T6 (INT SYSC & BU	RST GEN)
1001	0 713 000 70	DIODL	100220		10411	0 102 002 01	10	MUTTOOM	16 (1M1 5156 & 56	nor deny
D882	8-719-800-76		1SS226			8-759-032-01			AF (NAND)	_,
D883	8-719-800-76		1SS226			8-759-056-33			(INT/EXIT SELECTO	
D884	8-719-800-76		1SS226			8-759-605-29			(TIMING GEN & AGO	·)
D885	8-719-800-76		1SS226			8-759-925-74			ANS (INV)	
D886	8-719-800-76	DIODE	1SS226		IC471	8-759-631-08	IC I	M51279FP	(ACC, ACK APC)	
D887	8-719-800-76	DIODE	1SS226		IC490	8-759-926-74	IC :	SN74HC393	BANS (H COUNTOR)	AEP, UK)
D888	8-719-800-76	DIODE	1SS226		IC491	8-759-926-74	IC :	SN74HC393	BANS (H COUNTOR)	
D896	8-719-104-34	DIODE	1S2836		IC492	8-759-032-01	IC !	AC74HC00A	AF (NAND)	
D899	8-719-157-33	DIODE	RD6. 2M-B		IC493	8-759-032-23	IC !	MC74HC74	AF (D F/F)	
D901	8-719-800-76	DIODE	1SS226		IC511	8-759-011-65	IC I	AC74HC40	53F (Y MAIN FADER)	
D917	8-719-800-76	DIODE	1SS226		IC512	8-759-011-65	IC I	MC74HC405	53F (Y MAIN FADER)	
D933	8-719-800-76		1SS226			8-759-011-65			53F (C MAIN FADER)	
D949	8-719-800-76		1SS226			8-759-011-65			53F (C MAIN FADER)	
D965	8-719-800-76		1SS226			8-759-011-65			53F (MONI Y SELECT	
D981	8-719-800-76		1SS226			8-759-011-65			53F (MONI C SELECT	
		< IC >			TCER1	8-759-011-65	īc i	4C7 AUC AO	53F (Y TITLE FADER	١
		\ 10 /	,			8-759-011-65			53F (Y TITLE FADER	-
10012	8-759-300-71	IC U	ID14053BFP (PROCESSOR SEL	ECTOD)		8-759-011-65			53F (C TITLE FADER	
	8-759-300-71		ID14053BFP (PROCESSOR SEL			8-759-011-65			53F (C TITLE FADER	
	8-759-100-96		iPC4558G2 (AUDIO AMP)	ECTOR)		8-759-011-03			AF (NAND)	.)
	8-759-100-96		PC4558G2 (AUDIO AMP)		10391	0-739-032-01	10	107411000	Ar (NANV)	
	8-759-100-90		iPC4558G2 (AUDIO AMP)		ICEUS	8-759-032-01	IC I	MC7AUCOO.	AF (NAND)	
10103	0-739-100-90	ic u	IFU433002 (AUDIO AMF)			8-759-056-33			(REC OUT SELECT)	
10104	8-759-100-96	īC	PC4558G2 (AUX AMP)			8-759-056-33			(MONITOR OUT SELECT)	ርጥ\
				CTOD\						
	8-759-009-06		IC14052BF (PROCESSOR SELE IC14052BF (PROCESSOR SELE			8-759-300-71			FP (REC Y/C SELECT	UK)
	8-759-009-06		DO	CIUK)	<u>√₹</u> 100/1	8-759-251-39	16	PQIZIZIU	(AVCC REG)	
	8-759-100-96		PC4558G2 (PROCESSOR AMP)	ECTOD)	10070	9_750_15700	IC !	000577111	(AVAM DEC)	
10102	8-759-300-71	10 H	ID14053BFP (PROCESSOR SEL	EUTUR)		8-759-157-22 8-759-157-22			(AVMM REG)	
10150	0_750, 200, 71	ור וו	INTANEODED (DRAGEGGAD GEL	ECTOB)				•	(EVER5 REG)	
	8-759-300-71 8-759-100-96		ID14053BFP (PROCESSOR SEL	LUIUR)		8-759-157-22		-	(FD VDD REG)	
			PC4558G2 (MAIN AMP)			8-752-033-58			&C ENCODER)	
	8-759-100-96		PC4558G2 (PROCESSOR AMP)	}	10702	8-759-032-16	10	110 / 4HUU8/	AF-T2 (AND)	
	8-759-100-96		PC4558G2 (PROCESSOR AMP)		10741	0 750 007 00	7.0	WD4 0000	(040511 +50)	
10201	8-759-981-58	10 K	C2043MD (MIC AMP)			8-759-987-20		-	(910FH AFC)	
10044	0 750 005 10	70	(F4404) /HTG 17G+\	,		8-759-191-44			(SCROLL G. A.)	
	8-759-605-46		IS1131L (MIC VCA)			8-759-907-81			INS (H&V TIMING)	
	8-759-605-46		151131L (AUX VCA)			8-759-907-81			INS (H&V TIMING)	
	8-759-605-46		IS1131L (MAIN VCA)		1C781	8-759-008-48	IC	MC74HC861	r (NUK)	
	8-759-100-96		PC4558G2 (MIC AMP)		****	0 550 000	7.0		17. (N.1115)	
1C261	8-759-100-96	IC u	PC4558G2 (REC AMP)			8-759-032-23			AF (NAND)	
						8-759-032-01			AF (NAND)	
	8-759-300-71		ID14053BFP (SELECTOR)			8-759-032-11		MC74HC04A		
10263	8-759-100-96	IC u	PC4558G2 (MONITOR AMP)	1	IC791	8-759-251-38	IC 1	MB90076BI	PF-G-BND (OSD)	

The components identified by Les composants identifiés

par une marque ⚠ sont

critiques pour la sécurité.

portant le numéro spécifié.

Ne les remplacer que par une pièce

mark $\underline{\Lambda}$ or dotted line with

mark. 🛕 are critical for

safety. Replace only with

part number specified.

C1793 8-759-274-02 C	Ref. No.	Part No.	Description	Rei	mark	Ref. No.	Part No.	Description	Remark
1080 8-759-273-98 C B06473837F (FROTT MICOM)	10793	8-759-274-02	IC HN62314RF (FRONT ROM)		1.707	1-410-384-31	INDUCTOR CHI	P 18uH (AFP IIK)
16802 8-759-273-98 IC HDR478954F (EDIT WICHO)									· · · ·
10803 8-759-253-14 1C M888131-165 (8 BOLL LAKO MICOM)									
CRORD 8 -759-253-14 IC MBB9131-155 CROIL LANC MICON)				•	OM)				
1681 8-759-982-82 10 SYTAMID TAMAS (ADDRESS LATCH) 1781 1-543-813-21 FILTER, EMI 1782 1-543-813-21 FILTER, EMI 1783 1-543-813-21 FILTER, EMI 1783 1-543-813-21 FILTER, EMI 1784 1-543-813-21 FILTER, EMI 1784 1-543-813-21 FILTER, EMI 1784 1-543-813-21 FILTER, EMI 1785 1-543-813-21 FILTER, EMI 1-54				•					
1-610 8-759-98-26-28 IC SYMINDTAMNS (ADDRESS LATCH) 1-759-98-26-28 IC SYMINDTAMNS (ADDRESS LATCH) 1-759-98-26-28 IC SYMINDTAMNS (ADDRESS LATCH) 1-759-98-27-10 IC SYMINDTAMNS (ADDRESS LATCH) 1-759-98-27-10 IC SYMINDTAMNS (ADDRESS LATCH) 1-759-98-27-10 IC SYMINDTAMNS (ADDRESS LATCH) 1-759-98-21-21 FILTER, EMI 1-759-98-21-21 IC MC74RC04AF (INV) 1-759-98-21-21 IC	IC806	8-759-501-36	IC MB84256A-LL	-PF-E1 (RAM)		L745	1-543-813-21	FILTER, EMI	
1681 8-759-926-72 C									
1.0815 8-759-032-23 C MC74HC74AF (D F/F) L791	IC811	8-759-926-28	IC SN74HC174AN	IS (ADDRESS LATCH)		L762	1-543-813-21	FILTER, EMI	
	IC814	8-759-925-74	IC SN74HC04ANS	(INV)		L763	1-543-813-21	FILTER, EMI	
ICASE 8-759-003-06 IC MC140528F (LANC I/O SELECTOR) L801 1-543-813-21 FILTER, EMI L802 8-759-032-11 IC MC74RC048F (INV) L801 1-543-813-21 FILTER, EMI L804 1-543-813-21 FILTER, EMI L804 1-543-813-21 FILTER, EMI L804 1-543-813-21 FILTER, EMI L805 1-543-813-21 FILTER, EMI L805 1-543-813-21 FILTER, EMI L806 1-543-813-21 FILTER, EMI L806 1-543-813-21 FILTER, EMI L806 1-543-813-21 FILTER, EMI L807	IC815	8-759-032-23	IC MC74HC74AF	(D F/F)		L791	1-543-813-21	FILTER, EMI	
IC881 8-759-922-80 IC C	IC821	8-759-009-06	IC MC14052BF (LANC I/O SELECTOR)	L792	1-543-813-21	FILTER, EMI	
C682 8-759-925-8 C				LANC I/O SELECTOR)	L793	1-543-775-11	FILTER, EMI	
1-543-813-21 FILTER, EMI 1-543-813-21 FILTER	IC881	8-759-032-11	IC MC74HC04AF	(INV)	İ	L801	1-543-813-21	FILTER, EMI	
1.6891				(INV)		L802	1-543-813-21	FILTER, EMI	
1.682	IC883	8-759-032-16	IC MC74HC08AF-	T2 (AND)		L804	1-543-813-21	FILTER, EMI	
C828 8-759-937-55 C S-8054AB-E-M-S (RESET) L806 1-543-813-21 FILTER, EMI EMS 8-759-511-00 C REVAZAMA (LOW BATT DET) L807 1-543-813-21 FILTER, EMI L808 1-540-803-21 FILTER, EMI L809 1-543-813-21 FILTER, EMI L809 1-543-813-21 FILTER, EMI L809 1-543-813-21 FILTER, EMI L809 1-543-813-21 FILTER, EMI L809 L809 1-543-813-21 FILTER, EMI L809 L809 1-543-813-21 FILTER, EMI L809 L809 L809 1-543-813-21 FILTER, EMI L809	IC891	8-759-044-65	IC M62352FP (E	VR)		L805	1-543-813-21	FILTER, EMI	
Carrier Carr			·	M-S (RESET)					
1.689	IC893	8-759-511-00	IC RH5VA24AA (LOW BATT DET)		L807			
10899 8-759-300-71 C	IC897	8-759-274-01				L808	1-410-658-31	INDUCTOR CHI	P 220uH
Correct Corr	IC898	8-759-032-01	IC MC74HC00AF	(NAND)		L809	1-543-813-21	FILTER, EMI	
1.6900 8-759-274-03 C uPD17203A6C (IR MICOM) L811 1-543-813-21 FILTER, EMI L881 1-543-813-21 FILTER, EMI L881 1-543-813-21 FILTER, EMI L889 1-543-813-21 FILTER, EMI L889 1-543-813-21 FILTER, EMI L899 L843-813-21 FILTER, EMI L843-813-21 FILTER, EMI L899 L843-813-21 FILTER, EMI L899 L843-813-21 FILTER, EMI L843-813-21 F	IC899	8-759-300-71	IC HD14053BFP	(DATA BUS SELECTO	R)	L810	1-543-813-21	FILTER, EMI	
L899 1-543-813-21 FILTER, EMI	IC900	8-759-274-03					1-543-813-21	FILTER, EMI	
L013						L881	1-543-813-21	FILTER, EMI	
L014			< COIF >			L899	1-543-813-21	FILTER, EMI	
L016	L013	1-410-388-31	INDUCTOR CHIP	39uH				< TRANSISTOR	>
L017 1-410-388-31 INDUCTOR CHIP 39uH Q014 8-729-120-28 TRANSISTOR 2SC1623-L5L6 Q016 8-729-120-28 TRANSISTOR 2SC1623-L5L6 Q016 8-729-120-28 TRANSISTOR 2SC1623-L5L6 Q016 8-729-120-28 TRANSISTOR 2SC1623-L5L6 Q017 8-729-120-28 TRANSISTOR 2SC1623-L5L6 Q017 8-729-120-28 TRANSISTOR 2SC1623-L5L6 Q018 R-729-120-28 TRANSISTOR 2SC1623-L5L6 Q018 R-729-120-28 TRANSISTOR QSC1623-L5L6 Q018 R-729-120-28 TRANSISTOR QSC1623-L5L6 Q018 R-729-120-28 TRANSISTOR QSC1623-L5L6 Q019 R-729-120-28 TRANSISTOR Q019 R-729-120-28 TRANSISTOR Q019 R-729-120-28 TRANSISTOR Q019 R-729-120-28 TRANSISTOR Q019 R-									
L401 1-410-388-31 INDUCTOR CHIP 39uH Q015 8-729-216-22 TRANSISTOR 2SC1623-L5L6 Q016 8-729-120-28 TRANSISTOR 2SC1623-L5L6 Q016 8-729-120-28 TRANSISTOR 2SC1623-L5L6 Q016 8-729-120-28 TRANSISTOR 2SC1623-L5L6 Q017 8-729-120-28 TRANSISTOR 2SC1623-L5L6 Q018 R-729-120-28 TRANSISTOR Q019 R-729-120-28 TRANSISTOR						-			
Q016 8-729-120-28 TRANSISTOR 2SC1623-L5L6 L403						-			
L402 1-410-388-31 INDUCTOR CHIP 39uH Q017 8-729-120-28 TRANSISTOR 2SC1623-L5L6	L401	1-410-388-31	INDUCTOR CHIP	39uH		•			
1-410-388-31 INDUCTOR CHIP 39uH			TURLIAMAN ALLIN			-			
L411 1-543-813-21 FILTER, EMI Q018 8-729-923-80 TRANSISTOR DTC143EK						QU17	8-729-120-28	TRANSISTOR	2SC1623-L5L6
L412 1-410-384-31 INDUCTOR CHIP 18uH (AEP, UK) Q019 8-729-120-28 TRANSISTOR 2SC1623-L5L6 Q020 8-729-120-28 TRANSISTOR 2SC1623-L5L6 Q021 8-729-120-28 TRANSISTOR 2SC1623-L5L6 Q022 8-729-120-28 TRANSISTOR 2SC1623-L5L6 Q024 8-729-923-80 TRANSISTOR 2SC3624A-L15 Q060 8-729-122-63 TRANSISTOR 2SC3624A-L15 Q060 8-729-122-63 TRANSISTOR 2SC3624A-L15 Q060 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q071 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q171 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q171 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q171 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q171 8-729-923-80 TRANSISTOR 2SC3624A-L15 Q191 8-729-923-80 TRANSISTOR DTC143EK Q192 8-729-923-80 TRANSISTOR DTC143EK Q192 8-729-923-80 TRANSISTOR DTC143EK Q193 8-729-923-80 TRANSISTOR DTC143EK Q193 8-729-923-80 TRANSISTOR DTC143EK Q194 8-729-923-80 TRANSISTOR DTC143EK Q195 8-729-923-80 TRANSISTOR DTC143EK				39uH	İ	0010	0 700 000 00	mb a Ma Lamon	pmg4 April
L412 1-410-385-11 INDUCTOR CHIP 22uH (US, Canadian) Q020 8-729-120-28 TRANSISTOR 2SC1623-L5L6 Q021 8-729-216-22 TRANSISTOR 2SA1162-G L413 1-410-392-11 INDUCTOR CHIP 82uH (AEP, UK) Q022 8-729-120-28 TRANSISTOR 2SC1623-L5L6 L413 1-410-393-11 INDUCTOR CHIP 100uH (US, Canadian) L414 1-410-393-11 INDUCTOR CHIP 100uH Q023 8-729-120-28 TRANSISTOR 2SC1623-L5L6 L441 1-543-813-21 FILTER, EMI Q024 8-729-923-80 TRANSISTOR DTC143EK L471 1-543-813-21 FILTER, EMI Q060 8-729-122-63 TRANSISTOR 2SC3624A-L15 L621 1-410-388-31 INDUCTOR CHIP 39uH L701 1-410-388-31 INDUCTOR CHIP 39uH L701 1-410-387-11 INDUCTOR CHIP 33uH L701 1-410-387-11 INDUCTOR CHIP 33uH L702 1-410-382-31 INDUCTOR CHIP 12uH Q173 8-729-107-46 TRANSISTOR 2SC3624A-L15 L703 1-410-382-31 INDUCTOR CHIP 12uH Q174 8-729-23-80 TRANSISTOR DTC143EK Q192 8-729-23-80 TRANSISTOR DTC143EK Q192 8-729-23-80 TRANSISTOR DTC143EK Q192 8-729-23-80 TRANSISTOR DTC143EK Q193 8-729-923-80 TRANSISTOR DTC143EK Q194 8-729-923-80 TRANSISTOR DTC143EK Q195 8-729-923-80 TRANSISTOR DTC143EK DTC143EK				10 (AED HV)					
Q021 8-729-216-22 TRANSISTOR 2SA1162-G					,				
L413 1-410-392-11 INDUCTOR CHIP 82uH (AEP, UK) L414 1-410-393-11 INDUCTOR CHIP 100uH (US, Canadian) L414 1-410-393-11 INDUCTOR CHIP 100uH (US, Canadian) L414 1-543-813-21 FILTER, EMI Q024 8-729-923-80 TRANSISTOR 2SC1623-L5L6 L441 1-543-813-21 FILTER, EMI Q024 8-729-923-80 TRANSISTOR DTC143EK L471 1-543-813-21 FILTER, EMI Q060 8-729-122-63 TRANSISTOR 2SC3624A-L15 L621 1-410-388-31 INDUCTOR CHIP 39uH Q172 8-729-107-46 TRANSISTOR 2SC3624A-L15 L622 1-410-388-31 INDUCTOR CHIP 39uH Q173 8-729-107-46 TRANSISTOR 2SC3624A-L15 L701 1-410-387-11 INDUCTOR CHIP 33uH Q173 8-729-107-46 TRANSISTOR 2SC3624A-L15 L702 1-410-387-11 INDUCTOR CHIP 33uH Q174 8-729-107-46 TRANSISTOR 2SC3624A-L15 L703 1-410-382-31 INDUCTOR CHIP 12uH Q191 8-729-923-80 TRANSISTOR DTC143EK L704 1-410-382-31 INDUCTOR CHIP 12uH Q193 8-729-923-80 TRANSISTOR DTC143EK L705 1-410-387-11 INDUCTOR CHIP 27uH (AEP, UK) L705 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) Q194 8-729-923-80 TRANSISTOR DTC143EK L706 1-410-387-11 INDUCTOR CHIP 33uH (AEP, UK) Q195 8-729-923-80 TRANSISTOR DTC143EK DTC143EK DTC143EK DTC143EK DTC143EK DTC143EK DTC143EK DTC143EK DTC143EK DTC143EK DTC143EK DTC143EK DTC143EK DTC143EK DTC143EK DTC143EK DTC143EK DTC143EK DTC143EK DTC143EK	L41Z	1-410-363-11	INDUCTOR CHIP	ZZun (US, Ganadian)	'	-			
L413 1-410-393-11 INDUCTOR CHIP 100uH (US, Canadian) L414 1-410-393-11 INDUCTOR CHIP 100uH L414 1-543-813-21 FILTER, EMI L471 1-543-813-21 FILTER, EMI L471 1-543-813-21 FILTER, EMI L621 1-410-388-31 INDUCTOR CHIP 39uH L701 1-410-387-11 INDUCTOR CHIP 33uH L702 1-410-387-11 INDUCTOR CHIP 33uH L703 1-410-382-31 INDUCTOR CHIP 12uH L704 1-410-382-31 INDUCTOR CHIP 12uH L705 1-410-387-11 INDUCTOR CHIP 27uH (AEP, UK) L705 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L706 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L706 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L706 1-410-387-11 INDUCTOR CHIP 33uH (AEP, UK) L707 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L708 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L709 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L700 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L701 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L702 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L703 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L704 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L705 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L706 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L707 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L708 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L709 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L700 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L700 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L700 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L700 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L700 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L700 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L700 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L700 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L700 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L700 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L700 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L700 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L700 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L700 1-410-387-11 INDUCTOR CHIP 33uH	1.413	1_410_309_11	INDUCTOR CHIR	921H (AED HK)		•			
L414 1-410-393-11 INDUCTOR CHIP 100uH Q023 8-729-120-28 TRANSISTOR 2SC1623-L5L6 L441 1-543-813-21 FILTER, EMI Q024 8-729-923-80 TRANSISTOR DTC143EK L471 1-543-813-21 FILTER, EMI Q060 8-729-122-63 TRANSISTOR 2SC3624A-L15 L621 1-410-388-31 INDUCTOR CHIP 39uH Q172 8-729-107-46 TRANSISTOR 2SC3624A-L15 L622 1-410-388-31 INDUCTOR CHIP 39uH Q173 8-729-107-46 TRANSISTOR 2SC3624A-L15 L701 1-410-387-11 INDUCTOR CHIP 33uH Q173 8-729-107-46 TRANSISTOR 2SC3624A-L15 L702 1-410-387-11 INDUCTOR CHIP 33uH Q174 8-729-107-46 TRANSISTOR 2SC3624A-L15 L703 1-410-382-31 INDUCTOR CHIP 12uH Q191 '8-729-923-80 TRANSISTOR DTC143EK L704 1-410-382-31 INDUCTOR CHIP 12uH Q193 8-729-923-80 TRANSISTOR DTC143EK L705 1-410-387-11 INDUCTOR CHIP 27uH (AEP, UK) L705 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) Q194 8-729-923-80 TRANSISTOR DTC143EK L706 1-410-387-11 INDUCTOR CHIP 33uH (AEP, UK) Q195 8-729-923-80 TRANSISTOR DTC143EK					2)	QULL	0 723 120 20	IIIANGIGION	2301023 E3E0
L441 1-543-813-21 FILTER, EMI L471 1-543-813-21 FILTER, EMI Q060 8-729-122-63 TRANSISTOR 2SA1226-E3 (AEP, UK) Q171 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q171 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q172 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q173 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q174 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q175 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q176 1-410-387-11 INDUCTOR CHIP 33uH Q177 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q178 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q179 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q190 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q191 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q192 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q193 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q194 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q195 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q196 Q197 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q197 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q198 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q199 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q190 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q191 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q191 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q192 8-729-107-46 TRANSISTOR 2SC3624A-L15 Q193 8-729-107-46 TRANSISTOR DTC143EK Q194 8-729-107-46 TRANSISTOR DTC143EK Q195 8-729-107-46 TRANSISTOR DTC143EK Q196 Q197 8-729-107-46 TRANSISTOR DTC143EK Q197 8-729-107-46 TRANSISTOR DTC143EK Q198 8-729-107-46 TRANSISTOR DTC143EK Q199 8-729-107-46 TRANSISTOR DTC143EK Q199 8-729-107-46 TRANSISTOR DTC143EK Q199 8-729-107-46 TRANSISTOR DTC143EK Q199 8-729-107-46 TRANSISTOR DTC143EK Q190 8-729-107-46 TRANSISTOR DTC143EK Q190 8-729-107-46 TRANSISTOR DTC143EK Q190 8-729-107-46 TRANSISTOR DTC143EK Q190 8-729-107-46 TRANSISTOR DTC143EK Q190 8-729-107-46 TRANSISTOR DTC143EK Q190 8-729-107-46 TRANSISTOR DTC143EK					"		8-72Q-12D-2Q	TRANSISTOR	2501623-1516
L471 1-543-813-21 FILTER, EMI Q060 8-729-122-63 TRANSISTOR 2SA1226-E3 (AEP, UK)				TOOULI		-			
Q171 8-729-107-46 TRANSISTOR 28C3624A-L15									
L621 1-410-388-31 INDUCTOR CHIP 39uH Q172 8-729-107-46 TRANSISTOR 2SC3624A-L15 L622 1-410-388-31 INDUCTOR CHIP 39uH L701 1-410-387-11 INDUCTOR CHIP 33uH Q173 8-729-107-46 TRANSISTOR 2SC3624A-L15 L702 1-410-387-11 INDUCTOR CHIP 33uH Q174 8-729-107-46 TRANSISTOR 2SC3624A-L15 L703 1-410-382-31 INDUCTOR CHIP 12uH Q191 '8-729-923-80 TRANSISTOR DTC143EK Q192 8-729-923-80 TRANSISTOR DTC143EK Q192 8-729-923-80 TRANSISTOR DTC143EK Q193 8-729-923-80 TRANSISTOR DTC143EK Q194 8-729-923-80 TRANSISTOR DTC143EK Q195 1-410-386-11 INDUCTOR CHIP 27uH (AEP, UK) Q196 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) Q194 8-729-923-80 TRANSISTOR DTC143EK Q195 8-729-923-80 TRANSISTOR DTC143EK Q196 1-410-387-11 INDUCTOR CHIP 33uH (AEP, UK) Q195 8-729-923-80 TRANSISTOR DTC143EK	B 1.1.1	1 010 010 21	TIDIDI, BIII			•			
L622 1-410-388-31 INDUCTOR CHIP 39uH L701 1-410-387-11 INDUCTOR CHIP 33uH Q173 8-729-107-46 TRANSISTOR 2SC3624A-L15 L702 1-410-387-11 INDUCTOR CHIP 33uH Q174 8-729-107-46 TRANSISTOR 2SC3624A-L15 L703 1-410-382-31 INDUCTOR CHIP 12uH Q191 '8-729-923-80 TRANSISTOR DTC143EK L704 1-410-382-31 INDUCTOR CHIP 12uH Q193 8-729-923-80 TRANSISTOR DTC143EK L705 1-410-386-11 INDUCTOR CHIP 27uH (AEP, UK) L705 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) Q194 8-729-923-80 TRANSISTOR DTC143EK L706 1-410-387-11 INDUCTOR CHIP 33uH (AEP, UK) Q195 8-729-923-80 TRANSISTOR DTC143EK	L621	1-410-388-31	INDUCTOR CHIP	39uH					
L701 1-410-387-11 INDUCTOR CHIP 33uH Q173 8-729-107-46 TRANSISTOR 2SC3624A-L15 L702 1-410-387-11 INDUCTOR CHIP 33uH Q174 8-729-107-46 TRANSISTOR 2SC3624A-L15 L703 1-410-382-31 INDUCTOR CHIP 12uH Q191 '8-729-923-80 TRANSISTOR DTC143EK L704 1-410-382-31 INDUCTOR CHIP 12uH Q193 8-729-923-80 TRANSISTOR DTC143EK L705 1-410-386-11 INDUCTOR CHIP 27uH (AEP, UK) L705 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) Q194 8-729-923-80 TRANSISTOR DTC143EK L706 1-410-387-11 INDUCTOR CHIP 33uH (AEP, UK) Q195 8-729-923-80 TRANSISTOR DTC143EK						\-			
L702 1-410-387-11 INDUCTOR CHIP 33uH Q174 8-729-107-46 TRANSISTOR 2SC3624A-L15 L703 1-410-382-31 INDUCTOR CHIP 12uH Q191 8-729-923-80 TRANSISTOR DTC143EK Q192 8-729-923-80 TRANSISTOR DTC143EK Q193 8-729-923-80 TRANSISTOR DTC143EK Q193 8-729-923-80 TRANSISTOR DTC143EK Q194 8-729-923-80 TRANSISTOR DTC143EK Q195 1-410-386-11 INDUCTOR CHIP 27uH (AEP, UK) Q196 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) Q197 8-729-923-80 TRANSISTOR DTC143EK Q198 8-729-923-80 TRANSISTOR DTC143EK Q199 8-729-923-80 TRANSISTOR DTC143EK Q190 8-729-923-80 TRANSISTOR DTC143EK Q190 8-729-923-80 TRANSISTOR DTC143EK						Q173	8-729-107-46	TRANSISTOR	2SC3624A-L15
L703 1-410-382-31 INDUCTOR CHIP 12uH Q191 8-729-923-80 TRANSISTOR DTC143EK Q192 8-729-923-80 TRANSISTOR DTC143EK Q192 8-729-923-80 TRANSISTOR DTC143EK Q193 8-729-923-80 TRANSISTOR DTC143EK Q193 8-729-923-80 TRANSISTOR DTC143EK Q193 8-729-923-80 TRANSISTOR DTC143EK Q195 1-410-386-11 INDUCTOR CHIP 27uH (AEP, UK) Q194 8-729-923-80 TRANSISTOR DTC143EK Q195 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) Q194 8-729-923-80 TRANSISTOR DTC143EK Q195 8-729-923-80 TRANSISTOR DTC143EK Q195 8-729-923-80 TRANSISTOR DTC143EK					1	-			
Q192 8-729-923-80 TRANSISTOR DTC143EK					l	•			
L704 1-410-382-31 INDUCTOR CHIP 12uH Q193 8-729-923-80 TRANSISTOR DTC143EK L705 1-410-386-11 INDUCTOR CHIP 27uH (AEP, UK) L705 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) Q194 8-729-923-80 TRANSISTOR DTC143EK L706 1-410-387-11 INDUCTOR CHIP 33uH (AEP, UK) Q195 8-729-923-80 TRANSISTOR DTC143EK					ĺ	-			
L705 1-410-386-11 INDUCTOR CHIP 27uH (AEP, UK) L705 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) L706 1-410-387-11 INDUCTOR CHIP 33uH (AEP, UK) Q194 8-729-923-80 TRANSISTOR DTC143EK Q195 8-729-923-80 TRANSISTOR DTC143EK	L704	1-410-382-31	INDUCTOR CHIP	12uH		-			
L705 1-410-387-11 INDUCTOR CHIP 33uH (US, Canadian) Q194 8-729-923-80 TRANSISTOR DTC143EK L706 1-410-387-11 INDUCTOR CHIP 33uH (AEP, UK) Q195 8-729-923-80 TRANSISTOR DTC143EK						•			
L706 1-410-387-11 INDUCTOR CHIP 33uH (AEP, UK) Q195 8-729-923-80 TRANSISTOR DTC143EK)	Q194	8-729-923-80	TRANSISTOR	DTC143EK
L706 1-410-388-31 INDUCTOR CHIP 39uH (US, Canadian) Q251 8-729-107-46 TRANSISTOR 2SC3624A-L15									
	L706	1-410-388-31	INDUCTOR CHIP	39uH (US, Canadian))	Q251	8-729-107-46	TRANSISTOR	2SC3624A-L15

Ref. No.	Part No.	Description		Remark	Ref. No.	Part No.	Description	_	Remark
Q252	8-729-107- 4 6	TRANSISTOR	2SC3624A-L15		Q423	8-729-120-28	TRANSISTOR	2SC1623-L5L6	
Q261	8-729-923-80		DTC143EK		Q441	8-729-901-47	TRANSISTOR	DTA143EK	
Q271	8-729-107-46	TRANSISTOR	2SC3624A-L15		Q451	8-729-120-28	TRANSISTOR	2SC1623-L5L6	
Q272	8-729-107-46		2SC3624A-L15		Q452	8-729-120-28	TRANSISTOR	2SC1623-L5L6	
Q281	8-729-120-28		2SC1623-L5L6		Q453	8-729-120-28	TRANSISTOR	2SC1623-L5L6	
กรอร	8-729-120-28	TDANGICTOD	2SC1623-L5L6	*	Q471	8-729-120-28	TRANSISTOR	2SC1623-L5L6	
Q282	8-729-216-22		2SA1162-G		Q471 Q472	8-729-120-28		2SC1623-L5L6	
Q283					Q472 Q473	8-729-120-28		2SC1623-L5L6	
Q291	8-729-901-01		DTC144EK		Q473 Q491	8-729-120-28		2SC1623-L5L6	
Q331	8-729-120-28		2SC1623-L5L6		Q491 Q492	8-729-120-28		2SC1623-L5L6	
Q332	8-729-120-28	TRANSISTUR	2SC1623-L5L6		Q432	0-723 120 20	TIMINOTOTOTI	2501025 2520	
Q333	8-729-120-28		2SC1623-L5L6		Q501	8-729-120-28		2SC1623-L5L6	
Q334	8-729-120-28		2SC1623-L5L6		Q502	8-729-120-28		2SC1623-L5L6	
Q335	8-729-216-22		2SA1162-G		Q503	8-729-120-28		2SC1623-L5L6	
Q341	8-729-120-28		2SC1623-L5L6		Q504	8-729-901-47		DTA143EK	
Q342	8-729-120-28	TRANSISTOR	2SC1623-L5L6	1	Q531	8-729-120-28	TRANSISTOR	2SC1623-L5L6	
Q343	8-729-120-28		2SC1623-L5L6		Q532	8-729-120-28		2SC1623-L5L6	
Q344	8-729-120-28	TRANSISTOR	2SC1623-L5L6		Q533	8-729-120-28	TRANSISTOR	2SC1623-L5L6	
Q345	8-729-216-22		2SA1162-G		Q534	8-729-120-28	TRANSISTOR	2SC1623-L5L6	
Q351	8-729-120-28	TRANSISTOR	2SC1623-L5L6		Q535	8-729-120-28	TRANSISTOR	2SC1623-L5L6	
Q352	8-729-120-28	TRANSISTOR	2SC1623-L5L6		Q536	8-729-120-28	TRANSISTOR	2SC1623-L5L6	
Q353	8-729-120-28	ROTZIZNAST	2SC1623-L5L6		Q537	8-729-120-28	TRANSISTOR	2SC1623-L5L6	
Q354	8-729-120-28		2SC1623-L5L6		Q541	8-729-120-28		2SC1623-L5L6	
Q355	8-729-216-22		2SA1162-G		Q542	8-729-120-28		2SC1623-L5L6	
	8-729-120-28		2SC1623-L5L6		Q543	8-729-120-28		2SC1623-L5L6	
Q361 Q362	8-729-120-28		2SC1623-L5L6		Q544	8-729-120-28		2SC1623-L5L6	
0000	0.700.100.00	TOANGIGTOD	2001022 1516		Q545	8-729-120-28	TDANC I CTOD	2SC1623-L5L6	
Q363	8-729-120-28		2SC1623-L5L6		Q543 Q551	8-729-120-28		2SC1623-L5L6	
Q364	8-729-120-28		2SC1623-L5L6		Q552	8-729-216-22		2SA1162-G	
Q365	8-729-216-22		2SA1162-G	-	Q553	8-729-120-28		2SC1623-L5L6	
Q371	8-729-120-28		2SC1623-L5L6		Q554	8-729-120-28		2SC1623-L5L6	
Q372	8-729-120-28	3 TRANSISTUR	2SC1623-L5L6		4004	0-129-120-20	NOTETENBRIT (2301023-6360	
Q373	8-729-120-28		2SC1623-L5L6		Q581	8-729-216-22		2SA1162-G	
Q374	8-729-120-28	3 TRANSISTOR	2SC1623-L5L6		Q582	8-729-120-28		2SC1623-L5L6	
Q375	8-729-216-22	TRANSISTOR	2SA1162-G		Q591	8-729-120-28		2SC1623-L5L6	
Q381	8-729-120-28	3 TRANSISTOR	2SC1623-L5L6		Q592	8-729-120-28	TRANSISTOR	2SC1623-L5L6	
Q382	8-729-120-28	3 TRANSISTOR	2SC1623-L5L6		Q603	8-729-120-28	REPRESENTATION TO THE PROPERTY OF THE PROPERTY	2SC1623-L5L6	
Q383	8-729-120-28	3 TRANSISTOR	2SC1623-L5L6		Q604	8-729-120-28	TRANSISTOR	2SC1623-L5L6	
Q384	8-729-120-28		2SC1623-L5L6		Q605	8-729-120-28		2SC1623-L5L6	
Q385	8-729-216-22		2SA1162-G		Q606	8-729-120-28	TRANSISTOR	2SC1623-L5L6	
Q401	8-729-120-28		2SC1623-L5L6		Q621	8-729-120-28	TRANSISTOR	2SC1623-L5L6	
Q402	8-729-120-28		2SC1623-L5L6		Q622	8-729-120-28	R TRANSISTOR	2SC1623-L5L6	
Q403	8-729-216-22	AULTINAUL C	2SA1162-G		Q623	8-729-216-22	TRANSISTOR	2SA1162-G	
Q403 Q404	8-729-120-28		2SC1623-L5L6		Q624	8-729-120-28		2SC1623-L5L6	
Q404 Q405		B TRANSISTOR	2SC1623-L5L6		Q625	8-729-120-28		2SC1623-L5L6	
-			2SC1623-L5L6		Q625 Q626	8-729-120-28		2SC1623-L5L6	
Q406 Q407		8 TRANSISTOR 8 TRANSISTOR	2SC1623-L5L6 2SC1623-L5L6		Q627	8-729-120-28		2SC1623-L5L6	
4									
Q408		D TRANSISTOR	DTC143EK		Q628	8-729-923-80		DTC143EK	
Q409		D TRANSISTOR	DTC143EK		Q671	8-729-101-07		2SB798-DL	
Q421		B TRANSISTOR	2SC1623-L5L6		Q672	8-729-923-80		DTC143EK	
Q422	8-729-120-2	8 TRANSISTOR	2SC1623-L5L6		Q701	8-729-120-28	B TRANSISTOR	2SC1623-L5L6	

Ref. No.	Part No.	Description		Remark	Ref. No.	Part No.	Descri	iption			Remark
Q702	8-729-120-28	TRANSISTOR	2SC1623-L5L6		Q965	8-729-120-28	TRANS	STOR	2SC1623-	1.51.6	
Q703	8-729-120-28		2SC1623-L5L6		Q966	8-729-120-28			2SC1623-		
Q704	8-729-120-28		2SC1623-L5L6		Q967	8-729-120-28			2SC1623-		
Q705	8-729-120-28		2SC1623-L5L6		Q968	8-729-120-28			2SC1623-		
Q706	8-729-120-28		2SC1623-L5L6		Q969	8-729-216-22			2SA1162-		
Q100	0 723 120 20	Hemoldion	2501020 2020		4303	0 723 210 22	TIGHO!	DIOIL	LONITUL	u	
Q707	8-729-120-28	TRANSISTOR	2SC1623-L5L6		Q981	8-729-120-28	TRANS	STOR	2SC1623-	L5L6	
Q708	8-729-120-28	TRANSISTOR	2SC1623-L5L6		Q982	8-729-120-28	TRANS	ISTOR	2SC1623-	L5L6	
Q709	8-729-923-80	TRANSISTOR	DTC143EK		Q983	8-729-120-28	TRANS	ISTOR	2SC1623-	L5L6	
Q801	8-729-120-28	TRANSISTOR	2SC1623-L5L6		Q984	8-729-120-28	TRANS	STOR	2SC1623-	L5L6	
Q802	8-729-900-53	TRANSISTOR	DTC114EK		Q985	8-729-216-22	TRANSI	STOR	2SA1162-	G	
Q803	8-729-901-01		DTC144EK				< RES	STOR >			
Q804	8-729-901-01	TRANSISTOR	DTC144EK								
Q811	8-729-901-47		DTA143EK		R001	1-208-755-11	METAL	GLAZE	75	0.50%	1/10W
Q812	8-729-901-47	TRANSISTOR	DTA143EK		R002	1-208-755-11	METAL	GLAZE	75	0.50%	1/10W
Q813	8-729-901-47	TRANSISTOR	DTA143EK		R003	1-208-755-11			75	0.50%	1/10W
					R004	1-208-755-11	METAL	GLAZE	75	0.50%	1/10W
Q814	8-729-901-47	TRANSISTOR	DTA143EK		R005	1-208-755-11	METAL	GLAZE	75	0.50%	1/10W
Q815	8-729-901-47	TRANSISTOR	DTA143EK								
Q816	8-729-901-47	TRANSISTOR	DTA143EK		R006	1-208-755-11	METAL	GLAZE	75	0.50%	1/10W
Q831	8-729-900-53	TRANSISTOR	DTC114EK		R007	1-208-755-11	METAL	GLAZE	75	0. 50%	1/10W
Q832	8-729-901-01	TRANSISTOR	DTC144EK		R008	1-208-755-11			75	0.50%	
,					R009	1-208-755-11			75		1/10W
Q833	8-729-900-53	TRANSISTOR	DTC114EK		R010	1-208-755-11			75		1/10W
Q834	8-729-901-01		DTC144EK								-,
Q835	8-729-900-53		DTC114EK		R011	1-208-755-11	METAL.	GLAZE	75	0. 50%	1/10 W
Q836	8-729-901-01		DTC144EK	i i	R012	1-208-755-11			75	0. 50%	
Q881	8-729-140-47		2SC3735-L-B35		R013	1-216-041-00			470		1/10W
•					R014	1-216-049-00			1K		1/10W
Q882	8-729-140-47	TRANSISTOR	2SC3735-L-B35	İ	R015	1-216-049-00			1K		1/10W
Q883	8-729-140-47		2SC3735-L-B35		11010	1 210 010 00		01111	211	070	1/ 1011
Q898	8-729-901-47		DTA143EK		R016	1-216-081-00	METAL.	CHIP	22K	5%	1/10W
Q899	8-729-901-47		DTA143EK		R017	1-216-081-00			22K		1/10W
Q901	8-729-120-28		2SC1623-L5L6		R018	1-216-065-00			4. 7K		1/10W
QUUI	0 .20 120 20	TIUM DION	2001020 8080		R019	1-216-049-00			1K		1/10W
Q902	8-729-120-28	TRANSISTOR	2SC1623-L5L6		R020	1-216-041-00			470		1/10W
Q903	8-729-120-28		2SC1623-L5L6			1 210 011 00			1.0	•	1, 10"
Q904	8-729-120-28		2SC1623-L5L6		R021	1-216-065-00	METAL.	CHIP	4. 7K	5%	1/10W
Q905	8-729-216-22		2SA1162-G		R022	1-216-073-00			10K		1/10W
Q917	8-729-120-28		2SC1623-L5L6		R023	1-208-782-11			1K	0. 50%	
~			2011020 2020		R024	1-208-782-11			1K	0. 50%	
Q918	8-729-120-28	TRANSISTOR	2SC1623-L5L6		R025	1-208-782-11			1K	0. 50%	
Q919	8-729-120-28		2SC1623-L5L6		NOLO	1 200 702 11	MUITID	GBMEL	. 111	0.00%	1/ 1011
Q920	8-729-120-28		2SC1623-L5L6		R026	1-216-045-00	METAI	CHIP	680	5%	1/10W
Q921	8-729-216-22		2SA1162-G		R027	1-208-800-11				0. 50%	
Q933	8-729-120-28		2SC1623-L5L6		R028	1-216-065-00			4. 7K		1/10W
Q333	0 723 120 20	TIMIBISION	2301023 L3L0		R029	1-216-065-00			4. 7K		1/10W
Q934	8-729-120-28	GOT21 PAAGT	2SC1623-L5L6		R030						
Q935	8-729-120-28				กบอบ	1-216-041-00	METAL	Unir	470	5%	1/10W
Q936			2SC1623-L5L6		D091	1_916_040.00	METAI	מונים	11/	E@	1 /10W
-	8-729-120-28		2SC1623-L5L6	,	R031	1-216-049-00			1K		1/10W
Q937	8-729-216-22		2SA1162-G			1-216-049-00			1K	5% 5%	1/10W
Q949	8-729-120-28	NU1616NAN1	2SC1623-L5L6		R033	1-216-081-00			22K		1/10W
0050	0 700 100 00	TOANGTOTOD	0001600 1516		R034	1-216-081-00			22K		1/10W
Q950	8-729-120-28		2SC1623-L5L6		R035	1-216-041-00	METAL	CHIP	470	5%	1/10W
Q951	8-729-120-28		2SC1623-L5L6		2000	4 040 007 57	.enm		4	F4:	4 44 000
Q952	8-729-120-28		2SC1623-L5L6		R036	1-216-065-00			4. 7K		1/10W
Q953	8-729-216-22	TRANSTSTUR	2SA1162-G	l	R037	1-216-049-00	METAL	CHIL	1K	5%	1/10W

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Descr	iption			Remark
R038	 1-216-041-00	METAL CHIP	470	5%	1/10W	R084	1-216-029-00	METAL	CHIP	150	5%	1/10W
R039	1-216-065-00	METAL CHIP	4. 7K		1/10W	R085	1-216-029-00	METAL	CHIP	150	5%	1/10W
R040	1-216-073-00		10K	5%	1/10W	R086	1-216-049-00	METAL	CHIP	1K	5%	1/10W
R041	1-208-782-11		1K	0.50%	1/10W	R087	1-216-049-00	METAL	CHIP	1K	5%	1/10W
R042	1-208-782-11		1K		1/10W	R091	1-208-830-11	METAL	GLAZE	100K	0. 50%	1/10W
R043	1-208-782-11	METAL GLAZE	1K	0. 50%	: 1/10W	R092	1-208-830-11	METAL	GLAZE	100K	0. 50%	1/10W
R044	1-216-045-00	METAL CHIP	680	5%	1/10W	R093	1-216-091-00	METAL	CHIP	56K	5%	1/10W
R045	1-208-800-11		5. 6K	0.50%	1/10W	R094	1-216-073-00	METAL	CHIP	10K	5%	1/10W
R046	1-216-065-00	METAL CHIP	4. 7K	5%	1/10W	R095	1-216-041-00	METAL	CHIP	470	5%	1/10W
R047	1-216-065-00	METAL CHIP	4. 7K	5%	1/10W	R096	1-216-097-00	METAL	CHIP	100K	5%	1/10W
R048	1-216-041-00	METAL CHIP	470	5%	1/10W	R097	1-216-097-00	METAL	CHIP	100K	5%	1/10W
R050	1-216-073-00		10K	5%	1/10W	R101	1-208-838-11	METAL	GLAZE	220K	0.50%	1/10W
		(US, Canadian)				R102	1-208-826-11	METAL	GLAZE	68K	0.50%	1/10W
R051	1-216-295-91	METAL GLAZE	0	5%	1/10W	R103	1-208-826-11	METAL	GLAZE	68K	0.50%	1/10W
		(US, Canadian)				R104	1-208-826-11	METAL	GLAZE	68K	0.50%	1/10W
R052	1-216-295-91		0	5%	1/10W							
		(US, Canadian)	_	-	-,	R105	1-208-838-11	METAL	GLAZE	220K	0.50%	1/10W
R060	1-216-025-00		100	5%	1/10W	R106	1-208-826-11	METAL	GLAZE	68K	0. 50%	1/10W
		(AEP, UK)			,	R107	1-208-826-11	METAL	GLAZE	68K	0. 50%	1/10W
		` , ,				R108	1-208-826-11	METAL	GLAZE	68K		1/10W
R061	1-216-085-00		33K	5%	1/10W	R109	1-208-838-11	METAL	GLAZE	220K	0. 50%	1/10₩
2000	4 040 050 00	(AEP, UK)	4.017		4 44 000	D440	1 000 000 11	MCMAI	CL ARE	COV	0 500	1 /100
R062	1-216-073-00		10K	5%	1/10W	R110	1-208-826-11			68K		1/10W
		(AEP, UK)		=0.	4 4 0 111	R111	1-208-826-11			68K		1/10W
R063	1-216-121-00		1M	5%	1/10W	R112	1-208-826-11			68K		1/10W
		(AEP, UK)				R113	1-208-838-11				0.50%	-
R064	1-208-826-11	METAL GLAZE (AEP, UK)	68K	0. 50%	1/10W	R114	1-208-826-11	METAL	GLAZE	68K	0. 50%	1/10W
R065	1-216-295-91	METAL GLAZE	0	5%	1/10W	R115	1-208-826-11	METAL	GLAZE	68K	0.50%	1/10W
		(AEP, UK)				R116	1-208-826-11	METAL	GLAZE	68K	0.50%	1/10W
						R117	1-208-838-11	METAL	GLAZE	220K	0.50%	1/10W
R066	1-216-065-00	METAL CHIP	4. 7K	5%	1/10W	R118	1-208-826-11	METAL	GLAZE	68K	0.50%	1/10W
		(AEP, UK)				R119	1-208-826-11	METAL	GLAZE	68K	0.50%	1/10W
R067	1-216-295-91		0	5%	1/10W	D4.00	1 000 000 11	MEMAI	01 400	0.017	0 50%	4 /4 055
B0.00		(AEP, UK)	417	m a.	4 /4 007	R120	1-208-826-11			68K		1/10W
R068	1-216-049-00		1K	5%	1/10W	R121	1-208-838-11				0. 50%	
2000	4 000 000 44	(AEP, UK)	0017		4 (4 0)	R122	1-208-826-11			68K		1/10W
R069	1-208-826-11		68K	U. 5U%	1/10W	R123	1-208-826-11			68K		1/10₩
D070	1 210 001 00	(AEP, UK)	วาน	E0/	1 /10W	R124	1-208-826-11	METAL	GLAZE	68K	0.50%	1/10W
R070	1-216-081-00	METAL CHIP	22K	5%	1/10W	D195	1 200 020 11	MCTAI	CI AZE	ววกห	0. 50%	1 /109
D071	1 910 001 00	MCTAL CUID	ากห	E@	1 /10W	R125	1-208-838-11					•
R071	1-216-081-00		22K	5% ===	1/10W	R126 R127	1-208-826-11 1-208-826-11			68K		1/10\ 1/10\
R072	1-216-081-00		22K	5% =~	1/10W	R127				68K		
R073 R074	1-216-081-00		22K	5% = 0*	1/10W	R129	1-208-826-11 1-208-838-11			68K 220K		1/10W
R074	1-216-081-00		22K	5%	1/10W	RIZS	1-200-030-11	MCIAL	GLAZE	ZZUN	U. JU%	1/10W
nu/o	1-216-081-00	MEIAL UNIP	22K	5%	1/10W	R130	1-208-826-11	METAI	CI AZE	68K	ก รกช	1/10W
R076	1-216-081-00	METAL CHID	22K	5%	1/10W	R131	1-208-826-11			68K		1/10W
R077	1-216-081-00		22K	5%	1/10W	R132	1-208-826-11			68K		1/10W
R078	1-216-121-00		1M	5%	1/10W	R141	1-216-065-00			4. 7K	5%	1/10W
R079	1-216-121-00		1M	5%	1/10W	R141	1-216-065-00			4. 7K		1/10\\ 1/10\\
R080	1-216-057-00		2. 2K		1/10W	. 1142	1 210 000 00	mu I Nb	AIIII	7. /11	U/U	1/ 1011
11000	1 210 001 00	WEIGE VIIII	<i>L.</i> 41\	J/I)	1/ 1011	R143	1-216-073-00	METAI	CHIP	10K	5%	1/10W
R081	1-208-755-11	METAL CLASE	75	በ 50%	1/10W	R143	1-216-073-00			10K	5%	1/10W
R082	1-208-755-11		75		1/10W	R144	1-216-073-00			10K	5%	1/10W
R083	1-208-755-11		75 75			R145	1-216-073-00			10K	5%,	
ແບບນ	1-400-700-11	METAL GLAVE	73	u. 3U%)	1/10W	1 R140	1-710-019-00	mC 1 AL	VIIIF	TOV	JA	1/10W

Ref. No.	Part No.	Descr	iption			Remark	Ref. No.	Part No.	D	escr.	iption			Remark
R151	1-208-838-11	METAL	GLAZE	220K	0. 50%	1/10W	R244	1-208-800	- 0-11 M	ETAL	GLAZE	5. 6K	0. 50%	1/10W
R152	1-208-826-11			68K		1/10W	R245	1-216-065				4. 7K		1/10W
R153	1-208-826-11			68K		1/10W	R246	1-216-065				4. 7K		1/10W
R154	1-208-826-11			68K		1/10W	R247	1-216-065				4. 7K		1/10W
R155	1-208-838-11				0. 50%		R248	1-208-800					0. 50%	
						-,								-,
R156	1-208-826-11	METAL	GLAZE	68K	0.50%	1/10W	R249	1-208-801	-11 M	ETAL	GLAZE	6. 2K	0.50%	1/10W
R157	1-208-826-11	METAL	GLAZE	68K	0.50%	1/10W	R250	1-216-065	-00 M	ETAL	CHIP	4. 7K	5%	1/10W
R158	1-208-826-11	METAL	GLAZE	68K	0.50%	1/10W	R251	1-216-041	-00 M	ETAL	CHIP	470	5%	1/10W
R159	1-216-073-00	METAL	CHIP	10K	5%	1/10W	R252	1-208-838	3-11 M	ETAL	GLAZE	220K	0.50%	1/10W
R161	1-216-065-00	METAL	CHIP	4. 7K	5%	1/10W	R253	1-216-065	-00 M	ETAL	CHIP	4. 7K	5%	1/10W
R162	1-216-065-00	METAL	CHIP	4. 7K	5%	1/10₩	R254	1-216-041	00 M	ETAL	CHIP	470	5%	1/10W
R163	1-216-065-00	METAL	CHIP	4. 7K		1/10W	R255	1-208-838	3-11 M	ETAL	GLAZE		0.50%	-
R164	1-216-065-00	METAL	CHIP	4. 7K		1/10₩	R256	1-216-065	i-00 M	ETAL	CHIP	4. 7K		1/10W
R165	1-216-065-00	METAL	CHIP	4. 7K	5%	1/10W	R261	1-208-830	11 M	ETAL	GLAZE	100K	0.50%	1/10₩
R166	1-216-065-00	METAL	CHIP	4. 7K	5%	1/10W	R262	1-208-830)-11 M	ETAL	GLAZE	100K	0.50%	1/10W
R171	1-216-065-00			4. 7K		1/10W	R263	1-208-830					0.50%	
R172	1-216-065-00			4. 7K		1/10W	R264	1-208-830					0.50%	
R173	1-216-065-00			4. 7K		1/10W	R265	1-208-830					0.50%	•
R174	1-216-041-00			470	5%	1/10W	R266	1-208-830					0. 50%	
R175	1-216-065-00	METAL	CHIP	4. 7K	5%	1/10W	R267	1-208-830	J-11 M	ETAL	GLAZE	100K	0.50%	1/1UW
R176	1-208-838-11	METAL	GI A7F	22NK	0. 50%	1/10W	R268	1-208-830)-11 M	FTAL	GLA7F	100K	0. 50%	1/10W
R177	1-216-065-00			4. 7K		1/10W	R269	1-216-073				10K	5%	1/10W
R178	1-216-065-00			4. 7K		1/10W	R271	1-216-041				470	5%	1/10W
R179	1-216-065-00			4. 7K		1/10W	R272	1-208-838					0.50%	
R180	1-216-041-00			470	5%	1/10W	R273	1-216-065				4. 7K		1/10W
						•								·
R181	1-216-065-00	METAL	CHIP	4. 7K	5%	1/10W	R274	1-216-041	-00 M	ETAL	CHIP	470	5%	1/10W
R182	1-208-838-11	METAL	GLAZE		0.50%	1/10W	R275	1-208-838	3-11 M	ETAL	GLAZE		0. 50%	1/10W
R183	1-216-065-00	METAL	CHIP	4. 7K	5%	1/10W	R276	1-216-065	-00 M	ETAL	CHIP	4. 7K	5%	1/10W
R184	1-216-065-00	METAL	CHIP	4. 7K	5%	1/10W	R281	1-216-065	-00 M	ETAL	CHIP	4. 7K	5%	1/10W
R185	1-216-065-00	METAL	CHIP	4. 7K	5%	1/10W	R282	1-216-065	-00 M	ETAL	CHIP	4. 7K	5%	1/10W
D100	1 010 041 00	METAT	CUID	470	FΦ	1 /1 OW	Dogg	1 010 070		CWA1	OHED	107	ΓOV	1 /100
R186	1-216-041-00			470	5% ==	1/10W	R283	1-216-073				10K 1M	5% 5%	1/10W
R187 R188	1-216-065-00 1-208-838-11			4. 7K	0. 50%	1/10W	R284 R285	1-216-121 1-216-073				10K	5%	1/10W 1/10W
R189	1-216-065-00			4. 7K			R286	1-210-073				68K		1/10\\
R199	1-216-065-00			4. 7K		1/10W 1/10W	R291	1-216-073				10K	0. 30% 5%	1/10W
N130	1-210-003-00	METAL	UIIIF	4. 71	JA	1/10#	17231	1-410-073	I UU MI	LIAL	UIII	101	3/0	1/10#
R191	1-216-065-00	METAL	CHIP	4. 7K	5%	1/10W	R292	1-216-073	-00 M	ETAL	CHIP	10K	5%	1/10₩
R192	1-216-041-00			470	5%	1/10W	R293	1-216-073				10K	5%	1/10W
R193	1-216-065-00			4. 7K	5%	1/10W	R294	1-208-826				68K		1/10W
R194	1-208-838-11			220K	0.50%		R295	1-208-802				6. 8K	0. 50%	
R204	1-208-814-11			22K		1/10W	R296	1-208-826				68K		1/10W
R205	1-208-814-11			22K		1/10W	R297	1-208-826				68K		1/10W
R206	1-208-802-11			6. 8K	0.50%		R301	1-208-826				68K		1/10₩
R207	1-208-838-11			220K	0.50%		R302	1-216-081				22K	5%	1/10W
R231	1-216-041-00			470	5%	1/10W	R303	1-216-041				470	5%	1/10W
R232	1-216-041-00	METAL	CHIP	470	5%	1/10W	R304	1-216-033	-00 M	ETAL	CHIP	220	5%	1/10W
R233	1-208-802-11	METAI	GI.AZF	6 8K	0. 50%	1/10W	R305	1-216-057	'-00 M	ETAI.	CHIP	2. 2K	5%	1/10W
R241	1-216-065-00			4. 7K		1/10W	R306	1-208-788					0.50%	
R242	1-216-065-00			4. 7K		1/10W	R307	1-208-790					0.50%	
R243	1-216-065-00			4. 7K		1/10W	R308	1-216-057				2. 2K		1/10W
10	_ 210 000 00	risu	VIII.	/ 11	0.0	-,	, 1000	1 210 001	00 111		71121	J. 211	0.0	-/ 10"

Ref. No.	Part No.	Descri	ption			Remark	Ref. No.	Part No.	Descr	iption			Remark
R309	1-216-041-00	METAL	CHIP	470	5%	1/10W	R358	1-216-041-00	METAL	CHIP	470	5%	1/10W
R310	1-216-041-00			470	5%	1/10W	R359	1-216-025-00	METAL	CHIP	100	5%	1/10W
R311	1-216-025-00			100	5%	1/10W	R360	1-216-001-00	METAL	CHIP	10	5%	1/10W
R312	1-216-001-00			10	5%	1/10W	R361	1-216-001-00	METAL	CHIP	10	5%	1/10W
R313	1-216-001-00			10		1/10W	R362	1-216-025-00	METAL	CHIP	100	5%	1/10W
5044	4 040 005 00	Neppma I	au a	400	- 	4 /4 000	naca	1 000 700 11	METAL	CLAZE	150	n Enev	1 /100
R314 R315	1-216-025-00 1-208-762-11			100 150	5% 0. 50%	1/10\\ 1/10\\	R363 R364	1-208-762-11 1-216-049-00			150 1K	0.50% 5%	1/10W
R316	1-216-049-00			180 1K		1/10W	R365	1-208-826-11			68K	0.50%	
R317	1-208-826-11			68K	0.50%	•	R366	1-216-081-00			22K		1/10W
R318	1-216-081-00			22K		1/10W	R367	1-216-041-00			470	5%	1/10W
								'				=0.	4 44 000
R319	1-216-041-00			470	5%	1/10W	R368	1-216-033-00			220	5%	1/10W
R320	1-216-033-00			220	5%	1/10W	R369	1-216-057-00			2. 2K		1/10W
R321	1-216-057-00			2. 2K		1/10W	R370	1-208-788-11				0. 50%	-
R322	1-208-788-11	METAL	GLAZE		0.50%	*	R371	1-208-790-11				0.50%	
R323	1-208-790-11	METAL	GLAZE	2. 2K	0. 50%	1/10W	R372	1-216-057-00	METAL	CHIP	2. 2K	5%	1/10W
R324	1-216-057-00	METAL	CHIP	2. 2K	5%	1/10W	R373	1-216-041-00	METAL	CHIP	470	5%	1/10W
R325	1-216-041-00			470	5%	1/10W	R374	1-216-041-00	METAL	CHIP	470	5%	1/10W
R326	1-216-041-00	METAL	CHIP	470	5%	1/10 W	R375	1-216-025-00	METAL	CHIP	100	5%	1/10W
R327	1-216-025-00			100	5%	1/10W	R376	1-216-001-00	METAL	CHIP	10	5%	1/10W
R328	1-216-001-00			10		1/10W	R377	1-216-001-00	METAL	CHIP	10	5%	1/10W
R329	1-216-001-00			10	5%	1/10W	R378	1-216-025-00			100	5%	1/10W
R330	1-216-025-00	METAL	CHIP	100	5%	1/10₩	R379	1-208-762-11			150	0. 50%	
R331	1-208-762-11	METAL	GLAZE	150	0.50%		R380	1-216-049-00			1K	5%	1/10W
R332	1-216-049-00			1K	5%	1/10W	R381	1-208-826-11			68K		1/10W
R333	1-208-826-11	METAL	GLAZE	68K	0. 50%	1/10W	R382	1-216-081-00	METAL	CHIP	22K	5%	1/10W
R334	1-216-081-00	METAL	CHIP	22K	5%	1/10W	R383	1-216-041-00	METAL	CHIP	470	5%	1/10W
R335	1-216-041-00	METAL	CHIP	470	5%	1/10W	R384	1-216-033-00	METAL	CHIP	220	5%	1/10W
R336	1-216-033-00	METAL	CHIP	220	5%	1/10W	R385	1-216-057-00	METAL	CHIP	2. 2K	5%	1/10W
R337	1-216-057-00	METAL	CHIP	2. 2K	5%	1/10W	R386	1-208-788-11	METAL	GLAZE	1. 8K	0.50%	1/10W
R338	1-208-788-11			1. 8K	0.50%	1/10W	R387	1-208-790-11	METAL	GLAZE	2. 2K	0. 50%	1/10₩
Doon	1-208-790-11	METAI	CLATE	2 24	0. 50%	1 /10W	R388	1-216-057-00	METAL	CHIP	2. 2K	5%	1/10₩
R339 R340	1-206-790-11			2. 2K		1/10W	R389	1-216-041-00			470	5%	1/10W
R341	1-216-037-00			470	5%	1/10W	R390	1-216-041-00			470	5%	1/10W
R341	1-216-041-00			470	5%	1/10W	R391	1-216-025-00			100	5%	1/10W
R342				100	5%	1/10W	R392	1-216-001-00			100	5%	1/10W
R343	1-216-025-00	MEIAL	UNIT	100	3/0	1/10#	N352	1 210 001 00	MLIAL	VIIII	10	J/0	1/10#
R344	1-216-001-00	METAL	CHIP	10	5%	1/10₩	R393	1-216-001-00			10	5%	1/10W
R345	1-216-001-00	METAL	CHIP	10	5%	1/10W	R394	1-216-025-00			100	5%	1/10W
R346	1-216-025-00	METAL	CHIP	100	5%	1/10W	R395	1-208-762-11	METAL	GLAZE	150		1/10W
R347	1-208-762-11	METAL	GLAZE	150	0. 50%	1/10W	R396	1-216-049-00			1K	5%	1/10W
R348	1-216-049-00	METAL	CHIP	1K	5%	1/10₩	R397	1-216-027-00	METAL	CHIP	120	5%	1/10W
R349	1-208-826-11	METAI	GLAZE	68K	0. 50%	1/10 W	R398	1-216-027-00	METAI	CHIP	120	5%	1/10W
R350	1-216-081-00			22K	5%	1/10W	R401	1-216-041-00			470	5%	1/10W
R351	1-216-041-00			470	5%	1/10W	R402	1-216-049-00			1K	5%	1/10W
R352	1-216-033-00			220	5%	1/10W	R403	1-216-049-00			1K	5%	1/10W
R353	1-216-057-00			2. 2K		1/10W	R404	1-216-081-00			22K	5%	1/10₩
								4 040 000 0		01117	6611	F04	4 /4 0/5
R354	1-208-788-11				0. 50%		R405	1-216-081-00			22K	5%	1/10W
R355	1-208-790-11				0. 50%		R406	1-216-041-00			470	5%	1/10W
R356	1-216-057-00			2. 2K		1/10W	R407	1-216-057-00			2. 2K		1/10W
R357	1-216-041-00	METAL	CHIP	470	5%	1/10 W	R408	1-216-049-00	METAL	CHIP	1K	5%	1/10W

AV-26P

AV-26U

Re	f. No.	Part No.	Descr	iption			Remark	Ref. No.	Part No.	Descr	iption			Remark
	R409	1-216-041-00	METAL	CHIP	470	5%	1/10W	R458	1-216-057-00	METAL	CHIP	2. 2K	5%	1/10W
	R410	1-216-057-00	METAL	CHIP	2. 2K	5%	1/10W	R459	1-216-073-00	METAL	CHIP	10K	5%	1/10W
	R411	1-216-073-00	METAL	CHIP	10K	5%	1/10W	R460	1-216-065-00			4. 7K		1/10W
	R412	1-216-041-00	METAL	CHIP	470	5%	1/10W	R461	1-216-057-00			2. 2K		1/10W
	R413	1-216-049-00			1K	5%	1/10W	R462	1-216-113-00			470K		1/10W
	D414	1 010 041 00	METAI	GUID	450	50 4	4 /4 000							
	R414 R415	1-216-041-00 1-216-073-00			470 10K	5% 5%	1/10W 1/10W	R463 R464	1-216-121-00 1-216-121-00			1M 1M	5% 5%	1/10W
	R416	1-216-041-00			470	5%	1/10W	R465	1-216-049-00			1K	5%	1/10W
	R417	1-216-057-00			2. 2K	5%	1/10W	R466	1-216-049-00					1/10W
	R418	1-216-041-00			470	5%	1/10W	R467	1-216-049-00			1K 1K	5% 5%	1/10\ 1/10\
				····	1,0	0,0	1,1011	11407	1 210 043 00	MLIAL	OUTI	IN	JA	1/10#
	R419	1-216-049-00			1K	5%	1/10W	R468	1-216-041-00			470	5%	1/10W
	R420	1-216-057-00			2. 2K		1/10W	R469	1-216-057-00			2. 2K	5%	1/10W
	R421	1~216-041-00			470	5%	1/10W	R470	1-216-095-00			82K	5%	1/10W
	R422	1-216-057-00			2. 2K	5%	1/10W	R471	1-216-057-00	METAL	CHIP	2. 2K	5%	1/10W
	R423	1-216-089-91	METAL	GLAZE	47K	5%	1/10W	R472	1-216-689-11	METAL	CHIP	39K	0. 5%	1/10W
J	R424	1-216-073-00	METAL	CHIP	10K	5%	1/10W	R473	1-216-065-00	METAL.	CHIP	4. 7K	5%	1/10W
]	R425	1-216-049-00	METAL	CHIP	1K	5%	1/10W	R474	1-216-041-00			470	5%	1/10W
1	R426	1-216-073-00	METAL	CHIP	10K	5%	1/10W	R475	1-216-049-00			1K	5%	1/10W
I	R427	1-216-041-00	METAL	CHIP	470	5%	1/10W	R476	1-216-081-00			22K	5%	1/10W
j	R428	1-216-049-00	METAL	CHIP	1K	5%	1/10W	R477	1-216-081-00			22K	5%	1/10W
_							· ·						0.0	1, 10,
	R429	1-216-081-00			22K	5%	1/10W	R478	1-216-081-00	METAL	CHIP	22K	5%	1/10W
	R430	1-216-061-00			3. 3K		1/10W	R479	1-216-049-00	METAL	CHIP	1K	5%	1/10W
	R431	1-216-121-00			1M	5%	1/10₩	R480	1-216-113-00			470K	5%	1/10W
	R432	1-216-097-00			100K	5%	1/10W	R481	1-208-782-11	METAL	GLAZE	1K	0.50%	1/10₩
ı	R433	1-216-073-00	METAL	CHIP	10K	5%	1/10W	R483	1-208-782-11	METAL	GLAZE	1K	0.50%	1/10W
I	R434	1-216-073-00	METAL	CHIP	10K	5%	1/10W	R484	1-216-053-00	METAL.	CHIP	1. 5K	5%	1/10W
I	R435	1-216-065-00	METAL	CHIP	4. 7K	5%	1/10W	R485	1-216-097-00			100K		1/10W
I	R436	1-216-025-00	METAL	CHIP	100	5%	1/10W	R486	1-216-295-91			0	5%	1/10W
ŀ	R437	1-216-049-00			1K	5%	1/10W	R487	1-216-295-91			0	5%	1/10W
F	R438	1-216-049-00	METAL	CHIP	1K	5%	1/10W	R488	1-216-065-00			4. 7K		1/10W
_													·	-,
		1-216-025-00			100	5%	1/10W	R490	1-216-075-00			12K	5%	1/10W
		1-216-049-00			1K	5%	1/10W	R491	1-208-788-11	METAL	GLAZE	1. 8K	0.50%	1/10W
		1-216-049-00			1K	5%	1/10W			(AEP, U	K)			
		1-216-025-00			100	5%	1/10W	R491	1-216-051-00	METAL	CHIP	1. 2K	5%	1/10W
ŀ	R443	1-216-049-00	METAL	CHIP	1K	5%	1/10W				nadian)			
F	R444	1-216-049-00	MFTAI	снір	1K	5%	1/10W	R492	1-208-789-11			2K	0.50%	1/10W
		1-216-049-00			1K	5%	1/10W	0402		(AEP, U		0.01/	rov.	1 /1 (10)
		1-216-075-00				5%		R492	1-216-061-00			3. 3K	5%	1/10W
		1-216-113-00			12K		1/10W			(US, Ca	nadian)			
		1-216-099-00			470K 120K	5% 5%	1/10W	DADO	1 010 007 00 1	MEGAL	OULD.	0 01/	E0.	4 /4 000
11	1110	1 210 033 00 1	nLIAL 1	UIIIT	1201	J/n	1/10W	R493 R494	1-216-057-00 I 1-216-073-00 I			2. 2K 10K	5% 5%	1/10W 1/10W
R	1449	1-216-057-00	METAL (CHIP	2. 2K	5%	1/10W	R495	1-216-065-00			4. 7K		1/10W
		1-216-049-00			1K	5%	1/10W	R496	1-216-057-00			2. 2K		1/10W
R		1-216-295-91			0	5%	1/10W	R497	1-216-065-00			4. 7K		1/10W
		1-208-802-11				0. 50%			. 210 000 00 1	AD ICID		T. / II	J.A)	1/ 1011
		1-216-061-00			3. 3K		1/10W	R498	1-216-065-00 1	METAL (CHIP	4. 7K	5%	1/10W
							•	R499	1-216-081-00			22K		1/10W
R	454	1-216-101-00	METAL (CHIP	150K	5%	1/10W	R500	1-216-049-00 N			1K		1/10W
		1-216-065-00			4. 7K		1/10W	R501	1-216-065-00 h					1/10W
		1-216-051-00			1. 2K		1/10W	R502	1-216-295-91 N			4. /n 0		1/10W
		1-216-061-00			3. 3K		1/10W	11302	1 210.230 31 N	BEIND (NUUPL	U	J/0	1/10#
						2.1 M	-,	1						

Ref. No.	Part No.	Descr	iption			Remark	Ref. No.	Part No.	Descr	iption			Remark
R503	1-216-041-00	METAL	CHIP	470	5%	1/10W	R554	- 	METAL	CHIP	470	5%	1/10W
R506	1-216-041-00			470	5%	1/10₩	R555	1-216-073-0	METAL	CHIP	10K	5%	1/10W
R507	1-216-041-00			470		1/10W	R556	1-216-057-0			2. 2K	5%	1/10W
R508	1-216-049-00			1K		1/10W	R557	1-216-041-0			470	5%	1/10W
R509	1-208-789-11			2K	0. 50%		R558	1-216-041-0			470	5%	1/10W
						•							
R510	1-208-789-11	METAL	GLAZE	2K	0.50%	1/10W	R559	1-216-073-0	O METAL	CHIP	10K	5%	1/10W
R511	1-208-782-11	METAL	GLAZE	1K	0.50%	1/10W	R560	1-216-049-0	O METAL	ÇHIP	1K	5%	1/10W
R512	1-208-789-11	METAL	GLAZE	2K	0.50%	1/10W	R561	1-216-073-0	O METAL	CHIP	10K	5%	1/10W
R513	1-208-782-11	METAL	GLAZE	1K	0.50%	1/10W	R562	1-216-041-0	O METAL	CHIP	470	5%	1/10W
R514	1-208-789-11	METAL	GLAZE	2K	0. 50%	1/10W	R563	1-216-041-0	O METAL	. CHIP	470	5%	1/10W
							2504	4 000 500 4	4 1407141	OI LEE	017	0 50%	4 /4 018
R515	1-208-782-11			1K	0. 50%		R564	1-208-789-1			2K	0.50%	
R516	1-208-789-11			2K		1/10W	R565	1-208-789-1			2K	0.50%	
R517	1-208-782-11			1K		1/10W	R566	1-208-782-1			1K	0.50%	
R518	1-208-789-11			2K		1/10W	R567	1-208-789-1			2K	0.50%	
R519	1-208-782-11	METAL	GLAZE	1 K	0. 50%	1/10W	R568	1-208-782-1	I METAL	. GLAZE	1K	0. 50%	1/10W
R520	1-208-789-11	METAL.	GLAZE	2K	0. 50%	1/10W	R569	1-208-789-1	1 METAL	GLAZE	2K	0. 50%	1/10 W
R521	1-208-789-11			2K		1/10W	R570	1-208-782-1			1K		1/10W
R522	1-208-789-11			2K		1/10W	R571	1-208-789-1			2K	0.50%	1/10W
R523	1-208-782-11			1K		1/10W	R572	1-208-782-1			1K	0.50%	1/10W
R524	1-208-789-11			2K		1/10W	R573	1-208-789-1			2K		1/10W
1.021	1 200 700 11		ODILL		0. 00.0	27 20							-,
R525	1-208-782-11	METAL	GLAZE	1K	0.50%	1/10W	R574	1-208-782-1	1 METAL	GLAZE	1K	0.50%	1/10W
R526	1-208-789-11	METAL	GLAZE	2K	0.50%	1/10W	R575	1-208-789-1	1 METAL	GLAZE	2K	0.50%	1/10W
R527	1-208-782-11	METAL	GLAZE	1K	0.50%	1/10W	R576	1-208-789-1	1 METAL	GLAZE	2K	0.50%	1/10W
R528	1-208-789-11	METAL	GLAZE	2K	0.50%	1/10W	R577	1-208-789-1	1 METAL	GLAZE	2K	0.50%	1/10W
R529	1-208-782-11	METAL	GLAZE	1K	0.50%	1/10W	R578	1-208-782-1	1 METAL	GLAZE	1K	0.50%	1/10W
DEOD	1 900 700 11	METAL	CLATE	าห	n Enev	1 /1 OW	R579	1-208-789-1	1 ነውሞል፤	CL A7F	2K	0.50%	1/10W
R530 R531	1-208-789-11			2K 1K		1/10W 1/10W	R580	1-208-783-1			2K 1K		1/10W
R532	1-208-782-11			2K		1/10W	R581	1-208-789-1			2K		1/10W
R532	1-208-789-11 1-216-049-00			2K 1K	5%	1/10W	R582	1-208-782-1			1K		1/10W
R534	1-216-049-00			4. 7K		1/10W	R583	1-208-789-1			2K		1/10W
NJ34	1-210-003-00	METAL	OHIT	4. /1	J/n	1/10#	11303	1 200 703 1	I MLIM	J GLINEL	211	0. 00%	1/10"
R535	1-216-041-00	METAL	CHIP	470	5%	1/10W	R584	1-208-782-1	1 METAI	GLAZE	1K	0.50%	1/10W
R536	1-216-041-00	METAL	CHIP	470	5%	1/10W	R585	1-208-789-1	1 METAI	GLAZE	2K	0. 50%	1/10W
R537	1-216-049-00	METAL	CHIP	1K	5%	1/10W	R586	1-208-782-1	1 METAI	GLAZE	1K	0.50%	1/10W
R538	1-216-049-00	METAL	CHIP	1K	5%	1/10W	R587	1-208-789-1	1 METAI	GLAZE	2K	0.50%	1/10₩
R539	1-216-041-00	METAL	CHIP	470	5%	1/10W	R588	1-216-041-0	O METAI	. CHIP	470	5%	1/10W
DE 40	1 010 040 00	Memai	CULD	117	ro.	4 /4 OW	DEGO	1 010 041 0	O METAL	CUID	470	ΕO	1/10W
R540	1-216-049-00			1K	5%	1/10W	R589	1-216-041-0			470	5% 5%	•
R541	1-216-295-91			0	5%	1/10W	R590	1-216-049-0			1K	5% 5%	1/10W
R542	1-216-065-00			4. 7K		1/10W	R591	1-216-065-0			4. 7K		1/10W
R543	1-216-041-00			470	5%	1/10W	R592	1-216-065-0			4. 7K		1/10W
R544	1-216-041-00	METAL	CHIP	470	5%	1/10W	R593	1-216-041-0	U METAI	CHIP	470	5%	1/10W
R545	1-216-065-00	METAL	CHIP	4. 7K	5%	1/10W	R594	1-216-041-0	O METAI	CHIP	470	5%	1/10W
R546	1-216-041-00			470	5%	1/10W	R595	1-216-015-0	O METAI	CHIP	39	5%	1/10W
R547	1-216-041-00			470	5%	1/10W	R596	1-216-073-0	O METAI	CHIP	10K	5%	1/10W
R548	1-216-049-00			1K	5%	1/10W	R599	1-216-053-0	O METAI	CHIP	1. 5K	5%	1/10W
R549	1-216-295-91			0	5%	1/10W	R600	1-216-121-0			1M	5%	1/10W
	4 040 005		auzs		Pa.	4 /4 000	2000	4 000 500	4 Mrm.	CI APP	4.17	0.500	1 /100
R550	1-216-065-00			4. 7K		1/10W	R602	1-208-782-1			1K		1/10W
R551	1-216-041-00			470	5%	1/10W	R603	1-208-782-1			1K		1/10W
R552	1-216-049-00			1K	5%	1/10W	R604	1-208-782-1			1K		1/10W
R553	1-216-049-00	J METAL	CHIP	1K	5%	1/10W	R605	1-208-782-1	.1 METAI	L GLAZE	1K	U. 5U%	1/10 W

Ref. No.	Part No.	Descr	iption			Remark	Ref. No.	Part No.	Description			Remark
R606	1-216-073-00	METAL	CHIP	10K	5%	1/10W	R690	1-208-762-11	METAL GLAZE	150	0. 50%	1/10W
R607	1-216-065-00			4. 7K		1/10W	R691	1-208-762-11		150		1/10W
R608	1-216-065-00			4. 7K	5%	1/10W	R692	1-208-762-11		150	0. 50%	-
R609	1-216-027-00			120	5%	1/10W	R704	1-216-051-00		1. 2K		1/10W
R610	1-208-782-11			1K		1/10W	R705	1-216-051-00		1. 2K		1/10W
11010	1 200 702 11	METTI	GLMZL	III	0. 00%	1, 10"	11703	1 210 001 00	METAL OHII	1. 211	JA)	1/10#
R611	1-208-782-11	METAL	GLAZE	1K	0.50%	1/10W	R706	1-216-051-00	METAL CHIP	1. 2K	5%	1/10W
R612	1-208-782-11	METAL	GLAZE	1K	0.50%	1/10₩	R707	1-216-041-00	METAL CHIP	470	5%	1/10W
R613	1-208-782-11	METAL	GLAZE	1K	0.50%	1/10W	R708	1-216-041-00	METAL CHIP	470	5%	1/10W
R614	1-216-073-00	METAL	CHIP	10K	5%	1/10W	R709	1-216-041-00	METAL CHIP	470	5%	1/10₩
R615	1-216-065-00	METAL	CHIP	4. 7K	5%	1/10W	R710	1-216-049-00	METAL CHIP	1K	5%	1/10₩
DC1C	1 010 005 00	METAL	CHID	4 717	ΓſV	1 /100	D711	1 910 040 00	MEMAL CUID	117	Γŵ	1 /1 055
R616	1-216-065-00			4. 7K		1/10W	R711	1-216-049-00		1K	5%	1/10W
R617	1-216-027-00			120	5%	1/10W	R712	1-216-049-00		1K	5%	1/10W
R618	1-216-121-00			1M	5%	1/10W	R713	1-216-065-00	•	4. 7K		1/10W
R621	1-216-081-00			22K	5%	1/10W	R714	1-216-065-00		4. 7K	5%	1/10W
R622	1-216-081-00	METAL	CHIP	22K	5%	1/10W	R715	1-216-053-00	METAL CHIP	1. 5K	5%	1/10W
R623	1-216-041-00	METAL	CHIP	470	5%	1/10₩	R716	1-216-053-00	METAL CHIP	1. 5K	5%	1/10W
R624	1-216-049-00			1K	5%	1/10 W	R717	1-216-041-00		470	5%	1/10W
R625	1-216-049-00			1K	5%	1/10 W	R718	1-216-077-00		15K	5%	1/10W
R626	1-216-081-00			22K	5%	1/10W	R719	1-216-073-00		10K	5%	1/10W
R627	1-216-081-00			22K	5%	1/10W	R720	1-216-041-00		470	5%	1/10W
11027	1 210 001 00	IIIL 173L	VIIII	LLIN	0.0	1/10#	10,20	1 210 041 00	METAL OIII	410	J.Aj	1/10#
R628	1-216-041-00	METAL	CHIP	470	5%	1/10W	R721	1-216-041-00	METAL CHIP	470	5%	1/10W
R629	1-216-065-00	METAL	CHIP	4. 7K	5%	1/10W	R722	1-216-077-00	METAL CHIP	15K	5%	1/10W
R630	1-216-049-00	METAL	CHIP	1K	5%	1/10W	R723	1-216-073-00	METAL CHIP	10K	5%	1/10W
R631	1-216-041-00	METAL	CHIP	470	5%	1/10 W	R724	1-216-041-00	METAL CHIP	470	5%	1/10W
R632	1-216-065-00	METAL	CHIP	4. 7K	5%	1/10W	R725	1-216-041-00	METAL CHIP	470	5%	1/10W
R633	1-216-073-00	МСТАІ	CHID	101/	Eov	1 /1 OW	D790	1 216 041 00	МЕТАІ СИІВ	470	ΕQ	1 /1 OW
				10K	5%	1/10W	R726	1-216-041-00		470	5% 5%	1/10W
R634	1-216-041-00			470	5%	1/10W	R727	1-216-041-00		470	5%	1/10W
R635	1-216-057-00			2. 2K		1/10W	R728	1-216-049-00		1K	5%	1/10W
R636	1-216-081-00			22K	5%	1/10W	R729	1-216-049-00		1K	5%	1/10W
R637	1-216-081-00	METAL	CHIP	22K	5%	1/10W	R730	1-216-049-00	METAL CHIP	1K	5%	1/10₩
R638	1-216-041-00	METAL	CHIP	470	5%	1/10W	R731	1-216-049-00	METAL CHIP	1K	5%	1/10W
R639	1-216-065-00			4. 7K		1/10W	R732	1-216-049-00		1K		1/10W
R640	1-216-081-00			22K		1/10W	R733	1-216-057-00		2. 2K	5%	1/10₩
R641	1-216-081-00			22K		1/10W	R740	1-216-027-00		120		1/10W
R642	1-216-041-00			470	5%	1/10W	R745	1-208-779-11		750	0. 50%	
110-12	1 210 011 00	MEIM	VIIII	110	0.00	1/10#	11710	1 200 773 11	METAL GLABE	700	U. 30A)	1/1011
R643	1-216-065-00	METAL	CHIP	4. 7K	5%	1/10W	R746	1-216-117-00	METAL CHIP	680K	5%	1/10W
R644	1-216-041-00	METAL	CHIP	470	5%	1/10W	R747	1-216-057-00	METAL CHIP	2. 2K	5%	1/10W
R645	1-216-057-00	METAL	CHIP	2. 2K	5%	1/10₩	R748	1-216-021-00	METAL CHIP	68	5%	1/10W
R671	1-216-049-00	METAL	CHIP	1K	5%	1/10W	R749	1-216-049-00	METAL CHIP	1K	5%	1/10W
R672	1-216-049-00	METAL	CHIP	1K	5%	1/10W	R750	1-216-057-00		2. 2K	5%	1/10W
R681	1-208-762-11			150	0. 50%	•	R751	1-216-019-00		56		1/10W
R682	1-208-762-11			150	0. 50%		R752	1-216-049-00		1K		1/10₩
R683	1-208-762-11			150	0. 50%		R753	1-216-073-00		10K		1/10W
R684	1-208-762-11			150	0. 50%		The state of the s	1-216-049-00		1K		1/10W
R685	1-208-762-11	METAL	GLAZE	150	0.50%	1/10W	R755	1-216-085-00	METAL CHIP	33K	5%	1/10W
R686	1-208-762-11	METAI	GLA7F	150	0. 50%	1/10W	R756	1-216-085-00	METAL CHIP	33K	5%	1/10 W
R687	1-208-762-11			150	0. 50%		R757	1-216-085-00		33K		1/10W
R688	1-208-762-11			150	0. 50%		R757	1-216-073-00		10K		1/10W
R689	1-208-762-11			150			R756					
пооз	1-700-107-11	mt IAL	ULALC	130	0. 50%	T\ TO#	1 4/28	1-216-049-00	MICIAL UNIP	1K	5%	1/10W

Ref. No.	Part No.	Descri	iption			Remark	Ref. No.	Part No.	Descri	ption			Remark
R771	1-208-801-11	METAL	GLAZE	6. 2K	0. 50%	1/10W	R837	1-216-041-00	METAL	CHIP	470	5%	1/10W
R772	1-216-073-00	METAL	CHIP	10K	5%	1/10W	R838	1-216-073-00	METAL	CHIP	10K	5%	1/10W
R776	1-216-085-00			33K	5%	1/10W	R839	1-216-041-00	METAL	CHIP	470	5%	1/10W
R777	1-216-689-11			39K	0. 5%	-	R840	1-216-073-00			10K		1/10W
R778	1-216-295-91			0	5%	1/10W	R841	1-216-121-00	METAL	CHIP	1M		1/10W
11.70	1 210 200 01	IND ITEM	CELLED	Ū	0.0								-,
R779	1-216-295-91	METAL	GLAZE	0	5%	1/10W	R842	1-216-033-00	METAL	CHIP	220	5%	1/10₩
R781	1-216-065-00	METAL	CHIP	4. 7K	5%	1/10W	R843	1-216-033-00	METAL	CHIP	220		1/10W
R782	1-216-065-00	METAL	CHIP	4. 7K	5%	1/10W	R847	1-216-073-00	METAL	CHIP	10K		1/10W
R783	1-216-065-00	METAL	CHIP	4. 7K	5%	1/10W	R848	1-216-073-00	METAL	CHIP	10K		1/10₩
R791	1-216-073-00	METAL	CHIP	10K	5%	1/10W	R849	1-216-073-00	METAL	CHIP	10K	5%	1/10W
R792	1-216-073-00	METAL	CHID	10K	5%	1/10W	R850	1-216-073-00	MFTAI	CHIP	10K	5%	1/10W
R792 R794	1-216-073-00			10K		1/10W	R851	1-216-073-00			10K		1/10W
R795	1-216-295-91			0	5%	1/10W	R852	1-216-073-00			10K		1/10W
ก/ชอ	1-210-293-91			U	JA	1/10#	R853	1-216-089-91			47K		1/10W
D707	1 200 700 11		anadian)	ον	O EOW	1 /1 OW	R854	1-216-089-91			47K	5%	1/10W
R797	1-208-789-11			2K	0.50%		1004	1-210-009-91	METAL	GLAZE	4/1	3/0	1/10#
R798	1-216-073-00	METAL	CHIP	10K	5%	1/10W	Doce	1 010 000 01	MEMAI	OI AGE	4517	rov	1 /1 050
							R855	1-216-089-91			47K	5% 5%	1/10W
R799	1-216-073-00			10K	5%	1/10W	R856	1-216-089-91			47K	5%	1/10W
R800	1-216-073-00			10K	5%	1/10W	R857	1-216-089-91			47K		1/10W
R801	1-216-065-00			4. 7K		1/10W	R858	1-216-089-91			47K		1/10W
R802	1-216-073-00			10K	5%	1/10W	R861	1-216-073-00	METAL	CHIP	10K	5%	1/10W
R803	1-216-073-00	METAL	CHIP	10K	5%	1/10W		4 040 050 00		aux D	401/	- 04	4 /4 (18)
							R862	1-216-073-00			10K	5%	1/10W
R804	1-216-073-00			10K	5%	1/10W	R863	1-216-073-00			10K	5%	1/10W
R805	1-216-073-00			10K	5%	1/10W	R866	1-216-073-00			10K	5%	1/10W
R806	1-216-073-00			10K	5%	1/10W	R867	1-216-073-00			10K	5%	1/10W
R807	1-216-073-00			10K	5%	1/10W	, R868	1-216-073-00	METAL	CHIP	10K	5%	1/10₩
R808	1-216-073-00	METAL	CHIP	10K	5%	1/10W					_		
							R870	1-216-295-91			0		1/10W
R809	1-216-073-00			10K	5%	1/10W	R871	1-216-295-91			0	5%	1/10W
R810	1-216-073-00			10K	5%	1/10W			(AEP, U				
R811	1-216-073-00			10K	5%	1/10W	R872	1-216-295-91			0	5%	1/10W
R812	1-216-073-00			10K	5%	1/10W	R874	1-216-041-00			470	5%	1/10W
R813	1-216-073-00	METAL	CHIP	10K	5%	1/10W	R875	1-216-041-00	METAL	CHIP	470	5%	1/10W
R814	1-216-073-00	METAL.	CHIP	10K	5%	1/10W	R878	1-216-073-00	METAL.	CHIP	10K	5%	1/10W
R820	1-216-049-00			1K	5%	1/10W	R879	1-216-073-00			10K	5%	1/10W
R821	1-216-073-00			10K	5%	1/10W	R880	1-216-073-00			10K	5%	1/10W
R822	1-216-097-00			100K		1/10W	R881	1-216-025-00			100	5%	1/10W
R823	1-216-085-00			33K	5%	1/10W	R882	1-216-041-00			470	5%	1/10W
R824	1-216-073-00	METAL	CHIP	10K	5%	1/10W	R883	1-208-786-11			1. 5K	0. 50%	
R825	1-216-073-00	METAL	CHIP	10K	5%	1/10W	R884	1-216-025-00	METAL	CHIP	100	5%	1/10W
R826	1-216-073-00	METAL	CHIP	10K	5%	1/10W	R885	1-216-049-00	METAL	CHIP	1K	5%	1/10W
R827	1-216-073-00	METAL	CHIP	10K	5%	1/10W	R886	1-208-786-11	METAL	GLAZE	1. 5K	0.50%	1/10₩
R828	1-216-073-00	METAL	CHIP	10K	5%	1/10₩	R887	1-216-025-00	METAL	CHIP	100	5%	1/10W
poon	1. 910 070 00	МБалт	CUID	100	Εθν	1 /1 OW	Dogo	1_900 700 11	METAI	CLATE	1 FV	U EUM	1 /1 /10
R829	1-216-073-00			10K	5% ===	1/10W	R888	1-208-786-11 1-216-041-00			1. 5K	0. 50%	
R830	1-216-073-00			10K	5% =~	1/10W	R889				470	5% 5%	1/10W
R831	1-216-073-00			10K	5%	1/10W	R890	1-216-073-00			10K	5%,	1/10W
R832	1-216-073-00			10K	5%	1/10W	R891	1-216-025-00			100	5%	1/10W
R833	1-216-073-00	METAL	CHIP	10K	5%	1/10W	R892	1-208-786-11	METAL	GLAZE	1. 5K	0. 50%	T\TN#
R834	1-216-073-00	METAI.	CHIP	10K	5%	1/10W	R893	1-216-041-00	METAL.	CHIP	470	5%	1/10W
R835	1-216-073-00			10K	5%	1/10W	R894	1-216-073-00			10K	5%	1/10W
R836	1-216-073-00			10K	5%	1/10W	R895	1-216-049-00			1K	5%	1/10W
	000		**	2011		-,"	, 1000		a £ 3£3		~	0	-,

Ref. No.	Part No.	Descr.	iption_			Remark	Ref. No.	Part No.	Descr:	iption			Remark
R896	1-216-049-00	METAL	CHIP	1K	5%	1/10W	R947	1-208-762-11	METAL	GLAZE	150	0. 50%	1/10W
R897	1-216-049-00	METAL	CHIP	1K	5%	1/10W	R948	1-216-049-00			1K	5%	1/10W
R898	1-216-049-00			1K	5%	1/10W	R949	1-208-826-11			68K	0. 50%	
R901	1-208-826-11			68K	0.50%		R950	1-216-081-00			22K	5%	1/10W
R902	1-216-081-00			22K	5%	1/10W	R951	1-216-041-00			470	5%	1/10W
						-,				*****		•	2, 20
R903	1-216-041-00	METAL	CHIP	470	5%	1/10W	R952	1-216-033-00	METAL	CHIP	220	5%	1/10W
R904	1-216-033-00	METAL	CHIP	220	5%	1/10W	R953	1-216-057-00	METAL	CHIP	2. 2K	5%	1/10W
R905	1-216-057-00	METAL	CHIP	2. 2K	5%	1/10W	R954	1-208-788-11	METAL	GLAZE	1. 8K	0.50%	1/10W
R906	1-208-788-11	METAL	GLAZE	1. 8K	0.50%	1/10W	R955	1-208-790-11	METAL	GLAZE	2. 2K	0.50%	1/10W
R907	1-208-790-11	METAL	GLAZE	2. 2K	0.50%	1/10W	R956	1-216-057-00	METAL	CHIP	2. 2K	5%	1/10W
R908	1-216-057-00	METAL	CHIP	2. 2K	5%	1/10W	R957	1-216-041-00	METAL	CHIP	470	5%	1/10W
R909	1-216-041-00	METAL	CHIP	470	5%	1/10W	R958	1-216-041-00	METAL	CHIP	470	5%	1/10W
R910	1-216-041-00	METAL	CHIP	470	5%	1/10W	R959	1-216-025-00	METAL	CHIP	100	5%	1/10W
R911	1-216-025-00	METAL	CHIP	100	5%	1/10W	R960	1-216-001-00	METAL	CHIP	10	5%	1/10W
R912	1-216-001-00	METAL	CHIP	10	5%	1/10W	R961	1-216-001-00	METAL	CHIP	10	5%	1/10W
R913	1-216-001-00	METAL	CHIP	10	5%	1/10\	R962	1-216-025-00	METAL	CHIP	100	5%	1/10₩
R914	1-216-025-00	METAL	CHIP	100	5%	1/10W	R963	1-208-762-11			150	0. 50%	1/10₩
R915	1-208-762-11	METAL	GLAZE	150	0.50%	1/10₩	R964	1-216-049-00	METAL	CHIP	1 K	5%	1/10₩
R916	1-216-049-00			1K	5%	1/10W	R965	1-208-826-11			68K	0. 50%	-
R917	1-208-826-11	METAL	GLAZE	68K	0.50%	1/10W	R966	1-216-081-00	METAL	CHIP	22K	5%	1/10₩
2010													
R918	1-216-081-00			22K	5%	1/10W	R967	1-216-041-00			470	5%	1/10W
R919	1-216-041-00			470		1/10W	R968	1-216-033-00			220	5%	1/10W
R920	1-216-033-00			220		1/10W	R969	1-216-057-00			2. 2K		1/10W
R921	1-216-057-00			2. 2K		1/10W	R970	1-208-788-11				0. 50%	
R922	1-208-788-11	METAL	GLAZE	1. 8K	0.50%	1/1UW	R971	1-208-790-11	METAL	GLAZE	2. 2K	0. 50%	1/1UW
R923	1-208-790-11	METAI	CI A7E	2 24	0. 50%	1 /1 01	R972	1-216-057-00	METAI	cuin	2. 2K	5%	1/10W
						· .							
R924	1-216-057-00			2. 2K		1/10W	R973	1-216-041-00			470	5% 5°	1/10W
R925	1-216-041-00			470		1/10\\	R974	1-216-041-00			470	5%	1/10W
R926	1-216-041-00			470		1/10W	R975	1-216-025-00			100	5%	1/10W
R927	1-216-025-00	METAL	UNIP	100	5%	1/10W	R976	1-216-001-00	MICIAL	Unir	10	5%	1/10₩
R928	1-216-001-00	MFTAI	CHIP	10	5%	1/10W	R977	1-216-001-00	METAI	CHIP	10	5%	1/10W
R929	1-216-001-00			10		1/10W	R978	1-216-025-00			100	5%	1/10W
R930	1-216-025-00			100		1/10W	R979	1-208-762-11			150	0.50%	
R931	1-208-762-11			150	0. 50%		R980	1-216-049-00			1K	5%	1/10W
R932	1-216-049-00			1K		1/10W	R981	1-208-826-11			68K	0.50%	
			·····		0.0	1, 10.11		1 200 020 11		45.155	0011	0.00%	1, 10
R933	1-208-826-11	METAL	GLAZE	68K	0.50%	1/10W	R982	1-216-081-00	METAL	CHIP	22K	5%	1/10W
R934	1-216-081-00			22K		1/10W	R983	1-216-041-00			470	5%	1/10W
R935	1-216-041-00			470		1/10W	R984	1-216-033-00			220	5%	1/10W
R936	1-216-033-00			220		1/10W	R985	1-216-057-00			2. 2K	5%	1/10W
R937	1-216-057-00			2. 2K		1/10W	R986	1-208-788-11				0.50%	
R938	1-208-788-11	METAL	GLAZE	1. 8K	0.50%	1/10W	R987	1-208-790-11	METAL	GLAZE	2. 2K	0.50%	1/10W
R939	1-208-790-11	METAL	GLAZE	2. 2K	0.50%	1/10W	R988	1-216-057-00	METAL	CHIP	2. 2K	5%	1/10W
R940	1-216-057-00	METAL	CHIP	2. 2K	5%	1/10W	R989	1-216-041-00	METAL	CHIP	470	5%	1/10W
R941	1-216-041-00	METAL	CHIP	470	5%	1/10W	R990 🖟	1-216-041-00	METAL	CHIP	470	5%	1/10W
R942	1-216-041-00	METAL	CHIP	470	5%	1/10W	R991	1-216-025-00	METAL	CHIP	100	5%	1/10W
R943	1-216-025-00			100		1/10W	R992	1-216-001-00	METAL	CHIP	10		1/10W
R944	1-216-001-00			10		1/10W	R993	1-216-001-00			10		1/10W
R945	1-216-001-00			10		1/10W	R994	1-216-025-00			100		1/10W
R946	1-216-025-00	METAL	CHIP	100	5%	1/10W	R995	1-208-762-11	METAL	GLAZE	150	0.50%	1/10W

AV-26P AV-26U CM-42

R996 1-216-049-00 METAL CHIP 1K 5% 1/10W C014 1-163-235-11 CERAMIC CHIP 22PF 5% R997 1-216-027-00 METAL CHIP 120 5% 1/10W C015 1-163-235-11 CERAMIC CHIP 22PF 5% C016 1-163-038-00 CERAMIC CHIP 22PF 5% C016 1-163-038-00 CERAMIC CHIP 22PF 5% C016 1-163-038-00 CERAMIC CHIP 22PF 5% C016 1-163-038-00 CERAMIC CHIP 22PF 5% C016 1-163-038-00 CERAMIC CHIP 22PF 5% C016 1-163-038-00 CERAMIC CHIP 22PF 5% C016 1-163-038-00 CERAMIC CHIP 22PF 5% C016 1-163-038-00 CERAMIC CHIP 22PF 5% C016 1-163-038-00 CERAMIC CHIP 22PF 5% C016 1-163-038-00 CERAMIC CHIP 22PF 5% C016 1-163-038-00 CERAMIC CHIP 22PF 5% C016 1-163-038-00 CERAMIC CHIP 22PF 5% C016 1-163-038-00 CERAMIC CHIP 22PF 5% C016	nark
R997 1-216-027-00 METAL CHIP 120 5% 1/10W C100 1-163-038-00 CERAMIC CHIP 22PF 5% C100 1-216-073-00 METAL CHIP 120 5% 1/10W C000 1-163-038-00 CERAMIC CHIP 0.1 uF C100 1-163-038-00 CERAMIC CHIP 0.1 uF C100 C108-038-00 CERAMIC CHIP 0.1 uF C108-0	50V
R999 1-216-073-00 METAL CHIP 10K 5% 1/10W CONNECTOR >	50V
R999 1-216-073-00 METAL CHIP 10K 5% 1/10W CONNECTOR >	25V
CROOL 1-506-487-11 PIN, CONNECTOR 8P	
RV451 1-241-594-11 RES, ADJ, METAL GRAZE 10K RV471 1-241-594-11 RES, ADJ, METAL GRAZE 10K (US, CND) RV501 1-241-592-11 RES, ADJ, METAL GRAZE 1K D001 8-719-106-43 D100E RD9. 1M−B1 D002 8-719-157-33 D10DE RD9. 1M−B1 D003 8-719-800-76 D10DE SS226 D004 8-719-800-76 D10DE SS226 D005 8-719-800-76 D10DE SS226 D005 8-719-800-76 D10DE SS226 D007 8-719-157-33 D10DE R06. 2M−B D07 8-719-970-40 LED GLIEG11 (POWER) D07 8-719-970-40 LED GLIEG11 (POWER) D07 8-719-157-33 D10DE R06. 2M−B D07 8-719-157-33 D10DE R06. 2M−B D07 8-719-157-33 D10DE R06. 2M−B D07 8-719-970-40 LED GLIEG11 (POWER) D07 8-719-970-40 LED GLIEG11 (POWER) D07 8-719-970-40 LED GLIEG11 (POWER) D07 8-719-157-33 D10DE R06. 2M−B D07 8-719-157-33 D10DE R06. 2M−B D07 8-719-157-33 D10DE R06. 2M−B D07	
RV471 1-241-594-11 RES, ADJ, METAL GRAZE 10K (US, CND)	
RV501 1-241-592-11 RES. ADJ. METAL GRAZE 2.2K RV701 1-241-591-11 RES. ADJ. METAL GRAZE 1K D001 8-719-106-43 D100E RD6. 2M-B D003 8-719-157-33 D10DE RD6. 2M-B D003 8-719-800-76 D10DE ISS226 D004 8-719-800-76 D10DE ISS226 D004 8-719-800-76 D10DE ISS226 D004 8-719-800-76 D10DE ISS226 D004 8-719-800-76 D10DE ISS226 D005 8-719-800-76 D10DE ISS226 D006 8-719-800-76 D10DE ISS226 D007 RV79-800-76 D10DE ISS226 D008 RV79-87-733 D10DE RV79-800-76 D10DE ISS226 D008 RV79-87-733 D10DE RV79-800-76 D10DE ISS226 D009 RV79-800-76 D10DE ISS226 D009 RV79-800-75 D100 RV79-800-75 D10DE ISS226 D009 RV79-800-75 D10DE ISS226 D009 RV79-800-75 D10DE ISS226 D009 RV79-800-75 D10DE D009 RV79-800-75	
RV701 1-241-591-11 RES. ADJ. METAL GRAZE 1K D001 8-719-106-43 D10DE RDS. 2M-B D002 8-719-1800-76 D10DE SS226 D004 8-719-800-76 D10DE SS226 D004 RDS. 2M-B D005 RDS. 2M-B D005 RDS. 2M-B D006 RDS. 2M-B D007 RDS. 2M-B D008 RDS. 2M-B D009 RDS.	
D002	
TPO60	
DO04 8-719-800-76 DIODE ISS226 TP060 1-535-757-11 CHIP, CHECKER (AEP, UK) D005 8-719-800-76 DIODE ISS226 TP411 1-535-757-11 CHIP, CHECKER D006 8-719-800-76 DIODE ISS226 TP801 1-535-757-11 CHIP, CHECKER D007 8-719-157-33 DIODE RD6. 2M-B D008 8-719-157-33 DIODE RD6. 2M-B D008 RD6. 2M-B D008 RD6. 2M-B D008 RD6. 2M-B D009 RD6. 2M-B D00	
TP060	
TP411 1-535-757-11 CHIP, CHECKER TP741 1-535-757-11 CHIP, CHECKER TP801 1-535-757-11 CHIP, CHECKER TP802 1-535-757-11 CHIP, CHECKER TP803 1-535-757-11 CHIP, CHECKER TP804 1-535-757-11 CHIP, CHECKER TP804 1-535-757-11 CHIP, CHECKER TP805 1-535-757-11 CHIP, CHECKER TP806 1-535-757-11 CHIP, CHECKER TP807 1-535-757-11 CHIP, CHECKER TP808 1-535-757-11 CHIP, CHECKER TP809 1-535-757-11 CHIP, CHECKER TP809 1-535-757-11 CHIP, CHECKER TP809 1-535-757-11 CHIP, CHECKER TP809 1-535-757-11 CHIP, CHECKER TP809 1-535-757-11 CHIP, CHECKER TP809 1-535-757-11 CHIP, CHECKER TP809 1-579-738-21 VIBRATOR, CRYSTAL (14. 32MHz) (US, Canadian) TP809 1-579-738-21 VIBRATOR, CRYSTAL (17. 73MHz) (AEP, UK) TP809 1-579-780-21 VIBRATOR, CRYSTAL (14. 20MHz) (AEP, UK) TP809 1-579-780-21 VIBRATOR, CRYSTAL (17. 73MHz) (AEP, UK) TP809 1-579-738-21 VIBRATOR, CRYSTAL (17. 73MHz) (AEP, UK) TP809 1-579-738-21 VIBRATOR, CRYSTAL (14. 32MHz) TP809 1-579-738-21 VIBRATOR, CRYSTAL (14. 32MHz) TP809 1-579-738-21 VIBRATOR, CRYSTAL (14. 32MHz) TP809 1-579-738-21 VIBRATOR, CRYSTAL (14. 32MHz) TP809 1-579-738-21 VIBRATOR, CRYSTAL (14. 32MHz) TP809 1-579-738-21 VIBRATOR, CRYSTAL (14. 32MHz) TP809 1-579-738-21 VIBRATOR, CRYSTAL (14. 32MHz) TP809 1-579-738-21 VIBRATOR, CRYSTAL (14. 32MHz) TP809 1-579-738-21 VIBRATOR, CRYSTAL (14. 32MHz) TP809 1-579-738-21 VIBRATOR, CRYSTAL (14. 32MHz) TP809 1-579-738-21 VIBRATOR, CRAMIC (8. 00MHz) TP809 1-577-082-11 VIBRATOR, CRAMIC (48. 00MHz) TP809 1-577-082-11 VIBRA	
TP741	
TP801 1-535-757-11 CHIP, CHECKER TP802 1-535-757-11 CHIP, CHECKER TP803 1-535-757-11 CHIP, CHECKER TP804 1-535-757-11 CHIP, CHECKER TP805 1-535-757-11 CHIP, CHECKER TP806 1-535-757-11 CHIP, CHECKER TP807 1-535-757-11 CHIP, CHECKER TP808 1-535-757-11 CHIP, CHECKER	
TP802 1-535-757-11 CHIP, CHECKER TP803 1-535-757-11 CHIP, CHECKER TP804 1-535-757-11 CHIP, CHECKER CVIBRATOR > CVIBRATOR > CVIBRATOR > CVIBRATOR, CRYSTAL (14. 32MHz) (US, Canadian) X050 1-579-780-21 VIBRATOR, CRYSTAL (14. 20MHz) X061 1-579-780-21 VIBRATOR, CRYSTAL (14. 32MHz) (US, Canadian) X061 1-579-780-21 VIBRATOR, CRYSTAL (14. 32MHz) (US, Canadian) X071 1-579-780-21 VIBRATOR, CRYSTAL (14. 32MHz) (US, Canadian) X071 1-579-780-21 VIBRATOR, CRYSTAL (14. 32MHz) (US, Canadian) X071 1-579-780-21 VIBRATOR, CRYSTAL (14. 32MHz) X081 1-579-780-21 VIBRATOR, CRYSTAL (14. 32MHz) X091 1-579-708-21 LED X091 1-579-70	
D010	
TP803 1-535-757-11 CHIP, CHECKER TP804 1-535-757-11 CHIP, CHECKER D012 8-719-970-40 LED GL1EG11 (POWER)	
TP804 1-535-757-11 CHIP, CHECKER D090 8-719-157-33 DIODE RD6. 2M-B	
D090	
Note	
Note	
X050 1-579-738-21 VIBRATOR, CRYSTAL (14. 32MHz) (US, Canadian) D101 8-719-047-23 LED LT3S43P (DISPLAY) (D15PLAY) (US, Canadian) D102 8-719-047-23 LED LT3S43P (CINEMA)	
(US, Canadian) X060 1-579-780-21 VIBRATOR, CRYSTAL (17. 73MHz) (AEP, UK) X061 1-579-519-21 VIBRATOR, CRYSTAL (14. 20MHz) (AEP, UK) X471 1-579-780-21 VIBRATOR, CRYSTAL (17. 73MHz) (AEP, UK) X471 1-579-780-21 VIBRATOR, CRYSTAL (17. 73MHz) (AEP, UK) X471 1-579-788-21 VIBRATOR, CRYSTAL (14. 32MHz) (US, Canadian) X801 1-567-132-00 OSCILLATOR, CERAMIC (8. 00MHz) X802 1-567-132-00 OSCILLATOR, CERAMIC (8. 00MHz) X803 1-577-082-11 VIBRATOR, CERAMIC (4MHz) X900 1-577-082-11 VIBRATOR, CERAMIC (4MHz) X900 1-577-082-11 VIBRATOR, CERAMIC (4MHz) X801 1-579-047-23 LED LT3S43P (CINEMA) D103 8-719-047-23 LED LT3S43P (MONOTONE) LT3S43P (WHITE) D104 8-719-047-23 LED LT3S43P (WHITE) D105 8-719-047-23 LED LT3S43P (BLACK) D106 8-719-970-91 LED GL1HS112 (PLAYER 2) D107 8-719-970-91 LED GL1HS112 (PLAYER 1) D109 8-719-970-91 LED GL1HS112 (RECORDER) D109 8-719-047-23 LED LT3S43P (PREVIEW) D110 8-719-047-23 LED LT3S43P (PREVIEW) D111 8-719-047-23 LED LT3S43P (PREVIEW)	
X060	
X061 1-579-519-21 VIBRATOR, CRYSTAL (14. 20MHz) (AEP, UK) D103 8-719-047-23 LED LT3S43P (MONOTONE)	
X471 1-579-738-21 VIBRATOR, CRYSTAL (14.32MHz)	
(US, Canadian) D106 8-719-970-91 LED GL1HS112 (PLAYER 3) D107 8-719-970-91 LED GL1HS112 (PLAYER 2) X801 1-567-132-00 OSCILLATOR, CERAMIC (8.00MHz) X802 1-567-132-00 OSCILLATOR, CERAMIC (8.00MHz) D108 8-719-970-91 LED GL1HS112 (PLAYER 1) D109 8-719-970-91 LED GL1HS112 (PLAYER 1) D109 8-719-970-91 LED GL1HS112 (RECORDER) D109 8-719-970-91 LED GL1HS112 (RECORDER) D110 8-719-047-23 LED LT3S43P (PREVIEW) D111 8-719-047-23 LED LT3S43P (PREVIEW) D112 8-719-047-23 LED LT3S43P (PREVIEW)	
X801 1-567-132-00 OSCILLATOR, CERAMIC (8.00MHz) X802 1-567-132-00 OSCILLATOR, CERAMIC (8.00MHz) X803 1-577-082-11 VIBRATOR, CERAMIC (4MHz) X900 1-577-082-11 VIBRATOR, CERAMIC (4MHz) ***********************************	
X801 1-567-132-00 OSCILLATOR, CERAMIC (8.00MHz) X802 1-567-132-00 OSCILLATOR, CERAMIC (8.00MHz) X803 1-577-082-11 VIBRATOR, CERAMIC (4MHz) X900 1-577-082-11 VIBRATOR, CERAMIC (4MHz) ***********************************	
X802 1-567-132-00 OSCILLATOR, CERAMIC (8.00MHz) X803 1-577-082-11 VIBRATOR, CERAMIC (4MHz) X900 1-577-082-11 VIBRATOR, CERAMIC (4MHz) ***********************************	
X803 1-577-082-11 VIBRATOR, CERAMIC (4MHz) X900 1-577-082-11 VIBRATOR, CERAMIC (4MHz) ***********************************	
X900 1-577-082-11 VIBRATOR, CERAMIC (4MHz) ***********************************	

D112 8-719-047-23 LED LT3S43P (PREVIEW)	
· · · · · · · · · · · · · · · · · · ·	
* A=7063=867=A FM=A7 ROADO COMDUNTO	

(Ref. No 4,000 series) D114 8-719-047-23 LED LT3S43P (1 EVENT PREVIEW)	
D115 8-719-047-23 LED LT3S43P (1 EVENT PREVIEW)	
BZ001 1-529-070-11 BUZZER D117 8-719-047-23 LED LT3S43P (1 EVENT PREVIEW)	
D118 8-719-047-23 LED LT3S43P (GO TO)	
< CAPACITOR > D119 8-719-047-23 LED LT3S43P (GO TO)	
D120 8-719-047-23 LED LT3S43P (GO TO)	
C001 1-124-589-11 ELECT 47uF 20% 16V D121 8-719-047-23 LED LT3S43P (GO TO)	
COO2 1-163-038-00 CERAMIC CHIP 0. 1uf 25V D122 8-719-047-23 LED LT3S43P (EDIT START)	
C003 1-124-584-00 ELECT 100uF 20% 10V	
COO4 1-163-038-00 CERAMIC CHIP 0. 1uf 25V D123 8-719-047-23 LED LT3S43P (EDIT START)	
CO10 1-163-038-00 CERAMIC CHIP 0. 1uf 25V D124 8-719-047-23 LED LT3S43P (EDIT START)	
D125 8-719-047-23 LED LT3S43P (EDIT START)	
C011 1-163-038-00 CERAMIC CHIP 0. 1uF 25V	
C012 1-163-038-00 CERAMIC CHIP 0. 1uf 25V	
C013 1-163-038-00 CERAMIC CHIP 0.1uF 25V	

Ref. No.	Part No.	Description		Remark	Ref. No.	Part No.	Description			Remark
		< FERRITE BE	EAD >	<u></u>	R009	1-216-041-00	METAL CHIP	470	5%	1/10 W
					R010	1-216-025-00		100	5%	1/10W
FB002	1-543-813-21	FILTER, EMI			R012	1-216-053-00		1. 5K		1/10W
FB003	1-543-813-21	FILTER, EMI			R013	1-216-053-00		1. 5K		1/10W
FB004	1-543-813-21	FILTER, EMI			R016	1-216-089-91		47K	5%	1/10W
FB005	1-543-813-21	FILTER, EMI						2.7.	0.0	1, 10,,
FB006	1-543-813-21	FILTER, EMI			R017	1-216-089-91	METAL GLAZE	47K	5%	1/10₩
					R018	1-216-089-91		47K	5%	1/10W
FB007	1-543-813-21	FILTER, EMI			R019	1-216-089-91		47K	5%	1/10W
					R021	1-216-089-91		47K	5%	1/10W
		< IC >			R023	1-216-089-91		47K	5%	1/10W
TC001	8-759-157-17	IC PQ05SZ1	II (REG)		R024	1-216-089-91	METAL CLATE	47K	5%	1/10W
	8-759-636-56		P (S-P CONV.)		R025	1-216-089-91		47K 47K	5%	
	8-759-032-01		OAF (NAND)		R032	1-216-033-00		220	5%	1/10W
	8-759-253-14		-165 (CONTROL)	NICOM)	R034	1-216-033-00		220	5%	1/10W
	8-759-937-56		LB-LM-S (RESET)		R038	1-216-033-00				1/10W
10010	0 103 301 00	10 B 0004n	LD LM 5 (NESE1)	,	noso	1-210-073-00	METAL CHIP	10K	5%	1/10W
		< ROTARY SWI	TCH >		R039	1-216-073-00	METAL CHIP	10K	5%	1/10W
					R040	1-216-103-91		180K	5%	1/10W
JG001	1-572-711-11	SWITCH, ROTA	RY (ENCODER)		R041	1-216-103-91	METAL GLAZE	180K	5%	1/10W
		(REVIRSE/FOR	WARD)		R042	1-216-085-00	METAL CHIP	33K	5%	1/10W
					R043	1-216-045-00	METAL CHIP	680	5%	1/10W
		< TRANSISTOR	>		Ì					•
					R044	1-216-089-91	METAL GLAZE	47K	5%	1/10W
Q001	8-729-140-47		2SC3735-L-B35		R045	1-216-089-91	METAL GLAZE	47K	5%	1/10W
Q004	8-729-120-28	TRANSISTOR	2SC1623-L5L6		R046	1-216-049-00	METAL CHIP	1K	5%	1/10W
Q005	8-729-120-28	TRANSISTOR	2SC1623-L5L6		R047	1-216-085-00	METAL CHIP	33K	5%	1/10W
Q006	8-729-120-28	TRANSISTOR	2SC1623-L5L6		R048	1-216-085-00	METAL CHIP	33K	5%	1/10W
Q007	8-729-120-28	TRANSISTOR	2SC1623-L5L6							
0000	0 700 004 04	MD 1 MG 1 GMOD	hma4 4 4 mm		R049	1-216-085-00		33K	5%	1/10W
Q008	8-729-901-01		DTC144EK		R050	1-216-051-00		1. 2K		1/10W
Q100	8-729-901-47		DTA143EK		R051	1-216-051-00		1. 2K		1/10W
Q101	8-729-901-47		DTA143EK			1-216-085-00		33K	5%	1/10W
Q102	8-729-901-47		DTA143EK		R091	1-216-073-00	METAL CHIP	10K	5%	1/10W
Q103	8-729-901-47	TRANSISTOR	DTA143EK							
0104	0 700 004 04	MD 1 NO I GMOD	D.M. 0.4 4 4 11 11		1	1-216-073-00		10K	5%	1/10W
Q104	8-729-901-01		DTC144EK			1-216-073-00		10K	5%	1/10W
Q105	8-729-901-01		DTC144EK		R094	1-216-073-00		10K	5%	1/10W
Q106	8-729-901-01		DTC144EK		R095	1-216-073-00		10K	5%	1/10W
Q107	8-729-901-01		DTC144EK		R096	1-216-073-00	METAL CHIP	10K	5%	1/10W
Q108	8-729-901-01	INANSISION	DTC144EK		D100	1 210 005 00	METAL CUID	0017	re.	4 /4 000
Q109	8-729-901-01	TRANCICTOR	DTC144EK		R100	1-216-085-00		33K	5%	1/10W
Q110	8-729-901-01		DTC144EK		R101	1-216-049-00		1K	5%	1/10W
Q111	8-729-901-01		DTC144EK		R102	1-216-029-00		150	5%	1/10W
ATTI	0 723 301 01	HOTOTOM	DICIAACK		R103 R104	1-216-029-00		150	5%	1/10W
		< RESISTOR >			1104	1-216-029-00	METAL CHIP	150	5%	1/10W
D004			4	4.4.00		1-216-029-00		150	5%	1/10 W
R001	1-216-053-00		1.5K 5%	1/10W	R106	1-216-029-00		150	5%	1/10W
R002	1-216-025-00		100 5%	1/10W		1-216-029-00		150	5%	1/10W
R003	1-216-049-00		1K 5%	1/10W		1-216-029-00		150	5%	1/10W
R004	1-216-025-00		100 5%	1/10W	R109	1-216-029-00 !	METAL CHIP	150	5%	1/10W
R005	1-216-049-00	METAL CHIP	1K 5%	1/10W	5445	4 040 000 00				
pone	1_910 050 00	METAL ALITA	1 52 50	4 /4 OW		1-216-029-00		150	5%	1/10W
R006	1-216-053-00		1. 5K 5%	1/10W	1	1-216-029-00		150	5%	1/10W
R007	1-216-073-00		10K 5%	1/10W	ì	1-216-029-00		150	5%	1/10W
R008	1-216-025-00	MCIAL CHIP	100 5%	1/10W	R113	1-216-029-00 N	METAL CHIP	150	5%	1/10W

CM-42 EI-2 EI-2P

Ref. No.	Part No.	Description		Remark
R114	1-216-029-00	METAL CHIP	150 5%	1/10W
R115	1-216-029-00		150 5%	1/10W
R116	1-216-029-00		150 5%	1/10W
R117	1-216-029-00		150 5%	1/10W
R118	1-216-029-00		150 5%	1/10W
U110	1-210-029-00	METAL UIII	130 3/6	;
D110	1-216-029-00	METAL CHID	150 5%	1/10W
R119	1-216-029-00		150 5%	1/10W
R120			150 5%	1/10W
R121	1-216-029-00			1/10W
R122	1-216-029-00			1/10W
R123	1-216-029-00	METAL CHIP	150 5%	1/10#
D104	1-216-029-00	MCTAL CUID	150 5%	1/10W
R124				
R125	1-216-029-00		150 5%	1/10W
R126	1-216-029-00		150 5%	1/10W
R127	1-216-029-00	METAL CHIP	150 5%	1/10W
		< VARIABLE RES	ISTOR >	
RV010	1-230-070-21	RES, VAR, SLIDE	E 10K (MIC LI	EVEL)
RV011		RES, VAR, SLIDI		
RV012		RES, VAR, SLIDE		
RV012		RES, VAR, SLIDE		
1010	1 200 010 21	REO, VING OBTO	3 1011 (11000)	
		< SWITCH >		
S001	1-572-596-11	SWITCH, KEY BOA	ARD (PLAYER :	l)
S002	1-572-596-11	SWITCH, KEY BOA	ARD (PLAYER :	2)
S003	1-572-596-11	SWITCH, KEY BOA	ARD (PLAYER :	3)
S004	1-572-596-11	SWITCH, KEY BOA	ARD (RECORDE	₹)
S005	1-571-977-11	SWITCH, TACTIL	(DISPLAY ON	/0FF)
S007	1-571-977-11	SWITCH, TACTIL	(PROCESSOR	ON/OFF)
S008	1-571-977-11	SWITCH, TACTIL	(DEL)	
S009	1-571-977-11	SWITCH, TACTIL	(FRAME)	
S010	1-571-977-11	SWITCH, TACTIL	(SLOW)	
S011	1-571-977-11	SWITCH, TACTIL	(WHITE)	
S012	1-571-977-11	SWITCH, TACTIL	(BLACK)	
S013	1-571-977-11		(MONOTONE)	
S014	1-571-977-11	SWITCH, TACTIL	(CINEMA)	
S017	1-571-977-11		(POWER ON/O	FF)
S018	1-571-977-11		(PAUSE)	
			. ,	
S019	1-571-977-11	SWITCH, TACTIL	(STOP)	
S020	1-571-977-11		(PLAY)	
S021	1-571-977-11			
S022	1-571-977-11			
S022	1-571-977-11			
5020	1 0/1 3// 11	. Salivis, invilla	(ILLO)	
S024	1-571-977-11	SWITCH, TACTII.	(COUNTER RE	SET)
S024	1-571-977-11		-	
S025	1-572-596-11		ARD (PREVIEW)
S020 S027	1-572-596-11		ARD (FREVIEW ARD (1 EVENT	
	1-572-596-11		ARD (I EVENI ARD (GO TO)	I HEVIEW)
S028	1-217-280-1	SMIION, NEI BU	พกบ (นับ 10)	
gnaa	1. E79 E06 11	משוידרט עבע הח	ADD (EDIT OT	ADT'\
S029		SWITCH, KEY BO		mil)
S030	1-571-977-11	SWITCH, FACILL	(CANCEL)	

Ref. l	No.	Part No.	Descrip	tion			Remark
SO:	34	1-571-977-11	SWITCH	TACTII.	(GPI)		
	35	1-571-977-11				I/F)	
S0:		1-571-977-11	•				
	37	1-571-977-11					
SO		1-571-977-11					
S0:	39	1-571-977-11	SWITCH,				
S04	40 .	1-571-977-11	- ,				
	41						
	42						
S0	43	1-571-977-11	SWITCH,	TACTIL	(EDIT	LIST)	
en.	44	1-571-977-11	CWITCH	TACTI	/EVEN	T DATA)	
	44 45	1-571-977-11					
	45 46	1-571-977-11					
	47						
	48	1-571-977-11	-			,	1
-					` '		
SO-	49	1-571-977-11	SWITCH,	TACTIL	(NO)		
			< VIBRA	TOR >			
VΩ	Λ1	1-577-101-11	VIRRATO	R CERAI	MIC (4	19MHz)	
		1-579-049-21					
		*****					*****
*		A-7071-954-A					ian)
*		A-7072-020-A		OARD, C			
			****	******		* f. No 3,000	series)
					(110	11 110 0, 000	50.105,
			< FERRI	TE BEAD	>		
FB	191	1-543-775-11	FILTER,	EMI			
		1-543-775-11					
		1-543-775-11					
FB	194	1-543-775-11	FILTER,	EMI			
			< JACK	\			
			< JACK	/			
* J1	90	1-764-434-11	CONNECT	OR (ROU	ND TYP	E) 8P (EDI	T I/F OUT)
****	****	*****	******	*****	*****	******	******

FD-51 FL-59P FL-59U

Ref. No.	Part No.	Description		Rem	ark	Ref. No.	Part No.	Descripti	on		Rei	mark
*	A-7066-030-A	FD-51 BOARD, COM	PLETE			R711	1-216-073-00	METAL CHI	P 10K	5%	1/10W	
		******	****			R712	1-216-073-00	METAL CHI	P 10K	5%	1/10W	
			(Ref. No 4,	000 ser	ies)	R713	1-216-073-00	METAL CHI	P 10K	5%	1/10W	
						R714	1-216-073-00	METAL CHI	P 10K	5%	1/10W	
	7-685-645-79	SCREW +BVTP 3X6	TYPE2 N-S			R715	1-216-049-00	METAL CHI	P 1K	5%	1/10W	
	7-682-547-09	SCREW +BVTT 3X6	(S)									
						R716	1-216-049-00	METAL CHI	P 1K	5%	1/10W	
		< CAPACITOR >				R717	1-216-049-00	METAL CHI	P 1K	5%	1/10W	
						R718	1-216-049-00	METAL CHI	P 1K	5%	1/10W	
C701	1-126-206-11	ELECT CHIP	100uF	20%	6. 3V	R719	1-216-049-00	METAL CHI	P 1K	5%	1/10W	
C702	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	R720	1-216-049-00	METAL CHI	P 1K	5%	1/10W	
C703	1-163-239-11	CERAMIC CHIP	33PF	5%	50V							
C704	1-163-239-11	CERAMIC CHIP	33PF	5%	50V	R721	1-216-097-00	METAL CHI	P 100K	5%	1/10W	
C705	1-163-038-00	CERAMIC CHIP	0. 1uF		25V `	R722	1-216-097-00	METAL CHI	P 100K	5%	1/10W	
						R723	1-216-073-00	METAL CHI	P 10K	5%	1/10W	
C706	1-163-222-11	CERAMIC CHIP	5PF	0. 25PF	50V	R724	1-216-073-00	METAL CHI	P 10K	5%	1/10W	
C707	1-163-222-11	CERAMIC CHIP	5PF	0. 25PF	50V	R725	1-216-073-00	METAL CHI	P 10K	5%	1/10W	
C708	1-163-038-00	CERAMIC CHIP	0. 1uF		25V						-,	
C709	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	R726	1-216-097-00	METAL CHI	P 100K	5%	1/10W	
C710	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	R727	1-216-097-00				1/10W	
						R728	1-216-055-00				1/10W	
C711	1-163-038-00	CERAMIC CHIP	0. 1uF		25V	R729	1-216-055-00				1/10W	
C712			0. 1uF		25V	R730	1-216-055-00				1/10W	
											·	
		< DIODE >				R731	1-216-055-00				1/10W	
5004	0 540 455 00	DIANE BRA AV B				R732	1-216-049-00			5%	1/10W	
D701	8-719-157-33					R733	1-216-049-00			5%	1/10W	
D702	8-719-157-33	DIODE RDG. 2M-B			.	R734	1-216-049-00	METAL CHI	P 1K	5%	1/10W	
		< IC >						< VIBRATO	R >			
10701	8-752-855-40	IC CXP80116-89	20 (ED MICO	M)		X701	1-567-927-11	VIRIATOR	CERAMIC (16	MH ₂ \		
	8-759-143-35			,		X702	1-579-970-11					
	8-759-032-43			UB)			*********	-	-		****	****
	8-759-032-11			OII)						******		*****
	8-759-973-29					*	A-7072-022-A	FI - SOD RA	ARD COMPLET	F (AFD	IIK)	
10700	0 700 070 20	10 BN/400NB 12	(Inniv)			*	A-7072-047-A					m)
10706	8-759-929-86	IC SN74LS14NS	(INV)				n Tota off h		*********		Janaara	111/
	8-759-987-84		` '								000seı	·ies)
		< COIL >						< CAPACIT	OR >			
		,						\ 0111 11011	on ,			
L701	1-543-813-21					C301	1-126-206-11	ELECT CHI	P 100uF		20%	6. 3V
L702	1-543-813-21	FILTER, EMI				C351	1-163-125-00				5%	50V
						C352	1-163-239-11	CERAMIC C	HIP 33PF		5%	50V
		< RESISTOR >				C353	1-163-038-00	CERAMIC C	HIP O. 1uF			25V
R701	1-216-073-00	METAL CHIP 1	10K 5%	1/10W				< CONNECT	OR >			
R702	1-216-073-00		10K 5%	1/10W					•			
R703	1-216-073-00		10K 5%	1/10W		CN401	1-691-199-21	CONNECTOR	. FPC 26P			
R704	1-216-073-00		10K 5%	1/10W			1-506-491-11		•			
R705	1-216-073-00		10K 5%	1/10W		201110		, ••••••				
R706	1-216-073-00		10K 5%	1/10W								
R707	1-216-073-00		10K 5%	1/10W								
R708	1-216-073-00	METAL CHIP 1	10K 5%	1/10W								
R709	1-216-073-00		10K 5%	1/10W								
R710	1-216-073-00	METAL CHIP 1	10K 5%	1/10W								

FL-59P FL-59U FR-85 FR-85P

Ref. No.	Part No.	Descript	tion		Remark	Ref. No.	Part No.	Descri	ption			Ren	nark
		< DIODE	>	-				< RESIS	STOR >				
D301	8-719-157-33	DIODE	RD6.	2M-B		R301	1-216-001-00	METAL (CHIP	10	5%	1/10₩	
D302	8-719-106-43			1M-B1		R302	1-216-049-00				5%	1/10W	
D303	8-719-106-43			1M-B1	1	R351	1-216-071-00			8. 2K		1/10W	
D303				1M-B1		R352	1-216-065-00			4. 7K		1/10W	
D304 D305	8-719-106-43 8-719-106-43			1M-B1	;	R353	1-216-085-00				5%	1/10W	
D306	8-719-106-43	DIODE	RD9.	1M-B1		R354	1-216-073-00	METAL (CHIP	10K	5%	1/10W	
D307	8-719-106-43	DIODE	RD9.	1M-B1		R355	1-216-115-00	METAL (CHIP	560K	5%	1/10W	
D308	8-719-106-43	DIODE	RD9.	1M-B1		R356	1-216-095-00	METAL (CHIP	82K	5%	1/10W	
D309	8-719-157-33	DIODE	RD6.	2M-B		R357	1-216-097-00	METAL (CHIP	100K	5%	1/10W	
D310	8-719-106-43			1M-B1		R358	1-216-085-00			33K	5%	1/10W	
							*****						****
D311	8-719-106-43			1M-B1							/··		
D312	8-719-106-43	DIODE	RD9.	1M-B1		*	A-7071-957-A						1)
D313	8-719-106-43			. 1M-B1		*	A-7072-023-A		•	COMPLETE	(AEP	, UK)	
D314 D315	8-719-106-43 8-719-106-43			. 1M-B1 . 1M-B1				****	*****		No. 3.	000 sei	ries)
D 313											.,,	000 20.	100,
D316	8-719-106-43			. 1M-B1				< CAPA	CITOR >				
D333	8-719-124-13		PH3			0404	1 104 770 00	PI POM	OIII D	10 F		OON	4.017
D351	8-719-800-76	DIODE	1SS	226		C401	1-124-779-00			10uF		20%	16V
						C402	1-163-038-00			0. 1uF			25V
		< FERRI	TE B	EAD >		C403	1-124-779-00	ELECT	CHIP	10uF		20%	16V
						C406	1-126-206-11	ELECT +	CHIP	100uF		20%	6. 3V
FB301	1-543-775-11	FILTER,	EMI			C407	1-124-779-00	ELECT	CHIP	10uF		20%	16V
FB302	1-543-775-11	FILTER,	EMI										
FB303	1-543-775-11	FILTER,	EMI			C410	1-126-206-11	ELECT	CHIP	100uF		20%	6. 3V
FB304	1-543-775-11	FILTER,	EMI										
FB305	1-543-775-11	FILTER,	EMI					< CONN	ECTOR >				
FB306	1-543-775-11	FILTER,	EMI			CN403	1-691-199-21	CONNEC	TOR, FP	C 26P			
FB308	1-543-775-11	FILTER,	EMI										
FB309	1-543-775-11	FILTER,	EMI					< DIOD	E >				
FB310	1-543-775-11	FILTER,	EMI										
FB311	1-543-775-11	FILTER,	EMI			D401	8-719-157-33	DIODE	RD6. 2	M-B			
						D402	8-719-157-33	DIODE	RD6. 2	M-B			
		< JACK	>			D403	8-719-157-33	DIODE	RD6. 2	M-B			
						D404	8-719-157-33	DIODE	RD6. 2	M-B			
J301	1-750-212-11			ROUND TYPE) 4P					TTE DEA	n \			
J302	1-691-110-21			UT3, S VIDEO)				/ renn	ITE BEA	/ ע			
0304	1-021-110-21					FRA01	1-543-775-11	FILTED	FMT				
TOOO	1 500 000 04			UT3, VIDEO/AUDIO)					•				
J303	1-566-822-21			D THINING LANG			1-543-775-11						
J304		•		R INPUT3, LANC)			1-543-775-11		•				
J305	1-691-258-21	JAUK (I	n ke	PEATEK)			1-543-775-11		-				
		/ TDANC	፣ ሮሞሶ	D \		FB554	1-543-775-11	FILTER	, EMI				
		< TRANS	1910	n /		EDECE	1_5/3_775_11	FIITED	EMI				
0201	0 720 100 00	TOANOTO	ሞለኮ	2001022 1510			1-543-775-11						
Q301	8-729-120-28			2SC1623-L5L6		decar	1-543-775-11	LILICK	, cmi				
Q302	8-729-140-75			2SD999-CLCK				/ TO \					
Q351	8-729-120-28			2SC1623-L5L6				< IC >					
Q352	8-729-120-28	IRAN51S	IUK	2SC1623-L5L6		IC401	8-759-700-45	IC N	.IM4556M	-A (HEADP	HONE	AMP)	
					ı			"	5 0 0111				

< IC >

IC801 8-759-157-17 IC PQ05SZ1U (REG) IC802 8-759-032-01 IC MC74HC00AF (NAND) IC803 8-759-032-01 IC MC74HC00AF (NAND) IC804 8-759-937-56 IC S-8054ALB-LM-S (RESET) IC805 8-759-253-14 IC MB89131-165 (KEYBOARD MICOM)

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description	on	Re	mark
		< JACK >	_			*	A-7072-024-A		*	_	
J401	1-566-822-31	JACK (HEADPI	HONES)					*****	************* (Ref. N	lo 4,000 se	ries)
J555	1-569-766-11								(11011.11	1,000 50	1105,
		< TRANSISTO	R >					< CAPACITO	OR >		
		\ IIMMBIDIO	. /			C801	1-126-395-11	ELECT	22uF	20%	16V
Q401	8-729-107-46	TRANSISTOR	2SC3624A	-L15		C802	1-126-395-11	ELECT	22uF	20%	16V
Q402	8-729-107-46	TRANSISTOR	2SC3624A	-L15		C803	1-126-206-11	ELECT CHIE	100uF	20%	6. 3
Q403	8-729-107-46		2SC3624A			C804	1-163-038-00				25V
Q404	8-729-107-46	TRANSISTOR	2SC3624A	-L15		C805	1-163-038-00	CERAMIC CH	IIP 0. 1uF		25V
		< RESISTOR	>			C806	1-163-038-00	CERAMIC CH	IIP 0. 1uF		25V
						C807	1-163-038-00	CERAMIC CH	IIP 0. 1uF		25V
R401	1-216-081-00	METAL CHIP	22K	5%	1/10W						
R402	1-216-073-00	METAL CHIP	10K	5%	1/10W			< CONNECTO	OR >		
R405	1-216-009-00	METAL CHIP	22	5%	1/10W						
R406	1-216-049-00	METAL CHIP	1K	5%	1/10W	CN801	1-506-487-11	PIN, CONNE	CTOR 8P		
R407	1-216-065-00	METAL CHIP	4. 7K	5%	1/10W	CN802	1-569-936-11	SOCKET, CO	NNECTOR 20P		
R408	1-216-081-00	METAL CHIP	22K	5%	1/10W			< DIODE >			
R409	1-216-073-00		10K	5%	1/10W						
R412	1-216-009-00		22	5%	1/10W	D801	8-719-106-43	DIODE RE	9. 1M-B1		
R413	1-216-049-00		1K	5%	1/10W	D802	8-719-157-33		6. 2M-B		
R414	1-216-065-00		4. 7K		1/10W	D803	8-719-800-76		S226		
						D804	8-719-800-76		S226		
R415	1-216-009-00	METAL CHIP	22	5%	1/10W	D805	8-719-800-76		S226		
R416	1-216-049-00	METAL CHIP	1K	5%	1/10W						
R417	1-216-009-00	METAL CHIP	22	5%	1/10W	D806	8-719-800-76	DIODE 18	S226		
R418	1-216-049-00	METAL CHIP	1K	5%	1/10W	D807	8-719-800-76	DIODE 18	S226		
R419	1-216-045-00	METAL CHIP	680	5%	1/10W	D808	8-719-800-76	DIODE 1S	S226		
					•	D809	8-719-800-76	DIODE 1S	S226		
R420	1-216-045-00	METAL CHIP	680	5%	1/10W	D810	8-719-800-76		S226		
R421	1-216-045-00	METAL CHIP	. 680	5%	1/10W						
		/ WARTARIE I	SEGIGTOD \			D811	8-719-157-33	DIODE RD	6. 2M-B		
		< VARIABLE F	RESISION >					< FERRITE	BEAD >		
RV401	1-241-506-11	RES, VAR, CA	ARBON 1K/1	K (HE	ADPHONES)						
*****	********	*******	*****	****	*****	FB801	1-543-813-21	FILTER, EM	I		
						FB802	1-543-813-21	FILTER, EM	I		
						FB804	1-543-813-21	FILTER, EM	II		
						FB805	1-543-813-21	FILTER, EM	I		
						FB806	1-543-813-21	FILTER, EM	II		
						FB811	1-543-813-21	FILTER, EM	I		
							1-543-813-21				
							1-543-813-21				
							1-543-813-21				

KM-13 PS-317 PS-317P

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Descri	ption			Remark
	- 	< JACK >				R833	1-216-073-00	METAL	CHIP	10K	5%	1/10₩
						R834	1-216-073-00	METAL	CHIP	10K	5%	1/10W
J888	1-569-766-11	JACK				R835	1-216-073-00	METAL	CHIP	10K	5%	1/10W
						R836	1-216-073-00	METAL	CHIP	10K	5%	1/10W
		< TRANSISTOR	>			R837	1-216-073-00			10K	5%	1/10W
Q801	8-729-140-47	TRANSISTOR	2SC3735-1	B35	.	R838	1-216-073-00	METAL	CHIP	10K	5%	1/10W
Q802	8-729-140-47		2SC3735-I			R839	1-216-073-00			10K	5%	1/10W
Q803	8-729-140-47		2SC3735-I			R840	1-216-073-00			10K	5%	1/10W
Q804	8-729-140-47		2SC3735-I			R841	1-216-073-00			10K	5%	1/10W
Q805	8-729-923-80		DTC143EK	, D00		R842	1-216-073-00			10K	5%	1/10W
Q806	8-729-923-80	SOTSISANGT	DTC143EK			R843	1-216-073-00	METAL	CHIP	10K	5%	1/10W
Q807	8-729-923-80		DTC143EK			1043	1 210 070 00	IIIL IIIL	OIIII	1011	V/II	1/1011
Q808	8-729-923-80		DTC143EK					< VIR	RATOR >			
Q809	8-729-923-80		DTC143EK					\ VIDI	INTOIL /			
Q810	8-729-923-80					X801	1-577-101-11	WIDDAT	TOD CEDAN	ATC /A	10MH~\	
Ø10	8-729-923-60	TRANSTSTUR	DTC143EK			i i	*********					*****
		< RESISTOR >										
						*	A-7071-955-A					
R801	1-216-025-00	METAL CHIP	100	5%	1/10W	*	A-7072-021-A	PS-317	P BOARD,	COMPLE	TE (AEI	P, UK)
R802	1-216-049-00	METAL CHIP	1K	5%	1/10W			*****	*******	*****	**	
R803	1-216-053-00	METAL CHIP	1. 5K	5%	1/10₩					(Re	f. No 3,	000series)
R804	1-216-025-00	METAL CHIP	100	5%	1/10W							
R805	1-216-049-00	METAL CHIP	1K	5%	1/10W			< DIOI	DE >			
R806	1-216-053-00	METAL CHIP	1. 5K	5%	1/10W	D201	8-719-037-62	LED	CL-140D-0	CD-T (F	RECORDE	R)
R807	1-216-025-00	METAL CHIP	100	5%	1/10W	D202	8-719-985-27	LED	CL-140Y-0	CD (PLA	YER 3)	
R808	1-216-041-00		470	5%	1/10W	D203	8-719-985-27		CL-140Y-0			
R809	1-216-053-00		1. 5K		1/10W	D204	8-719-985-27		CL-140Y-0	•		
R810	1-216-073-00		10K	5%	1/10W	D205	8-719-984-31		CL-140R-0			
R811	1-216-025-00	METAL CHIP	100	5%	1/10W	D206	8-719-987-02	LED	CL-140PG-	-CD (P(OWER ON	/0FF)
R812	1-216-049-00		1K	5%	1/10W		0 110 001 02	222	00 11014	· (, (, o ,	, 411,
R813	1-216-053-00		1. 5K		1/10W			< RES	ISTOR >			
R814	1-216-025-00		100	5%	1/10W			· IIDO	ibion /			
R815	1-216-041-00		470	5%	1/10W	R201	1-216-029-00	METAI	CHIP	150	5%	1/10W
11013	1 210 041 00	MLIAL VIII	410	J <i>7</i> 0	1/10#	R202	1-216-029-00			150	5%	1/10W
D016	1-216-053-00	METAL CUID	1 EV	EW	1 /10W	R203	1-216-029-00			150	5%	1/10\\
R816			1. 5K 10K	5%	1/10\ 1/10\		1-216-029-00			150	5%	1/10\\\
R817	1-216-073-00				•	R204					5%	
R818	1-216-025-00		100	5%	1/10W	R205	1-216-041-00	METAL	UNIP	470	376	1/10W
R819	1-216-041-00		470	5% 5%	1/10W	pane	1_216_020_00	ИСТАІ	CUID	150	E9/	1/10W
R820	1-216-053-00	METAL UNIP	1. 5K	J <i>7</i> 6	1/10W	R206	1-216-029-00	MCIAL	СПІР	150	5%	1/10#
R821	1-216-073-00	METAL CHIP	10K	5%	1/10W	1		< SWIT	rch >			
R822	1-216-025-00	METAL CHIP	100	5%	1/10W							
R823	1-216-049-00	METAL CHIP	1K	5%	1/10W	S201	1-692-446-11	SWITCH	i, TACTIL	(LS201	3B-2-T)	(RECORDER)
R824	1-216-053-00	METAL CHIP	1. 5K	5%	1/10W	S202	1-692-446-11	SWITCH	i, TACTIL	(LS20E	3B-2-T)	(PLAYER 3)
R825	1-216-025-00	METAL CHIP	100	5%	1/10W	S203	1-692-446-11	SWITCH	I, TACTIL	(LS20F	3B-2-T)	(PLAYER 2)
					,	S204	1-692-446-11		•	•		-
R826	1-216-041-00	METAL CHIP	470	5%	1/10W	S205	1-692-446-11					
R827	1-216-053-00		1. 5K		1/10W		11		R ON/STAND		/	
R828	1-216-073-00		10 K	5%	1/10W	*****	******		-		*****	*****
R829	1-216-073-00		10K	5%	1/10W							
R830	1-216-073-00		10K	5%	1/10W							
					,							
R831	1-216-073-00	METAL CHIP	10K	5%	1/10W							
R832	1-216-073-00		10K	5%	1/10W							
					•	•						

PW-106P PW-106U RP-175

RP-175P

Ref. No.	Part No.	Description		Rem	ark	Ref. No.	Part No.	Description Remark
<u>^</u> * <u>^</u> *		PW-106P BOARD, CO PW-106U BOARD, CO ************************************	MPLETE (US,	Canadi		⚠ D001	8-719-510-06	
A A.	1-533-189-11	FUSE, GLASS TUBE HOLDER, FUSE FUSE (H. B. C.) (AE		an)		∱ F301 ∱ F302		< FUSE > FUSE, MICRO (SECONDARY) (US, Canadian) FUSE, MICRO (SECONDARY) (US, Canadian)
		< CAPACITOR >						< COIL >
⚠C001 ⚠C002 ⚠C003	1-104-706-11 1-104-705-11 1-107-397-11	FILM 0	. 22uF . 1uF 30uF	20% 20% 20%	250V 250V 200V	L021 L022		CIL, CHOKE 22uH CIL, CHOKE 22uH
 €0003	1-107-400-11	(US, Canadian) ELECT 1 (AEP, UK)	50uF	20%	400V	∕ ∧ LF001	1-424-672~11	< LINE FILTER > TRANSFORMER, LINE FILTER
 \$€000	1-161-740-00		70PF	10%	400V	<u> </u>		< IC LINK >
<u></u> \$\$\doldown{\hat{C}}\$\$\$008	1-161-741-00	CERAMIC 0 (AEP, UK)	. 001uF	10%	400V			LINK, IC 2.0A (ICP-N50) (AEP, UK) LINK, IC 1.0A (ICP-N25) (AEP, UK)
 €C009	1-161-740-00	CERAMIC 4 (US, Canadian)	70PF	10%	400V			< RESISTOR >
∆ C009	1-161-741-00	(AEP, UK)	. 001uF	10%	400V	_	1-214-947-00	· · · · - · - · - · - · · · ·
∆ C010	1-161-741-00	(AEP, UK)	. 001uF	10%	400V		1-216-397-11 ******	WIREWOUND 4.7 10% 2W F
∆ C011	1-161-741-00	(AEP, UK)	. 001uF	10%	400V	*		RP-175 BOARD, COMPLETE (US, Canadian) RP-175P BOARD, COMPLETE (AEP, UK)
<u>∧</u> C012	1-161-742-00	CERAMIC 0. (US, Canadian)	. 0022uF	20%	400V			******* (Ref. No 2, 000 series)
∆ C012	1-162-599-12	(AEP, UK)	. 0047uF	20%	400V			< CONNECTOR >
∆ C013	1-162-599-12	CERAMIC 0. (AEP, UK)	. 0047uF	20%	400V	* CN101	1-562-717-11	CONNECTOR, 34P
∆ C014	1-162-599-12	CERAMIC 0. (AEP, UK)	. 0047uF	20%	400V			CONNECTOR, 34P CONNECTOR, 34P
C021	1-124-480-11	ELECT 4' (US, Canadian)	70uF	20%	25V			< DIODE >
C021	1-124-557-11	ELECT 10 (AEP, UK)	000uF	20%	25V	D101 D102	8-719-157-33 8-719-157-33	
C022	1-124-360-00	ELECT 10	000uF	20%	16V	D103	8-719-157-33 8-719-157-33	DIODE RD6. 2M-B
		< CONNECTOR >					8-719-157-33	
		PIN, CONNECTOR 2P PIN, CONNECTOR 7P					8-719-157-33 8-719-157-33 8-719-157-33	DIODE RD6. 2M-B
		< COMPOSITION CIRC	CUIT BLOCK	>		D901	8 [±] 719-106-43 8-719-106-43	DIODE RD9. 1M-B1
		POWER BLOCK (US, Ca POWER BLOCK (AEP, N				D903 D904	8-719-106-43 8-719-106-43 8-719-106-43	DIODE RD9. 1M-B1 DIODE RD9. 1M-B1
					1	D906	8-719-106-43	DIODE RD9. 1M-B1

The components identified by Les composants identifiés mark 🛕 or dotted line with mark. $\underline{\Lambda}$ are critical for safety. Replace only with part number specified.

par une marque 🕂 sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

RP-175 RP-175P

Ref. No.	Part No.	Descrip	tion	Remark	Ref. No.	Part No.	Descript	tion
D907	8-719-106-43	DIODE	RD9. 1M-B1	-			< FERRIT	TE BEAD >
D908	8-719-106-43		RD9. 1M-B1					
D909	8-719-106-43		RD9. 1M-B1		FB101	1-543-775-11	FILTER,	EMI
D910	8-719-106-43		RD9. 1M-B1		1	1-543-775-11		
D911	8-719-157-33		RD6. 2M-B		FB103	1-543-775-11	FILTER,	EMI
(0 110 101 00			!	FB104	1-543-775-11	FILTER,	EMI
D912	8-719-157-33	DIODE	RD6. 2M-B		FB105	1-543-775-11	FILTER,	EMI
D913	8-719-106-43		RD9. 1M-B1		ļ			
D914	8-719-106-43		RD9. 1M-B1		FB106	1-543-775-11	FILTER,	EMI
D915	8-719-106-43		RD9. 1M-B1		FB107	1-543-775-11	FILTER,	EMI
D916	8-719-106-43		RD9. 1M-B1		FB108	1-543-775-11	FILTER,	EMI
					FB109	1-543-775-11	FILTER,	EMI
D917	8-719-106-43	DIODE	RD9. 1M-B1		FB110	1-543-775-11	FILTER,	EMI
D918	8-719-106-43		RD9. 1M-B1					
D919	8-719-106-43		RD9. 1M-B1		FB111	1-543-775-11	FILTER,	EMI
D920	8-719-106-43		RD9. 1M-B1		FB112	1-543-775-11	FILTER,	EMI
D921	8-719-106-43		RD9. 1M-B1		FB113	1-543-775-11	FILTER,	EMI
2021	V 120 200 20					1-543-775-11		
D922	8-719-106-43	DIODE	RD9. 1M-B1			1-543-775-11		
D923	8-719-106-43		RD9. 1M-B1					
D924	8-719-106-43		RD9. 1M-B1		FB116	1-543-775-11	FILTER,	EMI
D925	8-719-106-43		RD9. 1M-B1			1-543-775-11		
D926	8-719-106-43		RD9. 1M-B1		FB132	1-543-775-11	FILTER,	EMI
0020	0 ,10 100 10	21022			FB133	1-543-775-11	FILTER,	EMI
D927	8-719-106-43	DIODE	RD9. 1M-B1		FB134	1-543-775-11	FILTER,	EMI
D928	8-719-106-43		RD9. 1M-B1			-	,	
D929	8-719-106-43		RD9. 1M-B1		FB135	1-543-775-11	FILTER.	EMI
D930	8-719-106-43		RD9. 1M-B1		1	1-543-775-11		
D931	8-719-106-43		RD9. 1M-B1		1	1-543-775-11		
D001	0 110 100 10	, ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	noor in or			1-543-775-11		
D932	8-719-106-43	DIODE	RD9. 1M-B1			1-543-775-11		
D933	8-719-106-43		RD9. 1M-B1					
D934	8-719-106-43		RD9. 1M-B1		FB140	1-543-775-11	FILTER,	EMI
D935	8-719-106-43		RD9. 1M-B1		i	1-543-775-11		
D936	8-719-106-43		RD9. 1M-B1		FB142	1-543-775-11	FILTER,	EMI
					FB143	1-543-775-11	FILTER,	EMI
D937	8-719-106-43	DIODE	RD9. 1M-B1		FB144	1-543-775-11	FILTER,	EMI
D938	8-719-106-43		RD9. 1M-B1					
D939	8-719-106-43		RD9. 1M-B1		FB145	1-543-775-11	FILTER,	EMI
D940	8-719-106-43		RD9. 1M-B1		FB146	1-543-775-11	FILTER,	EMI
D941	8-719-106-43		RD9. 1M-B1		FB147	1-543-775-11	FILTER,	EMI
					FB148	1-543-775-11	FILTER,	EMI
D942	8-719-106-43	BDIODE	RD9. 1M-B1		FB149			
D943	8-719-106-43		RD9. 1M-B1					
D944	8-719-106-43	BDIODE	RD9. 1M-B1		FB150	1-543-775-11	FILTER,	EMI
D945	8-719-106-43	BDIODE	RD9. 1M-B1		FB151	1-543-775-11	FILTER,	EMI
D946	8-719-106-43	BIODE	RD9. 1M-B1		FB152	1-543-775-11	FILTER,	EMI
					FB153	1-543-775-11	FILTER,	EMI
D947	8-719-106-43	BDIODE	RD9. 1M-B1		1	1-543-775-11		
D948	8-719-106-43		RD9. 1M-B1					
D949	8-719-106-43		RD9. 1M-B1		FB155	1-543-775-11	FILTER,	EMI
D950	8-719-106-43		RD9. 1M-B1	•		1-543-775-11	FILTER,	EMI
						1-543-775-11		
					FB158	1-543-775-11	FILTER,	EMI
					FB159	1-543-775-11	FILTER,	EMI
					FB160			
					FB161	1-543-775-11	FILTER,	EMI

Remark

Ref. No.	Part No.	Description Remark	Ref. No.	Part No.	Description	Remark
FB162	 1-543-775-11	FILTER, EMI		****	******	
FB163	1-543-775-11	FILTER. EMI		НΑ	RDWARE LIST	
	1-543-775-11				*******	
	1-543-775-11	·				
	1-543-775-11	·	#1	7-685-645-7	79 SCREW +BVTP 3X6 TYPE2 N-S	:
12100		1223.9	#2		19 SCREW +BTP 2.6X8 TYPE2 N-	
FB167	1-543-775-11	FILTER. EMI	#3		19 SCREW +P 2.6X6 TYPE2 NON-	
	1-543-775-11		#4		79 SCREW +BVTP 3X8 TYPE2 IT-	
	1-543-775-11		#5		19 SCREW +BVTT 3X6 (S)	•
	1-543-775-11		""	. 332 31. 3	or bollow by III one (b)	
	1-543-775-11	•	*****	******	**********	******
		< JACK >		ACCESSORI	IES & PACKING MATERIALS	
				******	*******	
* J101	1-537-672-11	TERMINAL BOARD (PLAYER INPUT 1/2)				
J103	1-750-211-11	JACK BLOCK, PIN 2P (AUX AUDIO INPUT)		1-467-685-1	l1 REPEATER, IR	
* J104	1-537-672-11	TERMINAL BOARD (PROCESSOR IN/OUT 1)	A.	1-574-056-1	11 CORD, POWER (250V/2.5A)	(AEP, UK)
* J105	1-537-648-11	TERMINAL BLOCK, S (PROCESSOR OUT 2)		1-574-316-1	L1 CORD, CONNECTION	
* J106		TERMINAL BOARD (PROCESSOR IN/OUT)			(LANC CONTROL (L) CABLE)	
		, , ,	ŀ	1-574-496-1	11 CORD, CONNECTION (S/GPI (CONTROL CABLE
▶ J107	1-537-648-11	TERMINAL BLOCK, S (MONITOR OUT)			11 CORD, CONNECTION (AV CABI	
J108		JACK, ULTRA SMALL (LANC)				,
J109		JACK, ULTRA SMALL (LANC)		1-575-335-2	21 CORD, CONNECTION (S VIDEO	CABLE)
J110		JACK, ULTRA SMALL (RECORDER)	i.	1 0.0 000 1	(AEP, UK)	
J111		JACK, STEREO HEADPHONE (GPI OUT)		1-590-796-2	21 CORD, CONNECTION	
		,,			(CONTROL L CONVERT CABLE)	ı
J112	1-563-935-31	JACK, STEREO HEADPHONE (CTRL S OUT)		1-590-879-1	11 CORD, CONNECTION (VISCA (
		**********			21 CORD, CONNECTION (S VIDEO	
					(US, Canadian)	,
		MISCELLANEOUS	Δ	1-751-676-1	11 CORD, POWER (125V/7A) (US	S, Canadian)
		*******		3-334-173-0	O1 SHEET, PROTECTION	
11	1-751-796-11	CORD, CONNECTION		3-677-503-0	3 SHEET, PROTECTION	
53	1-751-996-11	CABLE, 1. OMM PITCH FLAT (FAF-1)		3-757-948-1	1 MANUAL, INSTRUCTION (ENGI	JISH)
62	1-751-997-11	WIRE (FLAT) (FFC CONNECTOR)		3-757-948-3	31 MANUAL, INSTRUCTION (FREM	(CH)
<u>1</u> 75		INLET, AC (250V/2.5A) (AEP, UK)			(Canadian, AEP)	ŕ
<u>↑</u> 75		INLET, AC (250V/1A) (US, Canadian)		3-757-948-4	11 MANUAL, INSTRUCTION (GERM	IANY) (AEP)
103	1-467-712-11	KEY BOARD UNIT		3-757-948-5	51 MANUAL, INSTRUCTION (SPAN	(ISH) (AEP)
109		CORD, CONNECTION		3-757-948-6	61 MANUAL, INSTRUCTION (NET	IERLANDS) (AE
∱ F001	1-532-740-11	FUSE GLASS TUBE (125V/1A) (US, Canadian)		3-757-948-8	31 MANUAL, INSTRUCTION (ITAL	IAN) (AEP)
∱ F001	1-576-225-21	FUSE GLASS TUBE (250V/1A) (AEP, UK)	*	3-795-581-2	21 SAFEGUARD (SONY), IMPORTA	ANT (US)
		************	*	3-953-465-0	O1 CUSHION, FRONT	
		* * * * * * * * * * * * * * * * * * *	*	3-953-466-0	O1 CUSHION, REAR	
					OI CUSHION (R), PULPE	
			*		OI CUSHION (L), PULPE	
			•	0 000 704-0	OF CODITION (D), I ULL	

mark 🛕 or dotted line with mark. extstyle extstylsafety. Replace only with part number specified.

3-959-494-01 INDIVIDUAL CARTON 3-959-495-01 CUSHION (L), KEY BOARD

3-959-496-01 CUSHION (R), KEY BOARD

The components identified by Les composants identifiés par une marque $extstyle \Delta$ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.